



Technical Service Bulletin

Technical Service Bulletin: TSB200071

Released Date: 07-May-2020

Removal of Orifice Plug Gasket from all PT Fuel Injectors

Removal of Orifice Plug Gasket from all PT Fuel Injectors

Warranty Statement

The information in this document has no effect on present warranty coverage or repair practices, nor does it authorize TRP or Campaign actions.

Contents

Product Affected

- K19
- K38
- K50
- M11 MECHANICAL
- N14
- N14 MECHANICAL
- NH/NT 855
- V903
- VTA903 CM2250 V105

Description of Change

The orifice plug gasket, Part Number 173086, is being removed from all PT fuel injectors. See Figure 1 below.

The orifice plug gasket is a small, clear gasket, so it can be difficult to see.



Figure 1, Orifice Plug Gasket Location

Reason for Change

The orifice plug gasket is redundant and is not required to create a seal at this joint.

Service Parts Availability

The part numbers for PT fuel injectors are not changing as the removal of the orifice plug gasket has no impact on the fuel injectors form, fit, or function.

The orifice plug gasket does **not** need to be removed from existing injector inventory prior to use. See Table 1: PT Fuel Injectors, for a full list of fuel injectors affected by this change.

Table 1: PT Fuel Injectors				
Part Description	Part Number	Obsoleted	Superseded	Description of Change
PT Fuel Injector	3016675	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3016676	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3018333	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3018337	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3022196	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3022197	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3023035	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3045102	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3046281	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3047968	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3047973	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3047976	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3047978	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3047979	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3047980	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3047981	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3047982	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3047983	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3047991	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3047992	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3049149	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3052226	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3052255	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3053124	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3053126	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3053206	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054047	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054048	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054049	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054051	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054053	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054058	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3054063	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054067	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054071	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054074	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054075	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054077	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054081	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054085	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054086	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054087	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3054088	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054089	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054091	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054095	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054097	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054196	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054197	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054199	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054204	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054205	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3054208	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054210	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054211	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054216	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054217	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054218	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054219	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054220	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054222	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054223	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3054224	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054225	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054226	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054227	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054228	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054231	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054232	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054233	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054236	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054238	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3054239	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054240	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054242	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054243	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054244	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054245	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054247	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054248	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054249	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054250	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3054251	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054252	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054253	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054254	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054255	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054256	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3054258	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3058849	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3062153	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3062535	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3064253	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3066486	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3068824	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3068825	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3068826	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3068899	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3069759	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3069767	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3070178	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3070649	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3071047	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3071490	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3071491	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3071492	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3071494	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3071495	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3071496	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3071497	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3071498	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3071499	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3071500	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3073754	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3073776	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3073778	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3074250	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3074251	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3074252	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3074319	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3074807	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3075343	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3075447	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3076132	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3076133	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3076134	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3076700	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3076702	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3076703	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3076704	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3076736	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3077709	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3077711	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3077714	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3077715	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3077718	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3077760	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3078016	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3078194	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3078195	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3078196	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3078197	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3078198	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3078206	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3079669	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3079946	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3079947	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3080415	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3081277	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3081368	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3083689	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3083764	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3083879	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3084108	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3084109	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3084110	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3084398	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3084399	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3084470	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3084724	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3084891	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3084934	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3087587	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3087648	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3095023	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3095055	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3095058	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3095460	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3095773	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3096538	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3253545	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3254076	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3278884	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3279505	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3279512	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3279513	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3279636	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3279660	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3279661	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3279664	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3279742	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3279743	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3279744	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3279745	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3279754	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3279801	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3279803	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3279830	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3349821	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3349860	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3349861	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3406592	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3406604	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3406704	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3406707	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3406714	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3411821	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3411827	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3609808	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3609840	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3609849	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3609865	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	3609913	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3609932	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3609962	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3609968	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3627922	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3629008	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	3676984	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4010642	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4054162	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4062154	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	4062311	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4071552	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4088105	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4307331	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4307426	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4307428	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4326359	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4326360	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4326413	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4326618	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	4345890	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4396920	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4902783	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4912080	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4912717	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4913146	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4914177	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4914308	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4914328	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4914452	No	No	Removal of orifice plug gasket PN 173086

PT Fuel Injector	4914458	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4914505	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4914537	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4914554	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4914555	No	No	Removal of orifice plug gasket PN 173086
PT Fuel Injector	4950431	No	No	Removal of orifice plug gasket PN 173086

Document History

Date	Details
2020-3-23	Module Created
2020-5-5	Non-Product Problem Solving (PPS)

Last Modified: 07-May-2020
