

-
-
- [Manual Change History](#)
- [Print This Page](#)

- [Section 1 - Level 1 - Maintenance and Troubleshooting](#)

- [\(3162384\) 3/16 Ball Driver](#)
- [\(5394386\) Aftertreatment Leak Test Kit](#)
- [\(5299448\) APR Liner Tool Kit](#)
- [\(4918413\) Banjo Connector Screw](#)
- [\(3165175\) Barring Plug Remover](#)
- [\(st747\) Barring Tool](#)
- [\(3824270\) Barring Tool](#)
- [\(3163160\) Engine Barring Adapter Kit](#)
- [\(3165001\) Barring Tool Adapter Kit](#)
- [\(st1138\) Belt Tension Gauge](#)
- [\(3164750\) Belt Tension Gauge](#)
- [\(3163569\) Belt Tension Gauge](#)
- [\(3376344\) Belt Tension Gauge](#)
- [\(3823772\) Belt Tension Gauge](#)
- [\(3822524\) Belt Tension Gauge \(Click Type\)](#)
- [\(3375150\) Blow-By Tool](#)
- [\(3376949\) Blow-By Tool](#)
- [\(3822566\) Blow-By Tool \(Use with ST 111-3\)](#)
- [\(3163530\) Brake Setting Feeler Gauge](#)
- [\(3163534\) Carburetor Adjuster](#)
- [\(3823204\) C-Brake Oil Pressure Test Kit](#)
- [\(3822985\) Combustion Leak Test Kit](#)
- [\(3164627\) Compression Gauge](#)
- [\(3162401\) Compression Test Adapter](#)
- [\(3162402\) Compression Test Adapter](#)
- [\(3162403\) Compression Test Adapter](#)
- [\(3377405\) Cooling Sight Glass](#)
- [\(4918282\) Cover, Cylinder Head Protective](#)
- [\(3162225\) Crowsfoot Wrench](#)
- [\(3824212\) Cylinder Diagnostics Kit](#)
- [\(5394335\) Cylinder Diagnostics Kit](#)
- [\(5394325\) DEF Doser Test Stand](#)
- [\(st537\) Dial Depth Gauge](#)
- [\(5394562\) Diesel Exhaust Fluid System Pressure Test Kit](#)
- [\(5298803\) Diesel Particulate Filter Cleaner Adapter Kit](#)
- [\(3824215\) Differential Pressure Test Kit](#)
- [\(3375631\) Digital Tachometer Assembly](#)
- [\(5299873\) Doser Extension Kit](#)
- [\(st1224\) Dual Tachometer Drive Adapter](#)
- [\(2892313\) EGR Cooler Leak Check Kit](#)
- [\(3164225\) EGR Cooler Leak Check Kit](#)
- [\(2892437\) EGR Cooler Leak Test Kit](#)
- [\(4919424\) EGR Cooler Leak Test Kit](#)
- [\(4919688\) EGR Cooler Leak Test Kit](#)
- [\(5299224\) EGR Cooler Leak Test Kit](#)
- [\(5395049\) EGR Cooler Leak Test Kit](#)
- [\(3164843\) EGR Cooler Leak Tester Kit](#)
- [\(3164463\) Electronic Throttle Actuator](#)
- [\(5394688\) Emersion Heater Socket](#)

- [\(5395488\) Engine Barring Drive Gear](#)
- [\(5299967\) Engine Barring Tool](#)
- [\(3822994\) Engine Coolant Analyzer](#)
- [\(4919726\) Exhaust Gas Recirculation \(EGR\) Cooler Leak Test Kit](#)
- [\(5298810\) Exhaust Gas Recirculation \(EGR\) Cooler Leak Test Kit](#)
- [\(3163173\) Exhaust Manifold Alignment Kit](#)
- [\(5395153\) Exhaust Manifold Seal Installation Tool](#)
- [\(3165116\) Fan Hub Lock Nut Replacer](#)
- [\(st832\) Fan Hub Wrench](#)
- [\(3375785\) Fan Hub Wrench](#)
- [\(3163681\) Feeler Gauge](#)
- [\(3823783\) Feeler Gauge](#)
- [\(3823802\) Feeler Gauge](#)
- [\(3376579\) Filter Cutter](#)
- [\(5394825\) Fuel Injector Isolation Tool](#)
- [\(3164044\) Fuel Pressure Gauge Adapter](#)
- [\(4919698\) Fuel Pressure Test Kit](#)
- [\(3162887\) Fuel Pump Idle Adjust Tool](#)
- [\(5395230\) Fuel Pump Test Kit](#)
- [\(3164617\) Fuel Pump Tester](#)
- [\(3164621\) Fuel Pump Tester](#)
- [\(4918193\) Fuel Pump Timing Kit](#)
- [\(3164383\) Fuel Sight Glass](#)
- [\(4298804\) Fuel System Leak Test Kit](#)
- [\(4918354\) Fuel System Leak Test Kit](#)
- [\(3164325\) Fuel System Leak Tester](#)
- [\(3164618\) Fuel System Leak Tester](#)
- [\(4919546\) Fuel System Leak Tester](#)
- [\(5395434\) Fuel System Pressure Tester](#)
- [\(5395147\) Fuel System Pressure Test Kit](#)
- [\(3162374\) Gas Pressure Gauge](#)
- [\(3165168\) Gauge Mounting Base](#)
- [\(4918217\) Gauge, Feeler](#)
- [\(3376337\) Geared Torque Multiplier](#)
- [\(3823782\) Hand Tachometer](#)
- [\(5394326\) Head Stud Length Gauge](#)
- [\(3400157\) Heavy Duty Oil Filter Wrench](#)
- [\(3823610\) Injector Adjustment Kit](#)
- [\(3823275\) Injector Adjustment Kit With Jacobs Brakes](#)
- [\(3823756\) Injector Adjustment Wrench](#)
- [\(3822575\) Injector and Valve Adjustment Kit](#)
- [\(3822509\) Injector Bore Brush](#)
- [\(3822510\) Injector Bore Brush](#)
- [\(3825165\) Injector Fuel](#)
- [\(3163194\) Injector Fuel Shut-Off](#)
- [\(3376872\) Injector Puller](#)
- [\(3822304\) Injector Puller](#)
- [\(3823024\) Injector Puller](#)
- [\(3162745\) Injector Puller Assembly](#)
- [\(3163483\) Injector Puller/Driver](#)
- [\(3823579\) Injector Puller/Installer](#)
- [\(3824653\) Injector Puller/Installer](#)
- [\(3824830\) Injector Puller/Installer](#)
- [\(3164464\) Injector Remover](#)
- [\(3164706\) Injector Remover](#)
- [\(4919661\) Injector Remover](#)
- [\(st1145\) Injector Torquing Adapter](#)
- [\(5299465\) J1939 Component Isolation Kit](#)

- [\(4918187\) Kit, Exhaust Manifold Leak Test](#)
- [\(5395162\) Leak Test Hose](#)
- [\(2892320\) Leak Test Kit](#)
- [\(3164410\) Locating Gauge](#)
- [\(5394441\) Magnetic Digital Angle Indicator](#)
- [\(3824569\) Magnetic Pointer/Timing Tape](#)
- [\(3164875\) Manometer](#)
- [\(3375935\) Marine Test Kit](#)
- [\(3400158\) Nylon Strap Oil Filter Wrench](#)
- [\(3376191\) Offset Wrench](#)
- [\(4918767\) Plug, Protective](#)
- [\(5298511\) Premium Spark Plug Gauge Kit](#)
- [\(st1273\) Pressure Gauge](#)
- [\(3375273\) Pressure Kit](#)
- [\(5394427\) Pressure Test Adapter - 3/4" - 16 JIC w/ Compuccheck](#)
- [\(4918932\) Protective Cover Kit](#)
- [\(4918934\) QSK19 and QSK38 Fuel System Protective Cover Kit](#)
- [\(5299057\) QSK19 SCR Engine Protective Cover Kit](#)
- [\(4918935\) QSK50 and QSK60 Fuel System Protective Cover Kit](#)
- [\(5298998\) QSK50 SCR Engine Protective Cover Kit](#)
- [\(5394245\) QSK95 Alternator Alignment Fixture](#)
- [\(3823700\) Rail Pressure Response Kit](#)
- [\(4919554\) Refractometer](#)
- [\(4918469\) Remover, Fuel Connector](#)
- [\(4918218\) Remover, Injector](#)
- [\(3163270\) Sight Glass Assembly](#)
- [\(3375932\) Snap Rail Pressure Gauge](#)
- [\(3824877\) Snap Rail Pressure Gauge](#)
- [\(st983\) Spanner Wrench](#)
- [\(3164898\) Spark Plug Adapter Replacer](#)
- [\(3824449\) Spark Plug Boot Remover](#)
- [\(4918793\) Spark Plug Socket](#)
- [\(3162231\) Spark Plug Wrench](#)
- [\(st1326\) Tachometer Drive Puller](#)
- [\(st1032\) Tachometer Seal Driver](#)
- [\(3162367\) Tappet Adjustment Wrench](#)
- [\(3822695\) Tappet Set Feeler Gauge](#)
- [\(3162420\) Telescoping Gauge](#)
- [\(4918234\) Tester, Exhaust Manifold Leak](#)
- [\(4918343\) Tester, Ignition Coil](#)
- [\(5394810\) Thread Repair Kit](#)
- [\(4918796\) Throttle Position Gauge](#)
- [\(3164899\) Throttle Shaft Bearing Installer](#)
- [\(3163021\) Timing Tool Kit](#)
- [\(3824568\) Timing Tool - Spill Port/High Pressure](#)
- [\(3824570\) Top Dead Center Locator](#)
- [\(3164794\) Torque Wrench](#)
- [\(3376592\) Torque Wrench - Inch Pound](#)
- [\(3823208\) Torque Wrench - Inch Pound](#)
- [\(5572826\) Turbo Support Lifting Kit](#)
- [\(st434\) Vacuum Gauge](#)
- [\(3162422\) Vacuum Pump](#)
- [\(4919473\) Valve Setting Feeler Gauge Kit](#)
- [\(3823799\) Waste Gate Pressure Test Kit](#)
- [\(3824433\) Waste Gate Pressure Test Kit](#)
- [Section 2 - Level 2 - In-Frame Overhaul Tools](#)
 - [\(2892191\) 21mm Impact Socket](#)
 - [\(3165161\) 24-MM Impact Socket](#)

- [\(st837\) Accessory Drive Bushing Driver](#)
- [\(3824703\) Accessory Drive Bushing Tool](#)
- [\(3823581\) Accessory Drive Gear Mandrel](#)
- [\(3824922\) Accessory Drive Oil Seal Installer](#)
- [\(3825104\) Accessory Drive Oil Seal Installer](#)
- [\(3824451\) Accessory Drive Seal Tool](#)
- [\(3824508\) Accessory Drive Wear Sleeve Installer](#)
- [\(3824452\) Accessory Drive Wear Sleeve Tool](#)
- [\(3377148\) Accessory Shaft Seal Expander](#)
- [\(5394457\) Aftertreatment Installation Gauge Kit](#)
- [\(3823528\) Air Compressor Seat Installation Socket](#)
- [\(5394292\) Air Handling Clean Care Kit](#)
- [\(3163059\) Air Impact Wrench](#)
- [\(3823154\) AV Seal Removal/Installation Kit](#)
- [\(5394231\) Base Engine Clean Care Kit](#)
- [\(3162411\) Bearing Installer](#)
- [\(3162412\) Bearing Remover](#)
- [\(4919740\) Bearing Replacer Kit](#)
- [\(3375787\) Bent Wrench](#)
- [\(3162423\) Blind Hole Puller Set](#)
- [\(5394744\) Bushing Replacer](#)
- [\(3824519\) Cam Follower Installations/Removal Fixture](#)
- [\(3162895\) Cam Gear Puller Kit](#)
- [\(3163054\) Cam Gear Removal and Installation Tool](#)
- [\(3163069\) Cam Gear Remover](#)
- [\(3823295\) Cam Install/Removal Tool](#)
- [\(5299981\) Camshaft Bearing Remover](#)
- [\(3164640\) Camshaft Bushing Installer](#)
- [\(3164407\) Camshaft Bushing Removal Kit](#)
- [\(4918438\) Camshaft Bushing Removal Kit](#)
- [\(4919308\) Camshaft Bushing Replacer](#)
- [\(3165034\) Camshaft Bushing Replacer Kit](#)
- [\(4919258\) Camshaft Bushing Replacer Kit](#)
- [\(4919265\) Camshaft Bushing Replacer Kit](#)
- [\(3164375\) Camshaft Gear Remover Kit](#)
- [\(3165093\) Camshaft Gear Replacer Kit](#)
- [\(3163732\) Camshaft Guide](#)
- [\(4919438\) Camshaft Guide Kit](#)
- [\(3376388\) Camshaft Guide Pilot](#)
- [\(3375268\) Camshaft Installation Pilot](#)
- [\(4919107\) Camshaft Timing Plate](#)
- [\(5395527\) Component Lifting Crane](#)
- [\(3375098\) Connecting Rod Guide Pin](#)
- [\(3377397\) Connecting Rod Guide Pins](#)
- [\(3163471\) Connecting Rod Piston Remover](#)
- [\(3823745\) Coolant Pressure Test Fixture Assembly](#)
- [\(3163785\) Counterbore Ledge Cutter Drive Unit](#)
- [\(3824789\) Counterbore Salvage Kit](#)
- [\(3376563\) Counterbore Tool](#)
- [\(3823326\) Counterbore Tool](#)
- [\(st887\) Crankshaft Flange Puller](#)
- [\(3164659\) Crankshaft Front Seal Replacer Kit](#)
- [\(4919374\) Crankshaft Oil Seal Installers](#)
- [\(4919263\) Crankshaft Pulley Collar Remover Kit](#)
- [\(3164660\) Crankshaft Rear Replacer Kit](#)
- [\(3164900\) Crankshaft Seal Installer](#)
- [\(4919705\) Crankshaft Seal Installer](#)
- [\(3164987\) Crankshaft Seal Installer Kit \(Front & Rear\)](#)

- [\(4918499\) Crankshaft Seal Replacer](#)
- [\(4919660\) Crankshaft Seal Replacer](#)
- [\(4919704\) Crankshaft Seal Replacer](#)
- [\(3163349\) Crankshaft Seal Replacer Kit](#)
- [\(4918798\) Crankshaft Seal Replacer Kit](#)
- [\(4919533\) Crankshaft Seal Replacer Kit](#)
- [\(4919752\) Crankshaft Seal Replacer Kit](#)
- [\(5298540\) Crankshaft Seal Replacer Kit](#)
- [\(3824424\) Crankshaft Sleeve/Seal Installer](#)
- [\(3823292\) Cylinder Block Counterbore "Step" Ring Gauge](#)
- [\(st1183\) Cylinder Liner Clamp](#)
- [\(3822503\) Cylinder Liner Clamp Set](#)
- [\(3164996\) Cylinder Liner Remover](#)
- [\(3376419\) Damper Torque Fixture](#)
- [\(3376619\) Dial Bore Gauge Kit](#)
- [\(st1325\) Dial Gauge Attachment](#)
- [\(3376050\) Dial Indicator Assembly](#)
- [\(st404\) Drill and Ream Fixture](#)
- [\(3162435\) Drive Handle](#)
- [\(3824270\) Engine Barring Tool](#)
- [\(5298916\) Engine Brake Piston Remover](#)
- [\(5395137\) Engine Lifting Hook](#)
- [\(3822390\) Engine Rack Parts](#)
- [\(3822747\) Engine Speed Sensor Socket](#)
- [\(3375272\) Engine Support Bracket Kit](#)
- [\(5298582\) Engine Timing Kit](#)
- [\(4919376\) Exhaust Lockplate Installer Kit](#)
- [\(3163173\) Exhaust Manifold Alignment Kit](#)
- [\(5394351\) Expansion Plug Installer](#)
- [\(5394402\) Expansion Plug Installer](#)
- [\(3823531\) Fan Temperature Switch Socket](#)
- [\(3823612\) Flexible Hose](#)
- [\(3376606\) Flywheel Housing Alignment Plate](#)
- [\(3376578\) Front Crank Spacer Plate](#)
- [\(3162408\) Front Crankshaft Oil Seal Installer](#)
- [\(3162992\) Front Crankshaft Seal R/I Kit](#)
- [\(3164926\) Front Crankshaft Seal Replacer Kit](#)
- [\(3163485\) Front Crankshaft Seal/Sleeve R&I Kit](#)
- [\(3377198\) Fuel Pump S Wrench](#)
- [\(3375764\) Fuel Pump Wrench](#)
- [\(3823144\) Fuel Pump Wrench](#)
- [\(st400\) Gear Cover Alignment Plug](#)
- [\(st1171\) Gear Cover Busing Mandrel](#)
- [\(st598\) Gear Cover Busing Mandrel](#)
- [\(3823774\) Gear Housing Bearing Install/Remove Tool](#)
- [\(3376696\) Guide Pin](#)
- [\(3824454\) Guide Pin](#)
- [\(5394346\) Guide Pin](#)
- [\(5299935\) Guide Stud](#)
- [\(5299936\) Guide Stud](#)
- [\(3164406\) Guide, Camshaft](#)
- [\(3823488\) Heat Plug Socket](#)
- [\(5395578\) Hydraulic Stud Tensioner](#)
- [\(3376194\) Impact Drive Socket](#)
- [\(5394247\) In-Frame Overhaul](#)
- [\(2892426\) Injection Timing Kit](#)
- [\(4918620\) Injector Installer](#)
- [\(3376271\) Injector and Valve Tappet Kit](#)

- [\(3375155\) Injector Protrusion Comparator](#)
- [\(3376461\) Injector Timing Fixture](#)
- [\(3824942\) Injector Timing Tool](#)
- [\(5394255\) Isolator Adjusting Wrench](#)
- [\(5394237\) Isolator Retaining Bolt Kit](#)
- [\(3823819\) Jumper Tube Removal Tool](#)
- [\(5395381\) Lifting Fixture](#)
- [\(5394651\) Lifting Ring Kit](#)
- [\(3823231\) Liner Bore Chip Control Plug](#)
- [\(st1229\) Liner Driver](#)
- [\(3823615\) Liner Installation Tool](#)
- [\(3163745\) Liner Puller \(Universal\)](#)
- [\(3376015\) Liner Puller \(Universal\)](#)
- [\(st414\) Liner Removal Tool](#)
- [\(3164404\) Locating Gauge](#)
- [\(3163500\) Lockplate Installer Kit](#)
- [\(3377399\) Magnetic Base Indicator Holder](#)
- [\(st1116\) Main Bearing Cap Puller](#)
- [\(3375356\) Main Bearing Cap Puller](#)
- [\(4919744\) Main Bearing Cap Remover](#)
- [\(3164620\) Main Bearing Replacer](#)
- [\(3823818\) Main Bearing Roll-out Tool](#)
- [\(3824652\) Master Cam Gear](#)
- [\(3377229\) Mechanical Variable Timing Kit](#)
- [\(3824117\) Needle Bearing Driver](#)
- [\(3824832\) Oil Capacitor Installer](#)
- [\(st1263\) Oil Seal Expander](#)
- [\(3376076\) Oil Seal Expander](#)
- [\(3376098\) Oil Seal Expander](#)
- [\(3376099\) Oil Seal Expander](#)
- [\(3376496\) Oil Seal Expander](#)
- [\(3162395\) Oil Seal Guide and Driver](#)
- [\(3375818\) Oil Seal Installation Capscrew](#)
- [\(st480\) Oil Seal Installer](#)
- [\(st971\) Oil Seal Installer](#)
- [\(st972\) Oil Seal Installer](#)
- [\(st1071\) Oil Seal Installer](#)
- [\(st1093\) Oil Seal Installer](#)
- [\(st1108\) Oil Seal Installer](#)
- [\(st1163\) Oil Seal Installer](#)
- [\(st1164\) Oil Seal Installer](#)
- [\(st1165\) Oil Seal Installer](#)
- [\(st1172\) Oil Seal Installer](#)
- [\(st1185\) Oil Seal Installer](#)
- [\(st1304\) Oil Seal Installer/Puller](#)
- [\(3375111\) Oil Seal Installer/Puller](#)
- [\(3375496\) Oil Seal Puller Drill Pilot](#)
- [\(3163826\) Oil Seal Replacer](#)
- [\(3824760\) Oil Seal/Wear Sleeve Installer/Puller](#)
- [\(5395300\) P80 Alternator Adjusting Screw Kit](#)
- [\(3375164\) Pilot Ring](#)
- [\(3823299\) Piston Cooling Nozzle Tool](#)
- [\(3164330\) Piston Ring Compressor](#)
- [\(3164399\) Piston Ring Compressor](#)
- [\(3164846\) Piston Ring Compressor](#)
- [\(3822736\) Piston Ring Compressor](#)
- [\(4918294\) Piston Ring Compressor](#)
- [\(4919373\) Piston Ring Compressor](#)

- [\(st1240\) Piston Ring Compressor Sleeve](#)
- [\(3164604\) Piston Ring Compressors](#)
- [\(st760\) Piston Ring Expander](#)
- [\(3823137\) Piston Ring Expander](#)
- [\(3823925\) Piston Ring Groove Gauge](#)
- [\(st560\) Piston Ring Groove Wear Gauge](#)
- [\(5299934\) Piston Ring Replacer](#)
- [\(5394538\) Power Cylinder Replacer](#)
- [\(3823096\) Power Steering Assembly Fixture](#)
- [\(3823765\) Pulley Adapter Kit](#)
- [\(3824502\) Pulley Adapter Kit](#)
- [\(5394249\) Pulley Installation Adapter](#)
- [\(3376326\) Pulley Installation Tool](#)
- [\(5299974\) QSK95 Lube Pump Lifting Kit](#)
- [\(3165000\) Ratcheting wrench 5/8-inch](#)
- [\(3162414\) Rear Camshaft Bearing Installer](#)
- [\(3162410\) Rear Crankshaft Oil Seal Installer](#)
- [\(3164302\) Rear Crankshaft Seal Replacer Kit](#)
- [\(3164780\) Rear Crankshaft Seal Replacer Kit](#)
- [\(3822980\) Rear Oil Seal Installation Tool](#)
- [\(3824078\) Rear Seal/Sleeve Installer](#)
- [\(3376486\) Regulator Valve Seat Driver](#)
- [\(4918530\) Replacer, Gear](#)
- [\(5395002\) Rod Support Fixture](#)
- [\(5394236\) SCR Clean Care Kit](#)
- [\(3162409\) Seal Expander](#)
- [\(3824498\) Seal Installer](#)
- [\(3824499\) Seal Installer](#)
- [\(5394637\) Seal Installer](#)
- [\(3162405\) Seal Remover Disk](#)
- [\(3164197\) Seal Replacer Kit](#)
- [\(4919291\) Sensor Socket](#)
- [\(5394254\) Sensor Socket](#)
- [\(3823942\) Small Bushing Driver Set](#)
- [\(3375292\) Socket Set - Heavy Duty](#)
- [\(3823228\) Special Fuel Pump Wrench](#)
- [\(3162417\) Special Tool Kit](#)
- [\(3376663\) Spline Coupling Puller](#)
- [\(st647\) Standard Puller](#)
- [\(3164396\) Stud Replacer](#)
- [\(3823461\) Super Chip Vacuum Kit](#)
- [\(3823374\) Tapered Cutter Plate Assembly Low Profile](#)
- [\(3165088\) Tappet Installation/Removal Tool](#)
- [\(3822513\) Tappet Replacement Kit](#)
- [\(3823843\) Temperature Sensor Socket](#)
- [\(3377418\) Template Spinner](#)
- [\(2892254\) Thermostat Seal Installer](#)
- [\(3377291\) Thermostat Seat Driver](#)
- [\(4919663\) Timing Pin](#)
- [\(3822694\) Timing Pin Extender](#)
- [\(5394743\) Torque Adapter](#)
- [\(3824520\) Torque Angle Socket](#)
- [\(3400034\) Torx Plus Driver Set](#)
- [\(st1182\) Valve Spring Nozzle Locator](#)
- [\(st1107\) Wear Sleeve Installer](#)
- [\(3824500\) Wear Sleeve Installer](#)
- [\(3165112\) Wear Sleeve Installer](#)
- [\(3824971\) Wear Sleeve Installer/Remover](#)

- [\(3825191\) Wear Sleeve/Seal Installer/Remover](#)
- [\(3823489\) Wobble Drive Extension](#)
- [Section 3 - Level 3 - Group 1 - Cylinder Block Group](#)
 - [\(5572700\) Adapter](#)
 - [\(5572913\) Adapter Gear Remover Kit](#)
 - [\(5394691\) APR Liner Tool Kit](#)
 - [\(5395253\) APR Liner Tool Kit](#)
 - [\(5394828\) Base Engine Clean Care Kit](#)
 - [\(3162411\) Bearing Installer](#)
 - [\(3376821\) Bearing Mandrel](#)
 - [\(5394531\) Block Skirt Inspection Gauge](#)
 - [\(5573020\) Bushing Removal & Installation Tool](#)
 - [\(3376234\) Cam Bore Salvage Kit](#)
 - [\(3822385\) Cam Bore Salvage Kit](#)
 - [\(3823821\) Cam Box Dowel Extractor Set](#)
 - [\(3163015\) Cam Bushing R&I Kit](#)
 - [\(5395472\) Cam Guide Kit](#)
 - [\(5299632\) Cam Replacer](#)
 - [\(5573076\) Camshaft Bearing Mandrel Kit](#)
 - [\(2892359\) Camshaft Front Gear Removal Kit](#)
 - [\(5395442\) Camshaft Gear Remover Kit](#)
 - [\(3165045\) Camshaft Bushing Replacement Kit](#)
 - [\(5299917\) Camshaft Removal and Installation Kit](#)
 - [\(5394715\) Compression & Leakdown Test Adapter](#)
 - [\(5394350\) Compression & Leakdown Test Adapter Kit](#)
 - [\(5394639\) Compression & Leakdown Test Adapter Kit](#)
 - [\(3822764\) Connecting Rod Bolt Checking Fixture](#)
 - [\(st1186\) Connecting Rod Bushing Driver](#)
 - [\(st861\) Connecting Rod Chamfer](#)
 - [\(st561\) Connecting Rod Checking Fixture](#)
 - [\(5394619\) Connecting Rod Guide Kit](#)
 - [\(5572717\) Connecting Rod Guide Pin](#)
 - [\(5572866\) Connecting Rod Guide Pin](#)
 - [\(5572867\) Connecting Rod Guide Pin Kit](#)
 - [\(st562\) Connecting Rod Mandrel](#)
 - [\(st800\) Connecting Rod Checking Mandrel Kit](#)
 - [\(st894\) Connecting Rod Ring Gauge](#)
 - [\(3823926\) Coolant Hole Insert Fixture Kit](#)
 - [\(3824297\) Coolant Leak Test Plugs](#)
 - [\(2892436\) Counterbore Cutter Kit](#)
 - [\(3824052\) Counterbore Cutter Plate O.S. Liners](#)
 - [\(5395552\) Counterbore Cutting Improvement Kit](#)
 - [\(3376830\) Counterbore Ring Gauge](#)
 - [\(3824119\) Counterbore Salvage Kit](#)
 - [\(3824789\) Counterbore Salvage Kit](#)
 - [\(3823325\) Counterbore Tool \(Lower Press Fit Liners\)](#)
 - [\(3165127\) Cover Plate](#)
 - [\(5394694\) Crank Bore Inspection Gage](#)
 - [\(4919372\) Crankshaft Bore Centering Kit](#)
 - [\(5395072\) Crankshaft Front Oil Seal Removal & Installation Kit](#)
 - [\(5395506\) Crankshaft Front Oil Seal Removal & Installation Kit](#)
 - [\(3165049\) Crankshaft Gear Remover](#)
 - [\(3823585\) Crankshaft Gear Splitter](#)
 - [\(5395409\) Crankshaft Rear Oil Seal Carrier Centering Guide](#)
 - [\(5395259\) Crankshaft Rear Oil Seal Installation Kit](#)
 - [\(5394933\) Crankshaft Rear Oil Seal Removal & Installation Kit](#)
 - [\(5394957\) Crankshaft Rear Seal Removal & Installation Kit](#)
 - [\(5395313\) Crankshaft Seal Removal Kit](#)

- [\(5395203\) Crankshaft Seal Replacer](#)
- [\(5395204\) Crankshaft Seal Replacer](#)
- [\(5394206\) Crankshaft Seal Replacer Kit](#)
- [\(3376058\) Cup Plug Driver](#)
- [\(3376489\) Cup Plug Driver](#)
- [\(3376793\) Cup Plug Driver](#)
- [\(3822372\) Cup Plug Driver](#)
- [\(5395600\) Cylinder Block Coolant Passage Leak Test Kit](#)
- [\(5299029\) Cylinder Block Counterbore Cutting Kit](#)
- [\(5299988\) Cylinder Block Counterbore Cutting Kit](#)
- [\(3376888\) Cylinder Block Lifting Fixture](#)
- [\(5395681\) Cylinder Block Salvage Kit](#)
- [\(4918748\) Cylinder Head Cover Plate](#)
- [\(3822479\) Cylinder Head Lifting Bracket](#)
- [\(4919360\) Cylinder Head Lifting Fixture Kit](#)
- [\(3164913\) Cylinder Head Mounting Kit](#)
- [\(3375820\) Cylinder Liner Counterbore Kit](#)
- [\(3377356\) Cylinder Liner Counterbore Tool \(Upper Press Fit Liners\)](#)
- [\(3164606\) Cylinder Liner Installation Kit](#)
- [\(5299492\) Cylinder Liner Installer](#)
- [\(5395260\) Cylinder Liner Installer Kit](#)
- [\(5394978\) Cylinder Liner Removal & Installation Kit](#)
- [\(5572914\) Cylinder Liner Replacer Kit](#)
- [\(4918175\) Drill Bushing Kit](#)
- [\(3376495\) Drill/Ream Bushing Set](#)
- [\(st1232\) Drill/Ream Fixture](#)
- [\(5299073\) Engine Barring Tool](#)
- [\(3823920\) Engine Lifting Bracket](#)
- [\(st125\) Engine Lifting Fixture](#)
- [\(3162871\) Engine Lifting Fixture](#)
- [\(3163264\) Engine Lifting Fixture Kit](#)
- [\(5296516\) Engine Mounting Plate Kit](#)
- [\(3375193\) Engine Rebuild Stand](#)
- [\(3375194\) Engine Rebuild Stand](#)
- [\(5395077\) Engine Repair Stand Mounting Plate Kit](#)
- [\(3375955\) Engine Rollover Stand](#)
- [\(3375990\) Engine Rollover Stand](#)
- [\(3162425\) Engine Stand](#)
- [\(3163368\) Engine Stand Adapter Plate](#)
- [\(st163\) Engine Support](#)
- [\(5394824\) Engine Timing Kit](#)
- [\(5572725\) Engine Timing Kit](#)
- [\(5394535\) Feeler Gauge Kit](#)
- [\(3375240\) Fillet Ball Gauges](#)
- [\(3376820\) Gear Mandrel](#)
- [\(3162393\) Gear Puller Ring](#)
- [\(3162394\) Gear Puller Ring](#)
- [\(4918339\) Guide, Con Rod Checking](#)
- [\(5394867\) Guide Pin](#)
- [\(st862\) Head Lifting Fixture](#)
- [\(5573075\) Hydraulic Cylinder Kit](#)
- [\(5395577\) Hydraulic Stud Tensioner](#)
- [\(5395579\) Hydraulic Stud Tensioner Upfit Kit](#)
- [\(5395580\) Hydraulic Stud Tensioner Upfit Kit](#)
- [\(3822548\) Idler Bore Salvage Kit](#)
- [\(3823063\) Idler Bore Salvage Kit](#)
- [\(5394201\) Inspection Gauge](#)
- [\(3823466\) Intercooler/Aftercooler Lifting Bracket](#)

- [\(4918508\) Kit, Service Piston Assembly Remover](#)
- [\(5572916\) Leak Test Kit](#)
- [\(3375847\) Main Bearing Alignment Kit](#)
- [\(3375059\) Main Bearing Bore Kit](#)
- [\(st1177\) Main Bearing Bore Tool](#)
- [\(5395122\) Main Bearing Cap Replacer](#)
- [\(5572796\) Main Bearing Removal & Installation Tool](#)
- [\(3377230\) Main Bearing Thread Salvage Kit](#)
- [\(3375053\) Main Bearing Thrust Surface Cutter](#)
- [\(3162380\) Main/Cam Bearing Driver](#)
- [\(2892406\) Mounting Plate Kit](#)
- [\(3375957\) Nylon Lifting Sling](#)
- [\(3824832\) Oil Capacitor Installer](#)
- [\(5394909\) Oil Pan Removal and Installation Kit](#)
- [\(5394666\) Piston Ring Compressor](#)
- [\(5394654\) Piston Ring Compressor Kit](#)
- [\(3164402\) Piston Ring Compressor Expander](#)
- [\(5299938\) Power Cylinder Removal Kit](#)
- [\(3823893\) Power Take Off - Bearing Race Driver Kit](#)
- [\(5394242\) QSK95 Engine and Alternator Lifting Kit](#)
- [\(5394243\) QSK95 Engine Lifting Kit](#)
- [\(5394361\) QSV to QSK95 Up Fit Hydraulic Tensioner Kit](#)
- [\(3162414\) Rear Camshaft Bearing Installer](#)
- [\(5395330\) Rear Crankshaft Seal Remover](#)
- [\(3824926\) Rear Engine Power Take Off Kit](#)
- [\(4919732\) Rear Power Take-Off \(REPTO\) Flange Replacer](#)
- [\(3164761\) Rear Power Takeoff Replacer Kit](#)
- [\(4918227\) Replacer, Fuel Pump Kit](#)
- [\(5572851\) Retainer Pin](#)
- [\(3823532\) Right Angle Drill \(Heavy Duty\).](#)
- [\(3376487\) Ring Dowel Driver](#)
- [\(3165073\) Ring Dowel Installer](#)
- [\(3825185\) Rod Bend/Twist Mandrel Kit](#)
- [\(3162424\) Rotor Positioning Sling](#)
- [\(5395411\) Service Tool Component Kit](#)
- [\(5394453\) Shield Installer](#)
- [\(5394866\) Shield Installer](#)
- [\(5394769\) Short Block Lifting Kit](#)
- [\(3162404\) Special Shoulder Bolt](#)
- [\(4918572\) Tap](#)
- [\(3375623\) Tappet Guide Screw Checking Tool](#)
- [\(3375622\) Tappet Guide Screw Salvage Kit](#)
- [\(3165088\) Tappet Installation/Removal Tool](#)
- [\(3824463\) T-Handle Lifting Stud Kit](#)
- [\(3822709\) Thread Insert Kit — Blind Metric](#)
- [\(3376448\) Thread Inset Kit — Blind SAE](#)
- [\(3375021\) Thread Insert Kit SAE](#)
- [\(3164021\) Thread Salvage Kit](#)
- [\(3377208\) Thread Salvage Locating Pin](#)
- [\(3377200\) Thread Salvage Reamer Set](#)
- [\(3377256\) Thread Salvage Taps Kit — Metric](#)
- [\(5394520\) Timing Gauge](#)
- [\(3823467\) Turbocharger Lifting Bracket](#)
- [\(5394434\) Vibration Isolator Torqueing Pump Kit](#)
- [\(3823679\) Water Hole Repair Kit](#)
- [\(3824066\) Water Hole Surface Repair Kit](#)
- [Section 4 - Level 3 - Group 2 - Cylinder Head Group](#)
 - [\(5395060\) 200 - 1000 ft-lb Torque Wrench](#)

- [\(3163606\) 4-Valve Spring Compressor Base Kit](#)
- [\(st1016\) Adapter Plate Clamp](#)
- [\(st826\) Bead Cutter Pilot](#)
- [\(st788\) Bead Cutting Tool](#)
- [\(3163293\) Boot Pliers](#)
- [\(5299837\) Camshaft Removal and Installation Kit](#)
- [\(5395513\) Camshaft Removal & Installation Kit](#)
- [\(5572844\) Camshaft Timing Pin](#)
- [\(3375432\) Crack Detection Kit](#)
- [\(3163430\) Crosshead Guide Installer](#)
- [\(3164373\) Crosshead Guide Installer](#)
- [\(3377149\) Crosshead Guide Reamer](#)
- [\(st633\) Crosshead Guide Spacer](#)
- [\(3376058\) Cup Plug Driver](#)
- [\(3376489\) Cup Plug Driver](#)
- [\(3376793\) Cup Plug Driver](#)
- [\(3822372\) Cup Plug Driver](#)
- [\(3823546\) Cylinder Head Capscrew Length Gauge](#)
- [\(3823861\) Cylinder Head Capscrew Template](#)
- [\(3164917\) Cylinder Head Coolant Test Kit](#)
- [\(3164943\) Cylinder Head Fuel Passage Leak Test Kit](#)
- [\(3165071\) Cylinder Head Inspection Gauge](#)
- [\(3164341\) Cylinder Head Leak Test Kit](#)
- [\(3824079\) Cylinder Head Leak Test Kit](#)
- [\(4919633\) Cylinder Head Leak Test Kit](#)
- [\(5394450\) Cylinder Head Lifter](#)
- [\(3164394\) Cylinder Head Lifting Fixture](#)
- [\(5394205\) Cylinder Head Lifting Kit](#)
- [\(5394494\) Cylinder Head Lifting Kit](#)
- [\(3376082\) Cylinder Head Water Test Kit](#)
- [\(3823895\) Die Grinder](#)
- [\(3163720\) Dowel Pin Puller](#)
- [\(5572701\) Exhaust Gas Temperature Sensor Socket](#)
- [\(3163319\) Exhaust Valve Seat Driver](#)
- [\(st969\) Expansion Plug Driver](#)
- [\(st1053\) Expansion Plug Driver](#)
- [\(3376792\) Expansion Plug Driver](#)
- [\(4919358\) Four Valve Spring Compressor Kit](#)
- [\(5394735\) Fuel Injector Sleeve Ring Installer](#)
- [\(st876\) Fuel Passage Cleaning Brush](#)
- [\(3164462\) Gauge, Valve Stem Seal Depth](#)
- [\(st1100\) Grooving Tool](#)
- [\(5572840\) Handle Assist Tool](#)
- [\(5299918\) Head Coolant and Valve Leak Test Kit](#)
- [\(st583\) Head Holding Fixture](#)
- [\(5299937\) Head Nut Socket](#)
- [\(5394979\) Head Stud Length Gauge](#)
- [\(5299846\) Head Stud Socket](#)
- [\(5395577\) Hydraulic Stud Tensioner](#)
- [\(3164395\) Hydraulic Stud Tensioning Kit](#)
- [\(5395579\) Hydraulic Stud Tensioner Upfit Kit](#)
- [\(5395580\) Hydraulic Stud Tensioner Upfit Kit](#)
- [\(st1012\) Hydrostatic Tester](#)
- [\(3824531\) Injector Bore Facing Tool](#)
- [\(5395114\) Injector Clamp Chamfering Tool Kit](#)
- [\(st981\) Injector Protrusion Comparator](#)
- [\(st379\) Injector Seat Cutter](#)
- [\(st1227\) Injector Sleeve Driver](#)

- [\(st880\) Injector Sleeve Expander](#)
- [\(st918\) Injector Sleeve Expander](#)
- [\(st922\) Injector Sleeve Expander](#)
- [\(3375425\) Injector Sleeve Extractor](#)
- [\(st1179\) Injector Sleeve Holding Tool](#)
- [\(st1245\) Injector Sleeve Puller](#)
- [\(3377079\) Injector Sleeve Puller](#)
- [\(3163523\) Injector Sleeve Remover](#)
- [\(4919002\) Inspection Gauge](#)
- [\(5394622\) Inspection Gauge](#)
- [\(4918258\) Installer, Valve Guide](#)
- [\(4918644\) Installer, Valve Stem Seal](#)
- [\(3163318\) Intake Valve Seat Driver](#)
- [\(5298979\) Overhead Adjustment Kit](#)
- [\(5395099\) Prechamber Reconditioning Kit](#)
- [\(3162458\) Rocker Bushing R&I Tool](#)
- [\(st691\) Rocker Lever Block & Mandrel Set](#)
- [\(st1284\) Rocker Lever Bushing Mandrel](#)
- [\(3163362\) Rocker Lever Bushing R&I Tool](#)
- [\(5573072\) Socket](#)
- [\(5299100\) Socket Assembly](#)
- [\(st1142\) Spark Plug Sleeve Seat Facer](#)
- [\(5572828\) Spark Plug Socket](#)
- [\(5395648\) Torque Adapter](#)
- [\(3164682\) Turbo Leak Test Kit](#)
- [\(3376256\) Valve Facing Machine](#)
- [\(st1211\) Valve Guide Driver](#)
- [\(3376061\) Valve Guide Drivers/Remover](#)
- [\(3163499\) Valve Guide Drop Gauge](#)
- [\(5299893\) Valve Guide Drop Gauge](#)
- [\(3162413\) Valve Guide Installer](#)
- [\(3163100\) Valve Guide Installer](#)
- [\(3162407\) Valve Guide Pilot](#)
- [\(3162416\) Valve Guide Pilot](#)
- [\(3376463\) Valve Guide Reamer - Oversize](#)
- [\(3162406\) Valve Guide Remover](#)
- [\(3163321\) Valve Guide Remover](#)
- [\(3164414\) Valve Guide Remover](#)
- [\(3824919\) Valve Guide Remover](#)
- [\(3164427\) Valve Guide Replacer](#)
- [\(st873\) Valve Guide Seal Installer](#)
- [\(3823946\) Valve Guide Seal Installer](#)
- [\(3163399\) Valve Guide/Seal R&I Tool](#)
- [\(3375938\) Valve Head Checking Tool](#)
- [\(3164984\) Valve Head Thickness Gauge](#)
- [\(5299451\) Valve Insert and Guide Installer](#)
- [\(3163294\) Valve Seal Installer](#)
- [\(3164790\) Valve Seat Adapter Installer](#)
- [\(3162385\) Valve Seat Cutter Kit](#)
- [\(3162373\) Valve Seat Driver](#)
- [\(3376617\) Valve Seat Extractors](#)
- [\(st685\) Valve Seat Grinding Machine](#)
- [\(3376405\) Valve Seat Grooving Tool](#)
- [\(3823031\) Valve Seat Insert Tool](#)
- [\(3164791\) Valve Seat Installer](#)
- [\(3165171\) Valve Seat Installer](#)
- [\(3164426\) Valve Seat Installer Kit](#)
- [\(3164412\) Valve Seat Remover](#)

- [\(3164413\) Valve Seat Remover](#)
- [\(5395059\) Valve Seat Remover](#)
- [\(st1122\) Valve Seat Staking Driver](#)
- [\(st1123\) Valve Seat Staking Tool](#)
- [\(3163292\) Valve Spring Compressor](#)
- [\(3375269\) Valve Spring Compressor](#)
- [\(5395188\) Valve Spring Compressor](#)
- [\(5299859\) Valve Spring Compressor](#)
- [\(5395402\) Valve Spring Compressor](#)
- [\(3162369\) Valve Spring Compressor Adapter](#)
- [\(2892408\) Valve Spring Compressor Kit](#)
- [\(3164329\) Valve Spring Compressor Kit](#)
- [\(3825105\) Valve Spring Compressor Kit](#)
- [\(5299565\) Valve Spring Compressor Kit](#)
- [\(st1026\) Valve Spring Compressor Plate](#)
- [\(st1022\) Valve Spring Compressor Stand](#)
- [\(5298830\) Valve Stem Inspection Gauge Kit](#)
- [\(3163937\) Valve Stem Seal Installer](#)
- [\(3164055\) Valve Stem Seal Installer](#)
- [\(3164430\) Valve Stem Seal Installer](#)
- [\(4919793\) Valve Stem Seal Installer](#)
- [\(5296545\) Valve Stem Seal Installer](#)
- [\(3824278\) Valve Vacuum Tester- 220 vac, 50/60 hz.](#)
- [\(3824277\) Valve Vacuum Tester-115 vac, 50/60 hz.](#)
- [\(st1013\) Water Test Plates](#)
- [Section 5 - Level 3 - Group 3 - Cam Followers/Tappets Group](#)
 - [\(st249\) Cam Follower Mandrel /Block](#)
 - [\(3823592\) Cam Follower Pin Driver](#)
 - [\(st195\) Cam Follower Plug Gauge](#)
 - [\(3376966\) Cam Follower Rebuild Fixture](#)
 - [\(5394821\) Engine Brake Lash Setting Tool](#)
 - [\(st970\) Expansion Plug Driver](#)
 - [\(st1053\) Expansion Plug Driver](#)
 - [\(st1198\) Tappet Roller Pin Fixture](#)
 - [\(3375315\) Tappet Sleeve Tool](#)
- [Section 6 - Level 3 - Group 4 - Fuel Pump Group](#)
 - [\(5394500\) Adapter, Tester](#)
 - [\(3375599\) AFC Barrel Puller](#)
 - [\(3822378\) AFC Barrel/Plunger Leakage Tester](#)
 - [\(3822611\) AFC Barrel/Plunger Tester 2 Spring](#)
 - [\(3375498\) AFC Breather Drill Fixture](#)
 - [\(3375934\) ASA/AFC Aneroid Test Stand](#)
 - [\(st302\) Ball Joint Vise](#)
 - [\(5394202\) Banjo Connector Screw](#)
 - [\(3162379\) Delivery Valve Test Fixture](#)
 - [\(3824045\) Dual Spring Height Gauge](#)
 - [\(3377443\) Filter Head Adapter Socket](#)
 - [\(5395006\) Filter Wrench](#)
 - [\(3822472\) Front Cover and Main Shaft Assembly Tool Kit](#)
 - [\(3375014\) Fuel Filter Adapter](#)
 - [\(3824875\) Fuel Pump Adapter](#)
 - [\(3163313\) Fuel Pump Adapter Wrench](#)
 - [\(3823114\) Fuel Pump AFC Adjusting Kit](#)
 - [\(5572583\) Fuel Pump Alignment Kit](#)
 - [\(3163281\) Fuel Pump Alignment Tool](#)
 - [\(5394982\) Fuel Pump & Actuator Lingage Adjustment Gauge](#)
 - [\(3376919\) Fuel Pump Bushing Driver](#)
 - [\(5299776\) Fuel Pump Clean Care Kit](#)

- [\(st1175\) Fuel Pump Countersink Drill](#)
- [\(3163381\) Fuel Pump Gear Puller](#)
- [\(4919304\) Fuel Pump Gear Remover Kit](#)
- [\(5299760\) Fuel Pump Gear Removal Tool](#)
- [\(3164707\) Fuel Pump Gear Replacer](#)
- [\(4918677\) Fuel Pump Gear Replacer](#)
- [\(4919586\) Fuel Pump Gear Replacer Kit](#)
- [\(4919703\) Fuel Pump Gear Replacer Kit](#)
- [\(3162887\) Fuel Pump Idle Adjust Tool](#)
- [\(5299015\) Fuel Pump Lifting Fixture Kit](#)
- [\(5573078\) Fuel Pump Lifting Kit](#)
- [\(3823956\) Fuel Pump Mounting Kit](#)
- [\(3162897\) Fuel Pump Mounting Plate](#)
- [\(3375133\) Fuel Pump Mounting Plate](#)
- [\(4918270\) Fuel Pump Mounting Support Socket](#)
- [\(5299014\) Fuel Pump Removal & Installation Kit Update Kit](#)
- [\(3823755\) Fuel Pump Seal Driver Kit](#)
- [\(3376874\) Fuel Pump Support Bushing Driver](#)
- [\(3376875\) Fuel Pump Support Bushing Driver](#)
- [\(5394259\) Fuel Pump Tester](#)
- [\(5299721\) Fuel Pump Test Kit](#)
- [\(5299726\) Fuel Pump Test Kit](#)
- [\(5394204\) Fuel Pump Test Kit](#)
- [\(4918193\) Fuel Pump Timing Kit](#)
- [\(3163611\) Fuel Pump Timing Tool](#)
- [\(5572664\) Fuel Pump Timing Tool](#)
- [\(3376929\) Fuel Pump Tool \(Misc\)](#)
- [\(3822640\) Fuel Pump Valve Driver](#)
- [\(5299979\) Fuel Pump Vise Mounting Kit](#)
- [\(3164383\) Fuel Sight Glass](#)
- [\(3165147\) Fuel Sight Glass Assembly](#)
- [\(5394203\) Fuel System Cleaner used on Fuel Metering Valve](#)
- [\(5394515\) Fuel System Leak Test](#)
- [\(3376330\) Gear Pump Flow Adapter](#)
- [\(st844\) Gear Pump Test Plate](#)
- [\(4919654\) Gear Replacer](#)
- [\(3376136\) Governor Barrel Lock Clip Driver](#)
- [\(3822724\) Governor Carrier Weight Installation and Removal Tool](#)
- [\(3376457\) Governor Plug Removal Tool](#)
- [\(st709\) Governor Weight Puller](#)
- [\(3375230\) Governor Weight Tool](#)
- [\(st434-1\) Hose Adapter Assembly](#)
- [\(3162853\) Injection Timing Kit](#)
- [\(3824077\) LDA Pretension Checking Kit](#)
- [\(5394499\) Kit, Fuel System Leak Test](#)
- [\(st835\) O'ring Assembly Tool](#)
- [\(3375703\) Piston Installation Sleeve](#)
- [\(3824780\) Plunger Retainer Expander](#)
- [\(5394873\) Pressure Gauge Adapter](#)
- [\(st589\) PTR Gauge Fixture](#)
- [\(3376903\) Ream Fixture](#)
- [\(5395471\) Sight Gauge Assembly](#)
- [\(5395503\) Sight Gauge Assembly](#)
- [\(5395504\) Sight Gauge Assembly](#)
- [\(5395505\) Sight Gauge Assembly](#)
- [\(5395566\) Sight Gauge Assembly](#)
- [\(5395567\) Sight Gauge Assembly](#)
- [\(5395568\) Sight Gauge Assembly](#)

- [\(4918317\) Spacer](#)
- [\(3375271\) Tach Drive Cup Plug Driver](#)
- [\(st1326\) Tachometer Drive Puller](#)
- [\(st1032\) Tachometer Seal Driver](#)
- [\(3375204\) Throttle Shaft Ball Tool](#)
- [\(3823844\) Torque Spring Height Gauge](#)
- [\(5395651\) Utility Cart](#)
- [\(st1241\) Weight Assist Checking Tool](#)
- [Section 7 - Level 3 - Group 5 - Injector Group](#)
 - [\(st718\) Ball Seating Tool](#)
 - [\(3376946\) Injection Nozzle Tester](#)
 - [\(st1298\) Injector Assembly Stand](#)
 - [\(3375084\) Injector Assembly Stand](#)
 - [\(st955\) Injector Ball Seat Cutter](#)
 - [\(3376297\) Injector Barrel Tester](#)
 - [\(3376350\) Injector Cup Spray Tester](#)
 - [\(3822298\) Injector Cup Wrench](#)
 - [\(3163438\) Injector Diagnostic Adapter](#)
 - [\(3164001\) Injector Leak Test Kit](#)
 - [\(3375375\) Injector Leakage Tester](#)
 - [\(3376887\) Injector Locknut Spanner](#)
 - [\(3376947\) Injector Nozzle Cleaning Kit](#)
 - [\(3164392\) Injector Nozzle Tester](#)
 - [\(3376177\) Injector Orifice Torque Wrench](#)
 - [\(3375209\) Injector Plunger Checking Tool](#)
 - [\(3162269\) Injector Test Fixture](#)
 - [\(3375317\) Injector Test Stand](#)
 - [\(st933\) Injector Wrench](#)
 - [\(st1262\) Master Injector](#)
 - [\(st426\) O'ring Assembly Tool](#)
 - [\(3163683\) STC Valve Test Kit](#)
 - [\(3822732\) Top Stop Setting Fixture](#)
 - [\(3375001\) Ultrasonic Cleaner](#)
 - [\(3376665\) Ultrasonic Cleaner](#)
 - [\(5298633\) Ultrasonic Cleaner Fluid](#)
- [Section 8 - Level 3 - Group 6 - Lubricating System Group](#)
 - [\(st994\) Bushing Mandrel](#)
 - [\(st1158\) Bushing Mandrel](#)
 - [\(5299761\) Connector Remover](#)
 - [\(3376011\) DFC Pressure Valve Fixture](#)
 - [\(3823875\) Dipstick Tube Installer](#)
 - [\(st1115\) Disassembly Fixture](#)
 - [\(4919518\) Filter Head Adapter Remover](#)
 - [\(3165074\) Filter Head Adapter Replacer Kit](#)
 - [\(3377443\) Filter Head Adapter Socket](#)
 - [\(st722\) Gear Mandrel](#)
 - [\(3377255\) Gear Mandrel](#)
 - [\(st1157\) Gear Spacer Mandrel](#)
 - [\(st1218\) Lube Cooler O'ring Mandrel](#)
 - [\(st1135\) Lube Oil Sampling Filter](#)
 - [\(3375082\) Lube Pump Gear Puller](#)
 - [\(4918200\) Lubricating Oil Cooler Test Kit](#)
 - [\(3823106\) Lubricating Pump Update Kit](#)
 - [\(3375253\) Oil Cooler Bundle Tester](#)
 - [\(3375859\) Oil Cooler Bundle Tester](#)
 - [\(3376765\) Oil Cooler Bundle Tester](#)
 - [\(3376861\) Oil Cooler Bundle Tester](#)
 - [\(4919867\) Oil Cooler Leak Test Kit](#)

- [\(5572847\) Oil Cooler Leak Test Kit](#)
- [\(5394819\) Oil Cooler Leak Test & Oil Filter Differential Pressure Test Kit](#)
- [\(5299851\) Oil Cooler Support Leak Test Kit](#)
- [\(534442\) Oil Filter Wrench](#)
- [\(5299094\) Oil Pan Seal Protector](#)
- [\(5572592\) Oil Pump Pressure Regulator Replacer](#)
- [\(5299913\) Oil Sample Hose](#)
- [\(3376844\) O'ring Expander](#)
- [\(55299761\) STC Connector Disconnect Tool](#)
- [Section 9 - Level 3 - Group 7 - Cooling System Group](#)
 - [\(5394287\) Aftercooler Leak Test Kit](#)
 - [\(st1114\) Bearing Disassembly Tool](#)
 - [\(3375695\) Bearing Driver](#)
 - [\(3375696\) Bearing Driver](#)
 - [\(3375693\) Bearing Race Driver](#)
 - [\(3375694\) Bearing Race Driver](#)
 - [\(3375704\) Bearing Race Driver](#)
 - [\(3375771\) Bearing/Snap Ring Installer](#)
 - [\(st659\) Carbon Seal Driver](#)
 - [\(5394833\) Coolant Manifold Tube Removal and Installation Tool](#)
 - [\(5298619\) Coolant System Test Kit](#)
 - [\(3376819\) Cup Plug Driver](#)
 - [\(3376788\) Fan Hub Bearing Driver](#)
 - [\(3376787\) Fan Hub Bearing/Seal Driver](#)
 - [\(3823378\) Fan Hub Rebuild Kit](#)
 - [\(5394722\) Fuel System Tester](#)
 - [\(5394887\) Heat Exchanger Service Kit](#)
 - [\(3375110\) Impeller Puller](#)
 - [\(5394751\) Leak Test Kit](#)
 - [\(5395562\) Oil Cooler Leak Test Kit](#)
 - [\(3376386\) Oil Seal Expander](#)
 - [\(3375692\) Oil Seal Mandrel](#)
 - [\(3375769\) Oil Seal/Bushing Mandrel](#)
 - [\(3375321\) Retaining Ring Expander](#)
 - [\(3375705\) Spring Compressor Plate](#)
 - [\(3377414\) Thermostat Check Valve Driver](#)
 - [\(3823082\) Thermostat Housing Drill Fixture-Vent Hole](#)
 - [\(5572670\) Thermostat Seal Installer](#)
 - [\(st657\) Water Pump Bearing Mandrel](#)
 - [\(st658\) Water Pump Bearing Mandrel](#)
 - [\(3375318\) Water Pump Bearing Mandrel](#)
 - [\(3376081\) Water Pump Bearing Mandrel](#)
 - [\(3375772\) Water Pump Bearing Race Mandrel](#)
 - [\(3375326\) Water Pump Bearing Separator](#)
 - [\(st1314\) Water Pump Bushing Mandrel](#)
 - [\(3823851\) Water Pump Drive Gear Tool](#)
 - [\(3376384\) Water Pump Gear Mandrel](#)
 - [\(3375257\) Water Pump Impeller Puller](#)
 - [\(3165124\) Water Pump Impeller Replacer](#)
 - [\(st1191\) Water Pump Oil Seal Driver](#)
 - [\(st1219\) Water Pump Oil Seal Driver](#)
 - [\(st1220\) Water Pump Oil Seal Driver](#)
 - [\(3376387\) Water Pump Oil Seal Expander](#)
 - [\(3376139\) Water Pump Oil Seal Mandrel](#)
 - [\(3823288\) Water Pump Pulley Puller](#)
 - [\(3823040\) Water Pump Pulley/Impeller Puller](#)
 - [\(3165055\) Water Pump Rebuild Fixture](#)
 - [\(3375707\) Water Pump Seal Assembly Tool](#)

- [\(st1159\) Water Pump Seal Driver](#)
- [\(st1161\) Water Pump Seal Driver](#)
- [\(3377269\) Water Pump Seal Driver](#)
- [\(3823815\) Water Pump Seal Driver](#)
- [\(3824836\) Water Pump Seal Driver](#)
- [\(3375768\) Water Pump Seal Expander](#)
- [\(3377147\) Water Pump Seal Expander](#)
- [\(3375319\) Water Pump Seal Mandrel](#)
- [\(3375320\) Water Pump Seal Mandrel](#)
- [\(3823885\) Water Pump Seal Pilot](#)
- [\(5298838\) Water Pump Seal Replacer Kit](#)
- [\(3375770\) Wear Sleeve Driver](#)
- [Section 10 - Level 3 - Group 8 - Air Intake Systems Group](#)
 - [\(4919573\) Aftertreatment Diesel Exhaust Fluid \(DEF\) Doser Shutoff Valve Test Kit](#)
 - [\(3165100\) Air Compressor Adapter Replacer](#)
 - [\(st1105\) Air Compressor Bushing Mandrel](#)
 - [\(st1143\) Air Compressor Bushing Mandrel](#)
 - [\(2892280\) Air Compressor Cleaning Kit](#)
 - [\(3822761\) Air Compressor Exhaust Seat Puller Kit](#)
 - [\(3823596\) Air Compressor Mounting Plate](#)
 - [\(3377415\) Air Compressor Seat Driver](#)
 - [\(3377416\) Air Compressor Seat Driver](#)
 - [\(3824736\) Air Compressor Shaft Nut Removal Bar](#)
 - [\(5296553\) Air Handling System Clean Care Kit](#)
 - [\(4919085\) Charge Air Cooler Leak Test Kit](#)
 - [\(5298868\) Diesel Exhaust Fluid Doser Cleaner Kit Extension Cable](#)
 - [\(5298935\) Diesel Exhaust Fluid Test Kit](#)
 - [\(5296510\) Doser Pump Cleaner Kit](#)
 - [\(3376144\) Exhaust Brake Bushing Driver](#)
 - [\(3376473\) Exhaust Brake Bushing Puller](#)
 - [\(5395386\) Fuel Distributor Sleeve Remover Kit](#)
 - [\(5572854\) Grommet Installer](#)
 - [\(5394385\) HE900 Turbocharger Leak Test Kit](#)
 - [\(5394443\) Hole Punch](#)
 - [\(4918515\) Kit, Turbocharger Coolant Leak Test](#)
 - [\(5299997\) Sensor Socket](#)
 - [\(5394620\) Torque Adapter](#)
 - [\(5394680\) Turbo Support Leak Test Kit](#)
 - [\(4919281\) Turbocharger Actuator Inspection Gauge Kit](#)
 - [\(st750\) Turbocharger Mounting Plate](#)
 - [\(3375533\) Turbocharger Rebuild Kit](#)
 - [\(3375543\) Turbocharger Rebuild Kit](#)
 - [\(st1095\) Turbocharger Rotor Socket](#)
 - [\(3376417\) Turbocharger Seal Ring Tools](#)
 - [\(st608\) Turbocharger Support Block](#)
 - [\(st544\) Valve Seat Puller](#)
- [Section 11 - Alternative Repair Parts Group](#)
 - [\(3376235\) Camshaft Bore Repair Sleeves](#)
 - [\(5394469\) Doser Pump Flexible Hose](#)
 - [\(3376959\) Idler Bore Repair Bushing/Tooling](#)
 - [\(4918151\) Idler Bore Repair Inserts](#)
 - [\(5395695\) Inspection Gauge](#)
 - [\(3375304\) Lower Bore Repair Bushing/Tooling](#)
 - [\(3375168\) Main Bearing Saddle Inserts](#)
 - [\(3376390\) Oil Gallery Sleeve](#)
 - [\(3375202\) Reamer](#)
 - [\(3822709\) Thread Repair Inserts](#)
 - [\(3822959\) Upper Deck Repair Bushings/Tooling](#)

- [\(3823680\) Water Hole Repair Inserts/Tooling](#)
- [Section 12 - Consumables Group](#)
 - [\(3823258\) Abrasive Hand Pad](#)
 - [\(3824397\) Anti-Seize Compound \(4 oz. plastic bottle\)](#)
 - [\(3824759\) Anti-Seize Compound \(1 lb.can\)](#)
 - [\(3824732\) Anti-Seize Lubricant \(4 oz. tube\)](#)
 - [\(3824879\) Anti-Seize Lubricant \(8 oz. plastic bottle\)](#)
 - [\(3824541\) Cleaning Disc \(2 in.\)](#)
 - [\(3822985\) Combustion Leak Test Kit](#)
 - [\(5394354\) Contact Cleaner](#)
 - [\(5394479\) Copper Flange Sealant](#)
 - [\(3375432\) Crack Detection Kit](#)
 - [\(3164956\) Dielectric Grease](#)
 - [\(3824538\) Disc Back Up Pad \(2 in.\)](#)
 - [\(4918818\) Electrical Connector Screw Repair Kit](#)
 - [\(3824785\) Electrical Connector Sealant](#)
 - [\(3376891\) Fluorescent Tracer](#)
 - [\(3165150\) Gasket Sealant](#)
 - [\(4918771\) Gasket Sealant](#)
 - [\(5394477\) Gasket Sealant](#)
 - [\(5394478\) Gasket Sealant](#)
 - [\(5394474\) Gray RTV Sealant](#)
 - [\(4918684\) Kit, Cylinder Head Repair](#)
 - [\(3822934\) Lithium Grease \(1.5 oz. tube\)](#)
 - [\(3824715\) Locquic T Primer](#)
 - [\(3163086\) Lubricant](#)
 - [\(5394473\) Lubricant, Penetrant](#)
 - [\(4918318\) Lubricant, Rubber Emulsion](#)
 - [\(msds\) MSDS Information](#)
 - [\(5299995\) Metal Free Anti-Seize Lubricant](#)
 - [\(3824515\) Paint Genuine Cummins Certified Colors](#)
 - [\(3824771\) Penetration Oil \(11 oz. aerosol\)](#)
 - [\(3822735\) Plastic Abrasive Media](#)
 - [\(3885823\) Premium Plus Flush Kit](#)
 - [\(3824510\) QD Contact Cleaner \(16 oz. aerosol\)](#)
 - [\(5394883\) UltraTraceUV® Leak Test Solution](#)
 - [\(5394644\) Retaining Compund](#)
 - [\(3824878\) Rubber Lubricant Emulsion](#)
 - [\(3164070\) Sealant](#)
 - [\(5394294\) Sealant](#)
 - [\(5394645\) Sealant](#)
 - [\(5394921\) Silicone-Based Lubricant](#)
 - [\(5394646\) Silicone Gasket Maker](#)
 - [\(3164067\) Silicone Sealant \(70ml\)](#)
 - [\(3823718\) Sleeve Retaining Compound \(10 ml bottle\)](#)
 - [\(3824421\) Solvent Cleaner \(1/2 Gallon\) \(Break-Away\)](#)
 - [\(5394468\) Spray Assembly Lubricant](#)
 - [\(3375066\) Thread Sealant \(1.69 oz. tube\)](#)
 - [\(5394371\) Thread Sealant](#)
 - [\(5394475\) Threadlocker](#)
 - [\(5394476\) Threadlocker](#)
 - [\(3824040\) Threadlocker \(Blue\) \(50 ml bottle\)](#)
 - [\(3375068\) Threadlocker-\(Red\) \(50 ml bottle\)](#)
 - [\(5395064\) Ultrasonic Cleaner Fluid](#)
- [Section 13 - Electronic Tooling](#)
 - [\(3165176\) Actuator Harness Repair Kit](#)
 - [\(5394596\) Adapter Harness](#)
 - [\(5394621\) Adapter Harness](#)

- [\(3164489\) Automotive Meter](#)
- [\(3163064\) Bench Calibration Harness](#)
- [\(5394436\) Bench Calibration Harness](#)
- [\(5572656\) Bench Calibration Harness](#)
- [\(3163151\) Bench Calibration Parent Cable](#)
- [\(3163150\) Brake Breakout Cable Kit](#)
- [\(5394709\) Circuit Load Test Leads](#)
- [\(3164490\) Clamp On Current Probe](#)
- [\(3164708\) Connector, Electrical Repair](#)
- [\(4918815\) Connector Jack Screw](#)
- [\(3163156\) Data Link Cable](#)
- [\(5394428\) Datalink Cable - OBDII \(16 PIN\) to Inline Adapter \(25 PIN\)](#)
- [\(2892512\) Delphi™ 96 Way Connector Repair Tool Kit](#)
- [\(3163156\) Data Link Cable](#)
- [\(3164721\) “INPOWER” Data Link Cable](#)
- [\(3163677\) On Engine Datalink Cable](#)
- [\(3164848\) Data Recorder Kit](#)
- [\(5298533\) Diesel Exhaust Fluid Doser Cleaner](#)
- [\(3163909\) Electrical Cable](#)
- [\(5298765\) Electrical Cable](#)
- [\(3163768\) Power Gen Electrical Cable](#)
- [\(3163878\) Electrical Circuit Tester Kit](#)
- [\(3163908\) Electrical Connector](#)
- [\(2892089\) Electrical Power Supply Kit](#)
- [\(3163610\) Electrical Repair Connector](#)
- [\(4918674\) Electrical Repair Connector](#)
- [\(4918722\) Electrical Terminal Crimper](#)
- [\(3164752\) Harness, Electrical Wiring](#)
- [\(3164653\) Electrical Wiring Harness Adapter](#)
- [\(3163890\) Engine Controller](#)
- [\(3163834\) Fuel Pump Diagnostic Tool](#)
- [\(3163531\) Fuel Shutoff Valve Breakout Cable](#)
- [\(3165125\) Fuse](#)
- [\(3164487\) Infrared Thermometer](#)
- [\(3164980\) Inspection Gauge](#)
- [\(3164491\) Pressure/Vacuum Adapter](#)
- [\(5394530\) ROM Boot Bench Calibration Cable](#)
- [\(3162898\) Sensor Breakout Cable](#)
- [\(5563489\) Software Download Tool Kit](#)
- [\(3164499\) Temperature Adapter](#)
- [\(3823967\) Thermocouple Extension Wire Set](#)
- [\(3822988\) Thermocouple Wire Extension Kit](#)
- [\(3824892\) Throttle Breakout Cable](#)
- [\(5394862\) USB Extension Cable](#)
- [\(4918779\) Valve Guide Inspection Gauge](#)
- [\(3400045\) Wire Stripping Tool](#)
- [\(3164584\) Wiring Interface Kit- OEM](#)
- [\(3824904\) Wiring Repair Kit — Master](#)
- [\(3162899\) Wiring Repair Kit — Various](#)
- [Section 14 - Miscellaneous](#)
 - [\(3162388\) AC Volt Tester](#)
 - [\(3164211\) Adapter](#)
 - [\(3824313\) Adapter](#)
 - [\(3824314\) Adapter](#)
 - [\(3824315\) Adapter](#)
 - [\(3824316\) Adapter](#)
 - [\(3824317\) Adapter](#)
 - [\(3824318\) Adapter](#)

- [\(3824430\) Adapter](#)
- [\(5299969\) Aftertreatment Bellows Alignment Kit](#)
- [\(3162377\) Black Lead Assembly](#)
- [\(3162370\) Brush Seating Stone](#)
- [\(3162371\) Commutator Stone](#)
- [\(3824319\) Coolant Dam/Pressure Tester](#)
- [\(3823978\) Dynamometer Room Charge Air Cooler](#)
- [\(5299367\) Electrical Test Lead Kit](#)
- [\(5572582\) Engine Support Bracket Locating Pin](#)
- [\(3377243\) Miscellaneous Engine Fittings](#)
- [\(5394387\) Engine Mounting Isolator Measurement Gauge](#)
- [\(3162419\) Portable Exhaust Analyzer](#)
- [\(5394460\) Exhaust manifold seal installer](#)
- [\(3163154\) Exhaust Probe](#)
- [\(3376317\) Fuel/Lube Oil Blenders](#)
- [\(4918219\) Gauge, Straight Edge](#)
- [\(5395689\) General Purpose Indicator Kit](#)
- [\(5394353\) Guide Pin Kit](#)
- [\(3162415\) Headless Bolt](#)
- [\(5394396\) Hitzinger Alternator Chain Guard Replacer](#)
- [\(5394392\) Hitzinger Alternator Check End Play/Shipping Brace](#)
- [\(3375783\) 10 Ton Hydraulic Puller](#)
- [\(5394240\) Inspection Shim](#)
- [\(5394220\) Isolator Torque Kit](#)
- [\(5395611\) Leak Test Dye Additive](#)
- [\(5394727\) Leak Test Machine](#)
- [\(5395356\) Lubricant](#)
- [\(3162418\) Microlite Flywheel Puller](#)
- [\(5395574\) Nox Sensor Cup Drill Bushing Kit](#)
- [\(3165089\) Oil Pan Adapter Kit](#)
- [\(3822904\) Oil Pan Adapter Kit](#)
- [\(4918864\) Oil Pressure/Temperature Sensor Adapter](#)
- [\(3885812\) PC Shop Cabinet — Mobile](#)
- [\(st1322\) Phase Sequence Indicator](#)
- [\(3822206\) Pin/Socket Extraction Tool](#)
- [\(4918319\) Plug, Protective Service Kit](#)
- [\(5394252\) Protective Cover](#)
- [\(3375779\) Puller Kits, Medium Duty](#)
- [\(3375784\) Puller Set, Light Duty](#)
- [\(3824311\) Radiator Cap Adapter](#)
- [\(3162376\) Red Lead Assembly](#)
- [\(3824294\) Rubber Expansion Plugs](#)
- [\(5572609\) Rubber Hardness Tester](#)
- [\(5395029\) Safety Switch Adapter](#)
- [\(5394758\) Sensor Socket](#)
- [\(5394916\) Sealant](#)
- [\(5572580\) Stud Remover and Installer](#)
- [\(3164078\) Temperature Monitor Label Kit](#)
- [\(5572606\) Torque Adapter](#)
- [\(5572825\) Torque Adapter](#)
- [\(3376613\) Trim Pot Screwdriver](#)
- [Obsolete Tools](#)
 - [\(5394772\) Aftertreatment Installation Kit](#)
 - [\(st695\) Air Compressor Bushing Mandrel](#)
 - [\(3822652\) Audit Kit, Injector Test Stand](#)
 - [\(3824591\) Barring Tool](#)
 - [\(3376135\) Burnishing Tool](#)
 - [\(3163400\) Bushing R&I Tool](#)

- [\(3375364\) Calibration Fluid](#)
- [\(3376748\) Cam Follower Plug Gauge](#)
- [\(5394572\) Cam Guide](#)
- [\(3164610\) Camshaft Remover and Installation Kit](#)
- [\(st318\) Chamfer Tool](#)
- [\(3824340\) Clutch Caddy](#)
- [\(st842\) Crankshaft Flange Adapter Puller](#)
- [\(3376810\) Cylinder Head Water Test Kit](#)
- [\(3377376\) Cylinder Head Water Test Kit](#)
- [\(3377378\) Cylinder Head Water Test Kit](#)
- [\(3377381\) Cylinder Head Water Test Kit](#)
- [\(3377383\) Cylinder Head Water Test Kit](#)
- [\(3824223\) Differential Pressure Tester](#)
- [\(3163594\) Electrical Circuit Tester](#)
- [\(3163091\) Engine Lifting Hook](#)
- [\(5299152\) Engine Rebuild Stand Adapter Plate Kit](#)
- [\(5394492\) Fuel Pump Lifting Fixture](#)
- [\(3375698\) Fuel Pump Test Stand](#)
- [\(3823490\) Fuel Pump Wrench AFC](#)
- [\(5394230\) Fuel System Clean Care Kit](#)
- [\(3822527\) Gear Housing Spotface Kit](#)
- [\(st1160\) Hose Assembly Tools](#)
- [\(3162248\) Hydraulic Cam Busing Tool Kit](#)
- [\(3824880\) Idler Bore Salvage Ki](#)
- [\(3376951\) Idler Shaft Bore Salvage Kit-\(K38 & K50\)](#)
- [\(3375805\) Lapping Paste](#)
- [\(3822290\) Lube Pump Salvage Kit](#)
- [\(3822291\) Lube Pump Salvage Kit](#)
- [\(3823101\) Lube Pump Salvage Kit](#)
- [\(3823102\) Lubricating Pump Bushing Replacer Kit](#)
- [\(3399878\) Mechanics Hand Tool Set](#)
- [\(4918736\) Plug, Protector](#)
- [\(3163524\) Pulley Alignment Fixture](#)
- [\(5394864\) Spark Plug Gap Gage](#)
- [\(5299900\) Spark Plug Socket](#)
- [\(3375622\) Tappet Guide Screw Salvage Kit](#)
- [\(3376138\) Tappet Holding Block](#)
- [\(3822514\) Test Stand Audit Kit](#)
- [\(3823720\) Test Stand Audit Kit - Fuel Pump](#)
- [\(3822734\) Test Stand Audit Kit - Monthly](#)
- [\(3823166\) Thermostat Cover Boring Tool](#)
- [\(3823173\) Thermostat Cover Boring Tool](#)
- [\(3823689\) Threadlocker \(Green\) \(50 ml bottle\)](#)
- [\(3376298\) Water Test Plug](#)