



Service Tool Instruction

Service Tool Instruction
Number: 3377949

Revision Level:

Released Date: 17-sep-
2003

Description

Fuel Sight Glass Assembly

Purpose

This document provides information describing available fuel sight glass assemblies. Fuel sight glass assemblies are used to check for air leaks in the suction side of the fuel system. The fuel sight glass assembly illustrated below is generic and will vary with hose application.

©Cummins Inc



22800673

Table 1, Fuel Sight Glass Assembly, Part Number 3165147

Item Number	Part Number	Description	Quantity
Not shown	3165147	Fuel sight glass assembly, number 20 o-ring face seal	1

Table 2, Other Fuel Sight Glass Assemblies, Purchased Separately

Item Number	Part Number	Description	Quantity
Not shown	3164383	Fuel sight glass assembly, number 10 SAE	1

Table 2, Other Fuel Sight Glass Assemblies, Purchased Separately			
Item Number	Part Number	Description	Quantity
Not shown	3375362	Fuel sight glass assembly, number 12 SAE	1
Not shown	3376718	Fuel sight glass assembly, number 12 JIC (Joint Industry Conference)	1
Not shown	3375808	Fuel sight glass assembly, number 16 JIC (Joint Industry Conference)	1
Not shown	3164387	Fuel sight glass assembly, number 12 o-ring face seal	1
Not shown	3163270	Fuel sight glass assembly, number 16 o-ring face seal	1

--

Table 3, Items Used with Fuel Sight Glass Assembly, Purchased Separately			
Item Number	Part Number	Description	Quantity
Not shown	3332160	O-ring face seal, number 20 (replacement for Part Number 3165147)	1
Not shown	3075658	O-ring face seal, number 16 (replacement for Part Number 3163270)	1
Not shown	3328589	O-ring face seal, number 12 (replacement for Part Number 3164387)	1
Not shown	3165146	Hose (used with 3164387 for QSK23)	1

--

