



Service Tool Instruction

Service Tool Instruction
Number: 3400237

Revision Level:

Released Date: 13-nov-
2006


Description

Rear Crankshaft Oil Seal Installer Kit

Purpose

This document provides information for the Rear Crankshaft Oil Seal Installer Kit, Part Number 4918762. The kit is used to remove and install the rear oil seal and rear wear sleeve oil seals on the crankshaft of the QST30 series engine with wet flywheel housings. For additional information, refer to Procedure 001-024 (</qs3/pubsys2/xml/en/procedures/57/57-001-024.html>) in the QST30 Series Engine Service Manual, Bulletin 4021539.

©Cummins Inc



22a00244

Table 1, Rear Crankshaft Oil Seal Installer Kit, Part Number 4918762

Item Number	Part Number	Description	Quantity
1	4918752	Spacer	1
2	3163828	Capscrew	25

Table 2, Items Used with the Rear Crankshaft Oil Seal Installer Kit, Purchased Separately			
Item Number	Part Number	Description	Quantity
Not shown	3825195	Rear Crankshaft Oil Seal/Wear Sleeve Removal and Installation Tool Kit	1