



Technical Service Bulletin

Technical Service Bulletin: TSB120221

Released Date: 21-Oct-2014

Front Crankshaft Seal with Wear Sleeve and Press-On Shaft Excluder (POSE)

Front Crankshaft Seal with Wear Sleeve and Press-On Shaft Excluder (POSE)

Warranty Statement

The information in this document has no effect on present warranty coverage or repair practices, nor does it authorize TRP or Campaign actions.

Contents

This document announces the release of the K19 service front crankshaft seal with wear sleeve and press-on shaft excluder (POSE) for use on 38 liter and 50 liter diesel and gas engines.

Seal Assembly with Wear Sleeve

This service seal with wear sleeve was developed for use where the shaft sealing surface has been worn or damaged. The wear sleeve is 1.57 mm [0.062 in] thick to provide a robust wear surface for the seal. The seal used with the wear sleeve was designed specifically for use with the wear sleeve. The seal is **not** interchangeable with the standard seal since it has a larger inside diameter and fits **only** the wear sleeve. If either the wear sleeve or seal is replaced, or the seal is removed, the complete seal and wear sleeve assembly must be replaced.

The wear sleeve and seal assembly **must** be installed in one operation. The installation requires the use of a special service tool to install the wear sleeve and seal to specific depths.

The use of the front crankshaft seal with wear sleeve is recommended for use on all engines during rebuild or repair, in order to prevent wear to the crankshaft nose. This seal with wear sleeve will be installed in production on new engines.

POSE

The POSE seal improves the front crankshaft seal durability. The POSE seal is installed in front of the front crankshaft seal and rotates with the crankshaft reducing the amount of dirt reaching the front crankshaft sealing element. No special service tools are required to install the POSE seal. The POSE seal can be installed onto the shaft using only hand pressure.

The engine serial number (ESN) first for the seal with wear sleeve and POSE being installed at the Daventry Engine Plant is 33196377.

Description	Part Number
Front Crankshaft Seal with Wear Sleeve	3095278

Description	Part Number
POSE	3331663
Front Crankshaft Seal Kit (contains both components above)	3803994
Use the following procedures for further information on removal and installation of the front crankshaft seal. • K38, K50, QSK38, and QSK50 Service Manual, Bulletin 4021528. Refer to Procedure 001-023 in Section 1. (/qs3/pubsys2/xml/en/procedures/28/28-001-023-tr.html) • KTA38GC CM558 Service Manual, Bulletin 4021642. Refer to Procedure 001-023 in Section 1. (/qs3/pubsys2/xml/en/procedures/28/28-001-023-tr-gc.html)	

Document History

Date	Details
2012-7-9	Module Created
2013-1-9	Add ESN first for Daventry
2014-10-21	Work Order 65066

Last Modified: 21-Oct-2014
