



Technical Service Bulletin

Technical Service Bulletin: TSB170037

Released Date: 20-Nov-2019

Service Part Topics (SPT) Archive

Service Part Topics (SPT) Archive

Warranty Statement

The information in this document has no effect on present warranty coverage or repair practices, nor does it authorize TRP or Campaign actions.

Contents

Announcement

- The Service Part Topics (SPT) in the SPT archive are for reference **only**. Some SPTs have been replaced by and/or converted to Technical Service Bulletins (TSB). TSBs were introduced in the year 2010.
- All available TSBs **must** be referenced first before searching for a SPT.

Example of SPTs on QSOL

- SPTs are sometimes listed in part references on QSOL. See Figure 1 below.
- The SPT archive **must** be manually searched to locate these SPTs.

© Cummins Inc. © Cummins Inc.

Parts are listed top to bottom from oldest to newest.

Part Number	Part Topic	Bulletin	Literature	Recon Equivalent	Fleetguard Xref
3918112					View
*3918403	90T0-6A				View
3922882	97T7-1				View
3919014	97T7-1				View
3934159					View
3974325					View

00r00213

Figure 1, Example of SPT Listed in Part Reference Section on QSOL.

Searching for SPTs

- To find Service Parts Topics (SPT) dating back as far as the year 1970, reference the link below:

Note : <https://quickserve.cummins.com/qs3/portal/service/spt/index.html?header=false> (<https://quickserve.cummins.com/qs3/portal/service/spt/index.html?header=false>)

- The Service Parts Topics Archive is divided into SPT groups 1 through 23. After finding the correct SPT group number, search by year.
- Breakdown of SPT number: SPT76T2-5
 - SPT = Service Parts Topic
 - 76 = Year 1976
 - T2 = SPT Group 2
 - 5 = An Index Number
- To manually locate Archived Service Parts Topics link on QuickServe® Online (See Figure 2 below):
 1. Select the Service tab
 2. Select the Related Information tab
 3. Reference the Service Documents section
 4. Select Archived Service Parts Topics




Figure 2, Locating Archived Service Parts Topics Link on QSOL.

- Tables 1, 2, 3, and 4 below include all SPT numbers included in the SPT archive for groups 000 to 023.

Table 1, Archived Service Parts Topics Group 000 to 004

000 Compl ete Engine Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	002 Cylind er Head Group	002 Cylind er Head Group	003 Rocke r Levers Group	004 Cam Follow ers Tappe ts Group
00T0-1	00T1-1	75T1-19	80T1-20	87T1-21	95T1-7	00T2-1	91T2-11	01T3-1A	01T4-1
00T0-10	00T1-10	75T1-2	80T1-21A	87T1-3	95T1-8	00T2-2	91T2-12	01T3-2	02T4-1
00T0-11	00T1-11	75T1-20	80T1-22	87T1-4	95T1-9	00T2-3	91T2-2	01T3-3	02T4-2
00T0-12	00T1-12	75T1-21	80T1-23	87T1-5	96T1-1	00T2-4	91T2-3	01T3-4	73T4-1
00T0-3	00T1-13	75T1-22	80T1-24	87T1-6	96T1-2	00T2-5	91T2-4	01T3-5	73T4-2_S1
00T0-4	00T1-2	75T1-23A	80T1-25	87T1-7	96T1-3	010T2-5	91T2-5	01T3-6	73T4-2

Table 1, Archived Service Parts Topics Group 000 to 004									
000 Compl ete Engine Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	002 Cylind er Head Group	002 Cylind er Head Group	003 Rocke r Levers Group	004 Cam Follow ers Tappe ts Group
00T0- 6	00T1- 3	75T1- 24	80T1- 26	87T1- 8	96T1- 5	01T2- 1	91T2- 6	01T3- 7	73T4- 2S1
00T0- 7_S1	00T1- 4	75T1- 25	80T1- 28	87T1- 9	96T1- 6	01T2- 10	91T2- 8	02T3- 1	73T4- 3
00T0- 7	00T1- 4A	75T1- 26	80T1- 29	88T1- 1	97T1- 1	01T2- 2	91T2- 9A	02T3- 2	74T4- 2
00T0- 8	00T1- 5	75T1- 27	80T1- 3	88T1- 10	97T1- 10	01T2- 3	92T2- 1	02T3- 3	74T4- 3
00T0- 9	00T1- 6	75T1- 3	80T1- 31	88T1- 11	97T1- 11	01T2- 4	92T2- 2A	02T3- 4	75T4- 1A
01T0- 1	00T1- 7	75T1- 4	80T1- 32	88T1- 12	97T1- 12	01T2- 6	92T2- 3	73T3- 1	75T4- 2
01T0- 10	00T1- 8	75T1- 5	80T1- 33	88T1- 13	97T1- 13	01T2- 7	93T2- 1	73T3- 2_S1	75T4- 3A
01T0- 11	00T1- 9	75T1- 6	80T1- 34	88T1- 19	97T1- 14	01T2- 8	93T2- 2	73T3- 2	75T4- 4
01T0- 12	01T1- 1	75T1- 7	80T1- 35	88T1- 2	97T1- 15	01T2- 9	93T2- 3	73T3- 3A_S1	76T4- 1A
01T0- 13	01T1- 10	75T1- 8	80T1- 36	88T1- 20	97T1- 16	02T2- 1	93T2- 4A	73T3- 3B	76T4- 2
01T0- 14	01T1- 11	75T1- 9	80T1- 38	88T1- 21	97T1- 17	02T2- 2	93T2- 5	73T3- 4	76T4- 3
01T0- 2	01T1- 12	76T1- 1	80T1- 4	88T1- 23	97T1- 2	02T2- 3	94T2- 2	74T3- 1	77T4- 1
01T0- 3	01T1- 13	76T1- 10	80T1- 41	88T1- 24	97T1- 3	02T2- 4	94T2- 3	74T3- 2	77T4- 2
01T0- 4	01T1- 14	76T1- 10A	80T1- 43	88T1- 25	97T1- 4	03T2- 1	94T2- 4	74T3- 3	77T4- 3
01T0- 5	01T1- 15	76T1- 11	80T1- 44	88T1- 4	97T1- 5	03T2- 2	94T2- 5	74T3- 4	77T4- 4
01T0- 7	01T1- 16	76T1- 12	80T1- 5	88T1- 5	97T1- 6	03T2- 3	94T2- 6	75T3- 1	77T4- 5

Table 1, Archived Service Parts Topics Group 000 to 004									
000 Compl ete Engine Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	002 Cylind er Head Group	002 Cylind er Head Group	003 Rocke r Levers Group	004 Cam Follow ers Tappe ts Group
01T0-8	01T1-17	76T1-13	80T1-6	88T1-6	97T1-7	03T2-4	95T2-1	75T3-2	78T4-1
01T0-9	01T1-2	76T1-14B	80T1-7	88T1-7	97T1-8	03T2-5	95T2-2	75T3-3	78T4-2
02T0-1	01T1-3	76T1-15	80T1-8	88T1-8	97T1-9	04T2-1	95T2-3	75T3-4	79T4-1
02T0-10	01T1-4	76T1-16	80T1-9	88T1-9	98T1-1	04T2-10	95T2-4	75T3-5	79T4-2
02T0-11	01T1-5	76T1-17	81T1-	89T1-11A	98T1-10	04T2-2	95T2-6	76T3-1	79T4-3
02T0-2	01T1-6	76T1-18	81T1-1	89T1-12	98T1-11	04T2-3	96T2-1	76T3-2	80T4-1_S1
02T0-3	01T1-7	76T1-19_S1	81T1-10	89T1-13	98T1-12	04T2-4	96T2-10	76T3-3	80T4-1
02T0-4	01T1-8	76T1-19	81T1-11	89T1-15	98T1-13	04T2-5	96T2-11	76T3-4	80T4-1S1
02T0-5A	01T1-9	76T1-19A	81T1-12	89T1-16	98T1-14	04T2-6	96T2-12	77T3-1	80T4-2
02T0-6	02T1-1	76T1-2	81T1-13	89T1-18	98T1-15	04T2-8	96T2-13	77T3-2	80T4-3
02T0-7	02T1-10	76T1-20	81T1-14	89T1-19	98T1-2	04T2-9	96T2-2	77T3-3	80T4-4
02T0-8	02T1-11	76T1-21	81T1-15	89T1-2	98T1-3	72T2-1	96T2-3	77T3-4	80T4-5
02T0-9	02T1-12	76T1-22	81T1-16	89T1-20	98T1-5	73T2-1	96T2-4	78T3-1	80T4-6
73T0-1	02T1-13	76T1-23	81T1-17	89T1-21	98T1-6	73T2-2A	96T2-5	78T3-3	80T4-7
74T0-1	02T1-14	76T1-24	81T1-18	89T1-22	98T1-7	73T2-3	96T2-5A	78T3-4	81T4-1
75T0-1	02T1-15	76T1-25	81T1-19	89T1-23	98T1-8	73T2-4	96T2-6	79T3-3A	81T4-2

Table 1, Archived Service Parts Topics Group 000 to 004									
000 Compl ete Engine Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	002 Cylind er Head Group	002 Cylind er Head Group	003 Rocke r Levers Group	004 Cam Follow ers Tappe ts Group
75T0- 2	02T1- 16	76T1- 26	81T1- 2	89T1- 4	98T1- 9	73T2- 5	96T2- 6A	80T3- 1	81T4- 3
76T0- 1	02T1- 17	76T1- 27	81T1- 20	89T1- 5	99T1- 1	73T2- 6	96T2- 7	80T3- 2	82T4- 1
77T0- 1	02T1- 18	76T1- 28	81T1- 21	89T1- 7	99T1- 10	74T2- 1	97T2- 1	80T3- 4	82T4- 2
78T0- 1	02T1- 2	76T1- 29	81T1- 22A	89T1- 8	99T1- 11	74T2- 10	97T2- 2	80T3- 5	82T4- 3
79T0- 1	02T1- 3	76T1- 3	81T1- 23	89T1- 9	99T1- 12A	74T2- 2	97T2- 3	81T3- 1	83T4- 1
80T0- 1	02T1- 4	76T1- 30	81T1- 25	90T1- 1	99T1- 13	74T2- 3	97T2- 4	81T3- 2	83T4- 3
81T0- 1	02T1- 5	76T1- 31	81T1- 26	90T1- 11	99T1- 14	74T2- 4	97T2- 5	82T3- 1	84T4- 1A
81T0- 2	02T1- 6	76T1- 32	81T1- 3	90T1- 12	99T1- 15	74T2- 5	98T2- 11	84T3- 1	84T4- 2
82T0- 1	02T1- 7	76T1- 33	81T1- 4	90T1- 13	99T1- 16	74T2- 6A	98T2- 12_S1	84T3- 2	86T4- 1
82T0- 2_S1	02T1- 8	76T1- 34	81T1- 5	90T1- 14	99T1- 17	74T2- 7	98T2- 13_S1	85T3- 1	86T4- 2
82T0- 2	02T1- 9	76T1- 35	81T1- 6	90T1- 15	99T1- 18	74T2- 8	98T2- 13	85T3- 2	86T4- 3
82T0- 4	03T1- 1	76T1- 36	81T1- 7A	90T1- 16	99T1- 19	74T2- 9	98T2- 14	85T3- 3	86T4- 4
82T0- 5	03T1- 10	76T1- 37	81T1- 8	90T1- 17	99T1- 2	75T2- 1	98T2- 15	85T3- 4	87T4- 1
83T0- 2	03T1- 11	76T1- 38	81T1- 9	90T1- 18	99T1- 20	75T2- 2	98T2- 16	85T3- 5	87T4- 2
83T0- 3	03T1- 12	76T1- 39	82T1- 1	90T1- 19	99T1- 22	75T2- 3	98T2- 18	86T3- 1	87T4- 3
83T0- 4	03T1- 13	76T1- 4	82T1- 10	90T1- 2	99T1- 23	75T2- 4	98T2- 19	86T3- 2	88T4- 1

Table 1, Archived Service Parts Topics Group 000 to 004									
000 Compl ete Engine Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	002 Cylind er Head Group	002 Cylind er Head Group	003 Rocke r Levers Group	004 Cam Follow ers Tappe ts Group
83T0-5	03T1-14	76T1-40	82T1-11	90T1-20	99T1-24	75T2-5	98T2-2	86T3-3	88T4-2
84T0-1	03T1-15	76T1-41	82T1-12	90T1-21	99T1-3	75T2-6	98T2-3	88T3-1	88T4-3
84T0-3	03T1-16	76T1-42	82T1-13	90T1-3	99T1-4	75T2-7	98T2-4	88T3-2	88T4-4
84T0-4	03T1-17	76T1-43	82T1-14A	90T1-4	99T1-5	75T2-8	98T2-5	88T3-3	89T4-1
84T0-5	03T1-18	76T1-44	82T1-15	90T1-5	99T1-6	75T2-9	98T2-6A	88T3-4	89T4-2
85T0-2	03T1-19	76T1-45	82T1-16	90T1-6	99T1-7	76T2-1	98T2-7	89T3-1	90T4-1
85T0-3	03T1-2	76T1-46	82T1-17	90T1-7	99T1-8	76T2-10	98T2-9	90T3-1	91T4-1
86T0-2	03T1-20	76T1-47	82T1-18	90T1-8	99T1-9	76T2-2	99T2-1	90T3-2A	92T4-1
87T0-2	03T1-21	76T1-48	82T1-19	90T1-9	-	76T2-2A	99T2-10	90T3-3A	92T4-2
87T0-3	03T1-22	76T1-5	82T1-2	91T1-1	-	76T2-3	99T2-2	90T3-4	93T4-1
88T0-1	03T1-3	76T1-6	82T1-20	91T1-10	-	76T2-4	99T2-3	90T3-5	94T4-1A
88T0-2	03T1-4	76T1-7	82T1-3	91T1-12	-	76T2-5	99T2-4	91T3-1	95T4-1
88T0-3	03T1-5	76T1-8	82T1-4	91T1-13	-	76T2-6	99T2-5	91T3-2	97T4-1
89T0-2	03T1-6	76T1-9	82T1-5	91T1-14	-	76T2-6A	99T2-6	91T3-4	97T4-2
89T0-3	03T1-7	77T1-1	82T1-6A	91T1-15	-	76T2-7	99T2-7	91T3-5	97T4-3
89T0-4	03T1-8	77T1-10	82T1-7	91T1-2	-	76T2-8	99T2-8	92T3-1	98T4-1

Table 1, Archived Service Parts Topics Group 000 to 004

000 Compl ete Engine Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	002 Cylind er Head Group	002 Cylind er Head Group	003 Rocke r Levers Group	004 Cam Follow ers Tappe ts Group
89T0-5	03T1-9	77T1-11	82T1-8	91T1-3	-	76T2-9	-	92T3-3	98T4-2
89T0-6	04T1-1	77T1-12	82T1-9	91T1-5	-	77T2-1	-	92T3-4	99T4-1
89T0-7	04T1-14	77T1-13	83T1-10	91T1-6	-	77T2-2	-	92T3-6	99T4-2
90T0-3	04T1-15	77T1-14	83T1-11	91T1-7	-	77T2-3	-	93T3-1	99T4-3
90T0-4	04T1-16	77T1-15	83T1-12	91T1-8	-	77T2-4	-	93T3-2	-
90T0-5	04T1-17	77T1-16	83T1-13a	91T1-9	-	77T2-5	-	93T3-3	-
90T0-6A	04T1-18	77T1-17	83T1-14	92T1-10	-	77T2-6	-	94T3-1	-
90T0-7	04T1-19	77T1-18	83T1-2	92T1-11	-	77T2-7	-	94T3-2	-
91T0-2	04T1-2	77T1-19	83T1-4	92T1-12	-	77T2-8	-	95T3-1	-
91T0-5	04T1-3	77T1-2	83T1-5	92T1-13	-	78T2-1	-	95T3-2	-
92T0-1	04T1-4	77T1-20	83T1-6	92T1-14A	-	78T2-2	-	95T3-3	-
92T0-3	04T1-5	77T1-21	83T1-8	92T1-15	-	78T2-3	-	95T3-4	-
92T0-4	04T1-6	77T1-22A	83T1-9	92T1-16	-	78T2-4	-	96T3-1A	-
92T0-5	04T1-7	77T1-23	84T1-1	92T1-17	-	79T2-1	-	96T3-2	-
92T0-6	04T1-9	77T1-24	84T1-10	92T1-18	-	79T2-2	-	96T3-3	-
93T0-1	73T1-10	77T1-25	84T1-2	92T1-19	-	79T2-3	-	96T3-4	-

Table 1, Archived Service Parts Topics Group 000 to 004

000 Compl ete Engine Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	002 Cylind er Head Group	002 Cylind er Head Group	003 Rocke r Levers Group	004 Cam Follow ers Tappe ts Group
93T0-2	73T1-11	77T1-26	84T1-3	92T1-20A	-	79T2-4	-	96T3-6	-
93T0-3A	73T1-12A	77T1-3	84T1-4	92T1-21	-	80T2-1	-	96T3-7	-
93T0-4	73T1-13	77T1-4	84T1-5	92T1-2A	-	80T2-10	-	97T3-1	-
93T0-6	73T1-14A_S1	77T1-5	84T1-6	92T1-3	-	80T2-11	-	97T3-2	-
94T0-1	73T1-14A	77T1-6	84T1-7	92T1-5	-	80T2-13	-	97T3-3	-
94T0-2A	73T1-15	77T1-7	84T1-8	92T1-6	-	80T2-2_FEB	-	97T3-4	-
95T0-11	73T1-16	77T1-8	85T1-1	92T1-7	-	80T2-2_OCT	-	98T3-10	-
95T0-12	73T1-17	77T1-9	85T1-10	92T1-8	-	80T2-3	-	98T3-2A	-
95T0-2	73T1-18	78T1-1	85T1-11	92T1-9	-	80T2-4	-	98T3-5	-
95T0-3	73T1-19	78T1-10	85T1-12	93T1-1	-	80T2-5_S1	-	98T3-6	-
95T0-5A	73T1-1A	78T1-11	85T1-13	93T1-11	-	80T2-5	-	98T3-7	-
95T0-6	73T1-2	78T1-12	85T1-14	93T1-12	-	80T2-6	-	98T3-8	-
95T0-7	73T1-20	78T1-13	85T1-15	93T1-14	-	80T2-7	-	-	-
96T0-2	73T1-21	78T1-14	85T1-18	93T1-15	-	80T2-8	-	-	-
96T0-3	73T1-22	78T1-15	85T1-19	93T1-16	-	80T2-9	-	-	-
96T0-4	73T1-23	78T1-16	85T1-2	93T1-17	-	81T2-1	-	-	-

Table 1, Archived Service Parts Topics Group 000 to 004

000 Compl ete Engine Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	002 Cylind er Head Group	002 Cylind er Head Group	003 Rocke r Levers Group	004 Cam Follow ers Tappe ts Group
96T0-7A	73T1-24	78T1-17	85T1-3	93T1-18	-	81T2-2	-	-	-
96T0-9	73T1-25	78T1-18	85T1-4	93T1-19	-	81T2-3	-	-	-
97T0-2	73T1-26	78T1-19	85T1-5	93T1-2	-	81T2-4	-	-	-
97T0-3	73T1-27	78T1-2	85T1-6	93T1-20	-	81T2-5	-	-	-
97T0-4	73T1-28	78T1-3	85T1-7	93T1-3	-	81T2-6	-	-	-
97T0-5	73T1-29	78T1-4A	85T1-8	93T1-4	-	82T2-1A	-	-	-
97T0-6	73T1-3	78T1-5	85T1-9	93T1-5	-	82T2-2	-	-	-
98T0-10	73T1-4	78T1-6	86T1-1	93T1-6	-	82T2-3	-	-	-
98T0-11	73T1-5	78T1-7_S1	86T1-10	93T1-7B	-	83T2-1	-	-	-
98T0-12	73T1-6_S1	78T1-7	86T1-11	93T1-8	-	83T2-2	-	-	-
98T0-13	73T1-6_S2	78T1-8	86T1-12	93T1-9	-	83T2-3	-	-	-
98T0-14	73T1-6A	78T1-9	86T1-13	94T1-1	-	84T2-1	-	-	-
98T0-15	73T1-7	79T1-1	86T1-14	94T1-10	-	84T2-2	-	-	-
98T0-16	73T1-8	79T1-10	86T1-15	94T1-11	-	84T2-2A	-	-	-
98T0-17	73T1-9	79T1-11	86T1-16	94T1-12A	-	84T2-3	-	-	-
98T0-18	74T1-1	79T1-12	86T1-17	94T1-13	-	84T2-4	-	-	-

Table 1, Archived Service Parts Topics Group 000 to 004									
000 Compl ete Engine Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	002 Cylind er Head Group	002 Cylind er Head Group	003 Rocke r Levers Group	004 Cam Follow ers Tappe ts Group
98T0-19	74T1-10	79T1-13	86T1-18	94T1-14	-	85T2-1	-	-	-
98T0-2	74T1-11	79T1-14	86T1-19	94T1-15	-	85T2-10	-	-	-
98T0-20	74T1-12	79T1-15	86T1-2	94T1-16	-	85T2-2	-	-	-
98T0-21	74T1-13	79T1-16	86T1-20A	94T1-17	-	85T2-3	-	-	-
98T0-22	74T1-15	79T1-17	86T1-21	94T1-18	-	85T2-3A	-	-	-
98T0-3	74T1-16	79T1-18	86T1-22	94T1-19	-	85T2-4	-	-	-
98T0-31	74T1-17	79T1-2	86T1-23	94T1-20	-	85T2-5	-	-	-
98T0-4	74T1-18B	79T1-20	86T1-24	94T1-21	-	85T2-6A	-	-	-
98T0-5	74T1-19	79T1-21	86T1-25	94T1-22	-	85T2-7	-	-	-
98T0-6	74T1-2	79T1-22A	86T1-26	94T1-23	-	85T2-8	-	-	-
98T0-8	74T1-20A	79T1-23	86T1-27	94T1-24	-	86T2-1A	-	-	-
98T0-9	74T1-21	79T1-24	86T1-28	94T1-25	-	86T2-2	-	-	-
99T0-1	74T1-2A	79T1-25	86T1-29	94T1-27	-	87T2-1	-	-	-
99T0-10	74T1-3	79T1-3	86T1-3	94T1-2A	-	87T2-2	-	-	-
99T0-11	74T1-4	79T1-4	86T1-4	94T1-3A	-	87T2-3	-	-	-
99T0-12	74T1-5	79T1-5A	86T1-5	94T1-4	-	87T2-4	-	-	-

Table 1, Archived Service Parts Topics Group 000 to 004									
000 Compl ete Engine Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	001 Cylind er Block Group	002 Cylind er Head Group	002 Cylind er Head Group	003 Rocke r Levers Group	004 Cam Follow ers Tappe ts Group
99T0-13	74T1-6	79T1-6	86T1-6	94T1-5	-	87T2-5	-	-	-
99T0-14	74T1-6A	79T1-7	86T1-7	94T1-6	-	87T2-7	-	-	-
99T0-15	74T1-7	79T1-8	86T1-8	94T1-7	-	88T2-1	-	-	-
99T0-16	74T1-8	79T1-8A	86T1-9A	94T1-8	-	88T2-2	-	-	-
99T0-17	74T1-9	79T1-9B	87T1-1	94T1-9	-	88T2-3	-	-	-
99T0-18	75T1-1	80T1-1	87T1-10	95T1-1	-	88T2-6	-	-	-
99T0-2	75T1-11A	80T1-10	87T1-11	95T1-10	-	88T2-7	-	-	-
99T0-21	75T1-12	80T1-11	87T1-13	95T1-11	-	89T2-1	-	-	-
99T0-22	75T1-13	80T1-12	87T1-14A	95T1-12	-	89T2-2	-	-	-
99T0-3	75T1-14A	80T1-13	87T1-15	95T1-13	-	89T2-3	-	-	-
99T0-4	75T1-15A	80T1-14	87T1-16	95T1-14	-	89T2-4	-	-	-
99T0-5	75T1-16_S1	80T1-16	87T1-17	95T1-2	-	89T2-5	-	-	-
99T0-6	75T1-16	80T1-17	87T1-18	95T1-3	-	90T2-1	-	-	-
99T0-7	75T1-17	80T1-18A	87T1-19	95T1-4	-	90T2-2	-	-	-
99T0-8	75T1-18	80T1-19	87T1-2	95T1-5	-	91T2-1	-	-	-
99T0-9	75T1-18A	80T1-2	87T1-20	95T1-6	-	91T2-10	-	-	-

Table 2, Archived Service Parts Topics Group 005 to 007

005 Fuel Syste m Group	005 Fuel Syste m Group	005 Fuel Syste m Group	005 Fuel Syste m Group	006 Injecto rs and Fuel Lines Group	006 Injecto rs and Fuel Lines Group	006 Injecto rs and Fuel Lines Group	007 Lubric ating Oil Syste m Group	007 Lubric ating Oil Syste m Group	007 Lubric ating Oil Syste m Group
00T5-1	78T5-13	86T5-17	92T5-28	00T6-1	86T6-2	98T6-5	00T7-1	78T7-9	95T7-7A
00T5-10	78T5-14	86T5-2	92T5-29	00T6-10	86T6-4	98T6-6	00T7-10	79T7-10A	95T7-8
00T5-11	78T5-16	86T5-3	92T5-3	00T6-10A	86T6-5	98T6-7	00T7-11	79T7-11	95T7-9
00T5-12	78T5-17	86T5-4	92T5-30	00T6-11	86T6-5A	98T6-8	00T7-12	79T7-12	96T7-1
00T5-13	78T5-2	86T5-5	92T5-31	00T6-2	86T6-7	98T6-9	00T7-13	79T7-13	96T7-2
00T5-14	78T5-3	86T5-6	92T5-4	00T6-3	87T6-1	99T6-1	00T7-14	79T7-1A	96T7-5
00T5-15	78T5-4	86T5-7	92T5-5	00T6-4	87T6-10A	99T6-10	00T7-15	79T7-2	97T7-1
00T5-16	78T5-5	86T5-7A	92T5-6	00T6-5	87T6-11	99T6-10A	00T7-16	79T7-3	97T7-2A
00T5-17	78T5-6	86T5-8	92T5-7	00T6-6	87T6-13	99T6-11	00T7-17	79T7-4	97T7-4
00T5-18	78T5-7	86T5-9	92T5-8	00T6-7	87T6-1A	99T6-2	00T7-18	79T7-5	97T7-5
00T5-2	78T5-8	87T5-1	92T5-9	00T6-8	87T6-2	99T6-3	00T7-19	79T7-6	97T7-6
00T5-29	78T5-9	87T5-10	93T5-10	00T6-9	87T6-3	99T6-4	00T7-2	79T7-8	97T7-7
00T5-3	79T5-10	87T5-11A	93T5-11	01T6-1	87T6-4	99T6-5	00T7-3	79T7-9	97T7-8
00T5-4	79T5-11	87T5-12	93T5-12	01T6-2	87T6-5	99T6-6	00T7-4	80T7-1	98T7-1
00T5-5	79T5-11A	87T5-13	93T5-13	01T6-3A	87T6-6	99T6-7	00T7-5	80T7-10	98T7-10
00T5-6A	79T5-12	87T5-14	93T5-14	01T6-4	87T6-7	99T6-7A	00T7-6	80T7-11	98T7-11

Table 2, Archived Service Parts Topics Group 005 to 007

005 Fuel System Group	005 Fuel System Group	005 Fuel System Group	005 Fuel System Group	006 Injectors and Fuel Lines Group	006 Injectors and Fuel Lines Group	006 Injectors and Fuel Lines Group	007 Lubricating Oil System Group	007 Lubricating Oil System Group	007 Lubricating Oil System Group
00T5-8	79T5-13	87T5-15	93T5-15	01T6-5	87T6-8	99T6-8	00T7-7	80T7-12	98T7-12
00T5-9	79T5-14	87T5-16	93T5-16_AE B	01T6-6	87T6-9	99T6-9	00T7-8	80T7-13	98T7-14
01T5-1	79T5-15	87T5-17	93T5-16	01T6-7	88T6-1	-	00T7-9	80T7-14	98T7-15
01T5-10	79T5-16	87T5-18	93T5-18	01T6-8	88T6-10	-	01T7-1	80T7-15	98T7-2
01T5-11	79T5-17	87T5-1A	93T5-19	02T6-1	88T6-11	-	01T7-10	80T7-16	98T7-5
01T5-12	79T5-18	87T5-20	93T5-1A	02T6-2	88T6-12	-	01T7-11	80T7-17	98T7-6
01T5-13	79T5-19	87T5-21	93T5-1B	02T6-3	88T6-13	-	01T7-12	80T7-18	98T7-7
01T5-14	79T5-2	87T5-2A	93T5-20	02T6-4	88T6-14	-	01T7-13	80T7-19	98T7-8
01T5-15	79T5-20	87T5-3	93T5-21	02T6-5	88T6-15	-	01T7-2A	80T7-2	98T7-9
01T5-16	79T5-21	87T5-4	93T5-22	02T6-6	88T6-18	-	01T7-3	80T7-20	99T7-1
01T5-2	79T5-22	87T5-4A	93T5-23	03T6-1	88T6-19	-	01T7-4	80T7-21	99T7-10
01T5-3	79T5-23	87T5-5	93T5-24	03T6-2	88T6-2	-	01T7-5	80T7-22	99T7-11
01T5-4	79T5-23A	87T5-6	93T5-2A	04T6-1	88T6-20	-	01T7-7	80T7-23	99T7-12
01T5-5	79T5-24	87T5-7	93T5-2B	04T6-2	88T6-3	-	01T7-8	80T7-3	99T7-13
01T5-6	79T5-25	87T5-8	93T5-3	04T6-3	88T6-4A	-	01T7-9	80T7-4	99T7-14
01T5-7	79T5-26	87T5-9	93T5-4	04T6-4	88T6-5	-	02T7-1	80T7-5	99T7-15

Table 2, Archived Service Parts Topics Group 005 to 007

005 Fuel System Group	005 Fuel System Group	005 Fuel System Group	005 Fuel System Group	006 Injectors and Fuel Lines Group	006 Injectors and Fuel Lines Group	006 Injectors and Fuel Lines Group	007 Lubricating Oil System Group	007 Lubricating Oil System Group	007 Lubricating Oil System Group
01T5-8	79T5-27A	88T5-1	93T5-5	04T6-5	88T6-6	-	02T7-2	80T7-6	99T7-16
01T5-9	79T5-29_S2	88T5-10	93T5-7	04T6-6	88T6-7	-	02T7-3	80T7-7	99T7-17
02T5-1	79T5-29	88T5-11	93T5-8	04T6-7	88T6-8	-	02T7-4	80T7-7A	99T7-18
02T5-2	79T5-3	88T5-12	93T5-9	05T6-10	88T6-9	-	02T7-5	80T7-8	99T7-2A
02T5-3	79T5-30	88T5-13	94T5-1	05T6-5	89T6-1	-	02T7-6	80T7-9	99T7-3
02T5-4	79T5-32	88T5-14	94T5-10	05T6-6	89T6-10A	-	02T7-7	81T7-1	99T7-4
02T5-5	79T5-33	88T5-15	94T5-11	05T6-7	89T6-13	-	02T7-8	81T7-10	99T7-5
02T5-6	79T5-34	88T5-17	94T5-12	05T6-8	89T6-2	-	02T7-9	81T7-11	99T7-6
02T5-7	79T5-35	88T5-18	94T5-13	05T6-9	89T6-3	-	03T7-1	81T7-1A	99T7-7
02T5-8	79T5-36	88T5-19	94T5-15	70T6-13	89T6-4	-	03T7-10	81T7-2	99T7-8
03T5-1	79T5-37	88T5-2	94T5-16	73T6-3	89T6-5	-	03T7-11	81T7-3A	99T7-9
03T5-10	79T5-38	88T5-20	94T5-2	74T6-1	89T6-6A	-	03T7-2	81T7-4	-
03T5-11	79T5-39	88T5-21	94T5-3	74T6-2	89T6-9A	-	03T7-3	81T7-5	-
03T5-12	79T5-4	88T5-22	94T5-4	74T6-3	90T6-1	-	03T7-4	81T7-6	-
03T5-13	79T5-5	88T5-23	94T5-5	75T6-1	90T6-10	-	03T7-5	81T7-8	-
03T5-14	79T5-6_S1	88T5-26	94T5-6	75T6-10	90T6-11	-	03T7-6	81T7-9	-

Table 2, Archived Service Parts Topics Group 005 to 007

005 Fuel System Group	005 Fuel System Group	005 Fuel System Group	005 Fuel System Group	006 Injectors and Fuel Lines Group	006 Injectors and Fuel Lines Group	006 Injectors and Fuel Lines Group	007 Lubricating Oil System Group	007 Lubricating Oil System Group	007 Lubricating Oil System Group
03T5-2	79T5-6	88T5-27	94T5-7	75T6-11	90T6-2	-	03T7-7	82T7-12	-
03T5-3	79T5-6A	88T5-28	94T5-8	75T6-1A	90T6-3	-	03T7-8	82T7-13	-
03T5-4	79T5-7	88T5-29	94T5-9	75T6-1B	90T6-4	-	03T7-9	82T7-14	-
03T5-5	79T5-8	88T5-3	95T5-1	75T6-3	90T6-5	-	73T7-1	82T7-2	-
03T5-6	79T5-9	88T5-30	95T5-10	75T6-4	90T6-6	-	73T7-10	82T7-3	-
03T5-7	80T5-1	88T5-31	95T5-12	75T6-5	90T6-7	-	73T7-11	82T7-5	-
03T5-8	80T5-10	88T5-32	95T5-13	75T6-6	90T6-8	-	73T7-12	82T7-7	-
04T5-1	80T5-12	88T5-33	95T5-3	75T6-7	90T6-9	-	73T7-13	82T7-8	-
04T5-2	80T5-13	88T5-34	95T5-4	75T6-8	91T6-1	-	73T7-2	82T7-9	-
04T5-3	80T5-14	88T5-4	95T5-5	75T6-8S1	91T6-10	-	73T7-3	83T7-10	-
04T5-4	80T5-15	88T5-5	95T5-6	75T6-9	91T6-11	-	73T7-4	83T7-2	-
04T5-8	80T5-17	88T5-8	95T5-8A	76T6-1	91T6-12	-	73T7-5	83T7-5	-
04T5-9	80T5-18	88T5-9	95T5-9	76T6-2	91T6-13	-	73T7-6A	83T7-7S1	-
05T5-12	80T5-19	88T5-9A	96T5-1	76T6-3	91T6-14	-	73T7-7	83T7-8	-
05T5-13	80T5-20	89T5-1	96T5-10	76T6-4	91T6-15	-	73T7-8A	83T7-9	-
05T5-14	80T5-21	89T5-10	96T5-2	76T6-5	91T6-2	-	73T7-9	84T7-1	-

Table 2, Archived Service Parts Topics Group 005 to 007

005 Fuel System Group	005 Fuel System Group	005 Fuel System Group	005 Fuel System Group	006 Injectors and Fuel Lines Group	006 Injectors and Fuel Lines Group	006 Injectors and Fuel Lines Group	007 Lubricating Oil System Group	007 Lubricating Oil System Group	007 Lubricating Oil System Group
05T5-15	80T5-3	89T5-11	96T5-3	76T6-6	91T6-3	-	74T7-1	84T7-10	-
05T5-16	80T5-4	89T5-12	96T5-4	77T6-1	91T6-4A	-	74T7-10	84T7-2	-
05T5-17	80T5-5	89T5-13	96T5-5	77T6-10	91T6-5	-	74T7-2A	84T7-3	-
05T5-18	80T5-6	89T5-14	96T5-6	77T6-2	91T6-6	-	74T7-3	84T7-4	-
05T5-19	80T5-7	89T5-15	96T5-7	77T6-3	91T6-7	-	74T7-4	84T7-5	-
69T5-15	80T5-9A	89T5-16	96T5-7A	77T6-4	91T6-8	-	74T7-5	84T7-6	-
71T5-3	81T5-1	89T5-17	97T5-1	77T6-5	91T6-9	-	74T7-6	84T77-7	-
73T5-1	81T5-10	89T5-18	97T5-10	77T6-7	92T6-1	-	74T7-7	84T7-8	-
73T5-15	81T5-11	89T5-19	97T5-10-2	77T6-7A	92T6-10	-	74T7-8	84T7-9	-
73T5-2	81T5-12	89T5-20	97T5-11	77T6-8	92T6-2	-	74T7-9	85T7-1	-
73T5-3	81T5-14	89T5-21	97T5-12	78T6-1	92T6-3	-	75T7-10	85T7-2	-
73T5-4	81T5-15	89T5-22	97T5-13	78T6-10	92T6-4A	-	75T7-12	85T7-3	-
73T5-5	81T5-16	89T5-23	97T5-14	78T6-11	92T6-7	-	75T7-13	86T7-1	-
73T5-6	81T5-17	89T5-2A	97T5-15	78T6-2_S1	92T6-8	-	75T7-14	86T7-2	-
73T5-7	81T5-18	89T5-3	97T5-17	78T6-2	92T6-9	-	75T7-15	86T7-3	-
74T5-1	81T5-2	89T5-4	97T5-18	78T6-3	93T6-1	-	75T7-16	86T7-4	-

Table 2, Archived Service Parts Topics Group 005 to 007

005 Fuel Syste m Group	005 Fuel Syste m Group	005 Fuel Syste m Group	005 Fuel Syste m Group	006 Injecto rs and Fuel Lines Group	006 Injecto rs and Fuel Lines Group	006 Injecto rs and Fuel Lines Group	007 Lubric ating Oil Syste m Group	007 Lubric ating Oil Syste m Group	007 Lubric ating Oil Syste m Group
74T5-10	81T5-3	89T5-5	97T5-19	78T6-4A	93T6-10	-	75T7-17	86T7-5	-
74T5-12_S1	81T5-4	89T5-6	97T5-2	78T6-5	93T6-11	-	75T7-2A	87T7-1	-
74T5-12_S2	81T5-5	89T5-6A	97T5-20	78T6-6	93T6-12	-	75T7-3A	87T7-2	-
74T5-12	81T5-6	89T5-7	97T5-2A	78T6-64A	93T6-13	-	75T7-5	87T7-3	-
74T5-13	81T5-7A	89T5-9	97T5-3	78T6-6S1	93T6-14	-	75T7-6	87T7-5	-
74T5-13A	81T5-8	90T5-1	97T5-5	78T6-7	93T6-15	-	75T7-7	87T7-6	-
74T5-13B	81T5-9	90T5-2	97T5-6	78T6-8	93T6-16	-	75T7-8	87T7-7	-
74T5-14	82T5-1	90T5-3	97T5-6A	78T6-9	93T6-17	-	75T7-9	88T7-1	-
74T5-2	82T5-10	90T5-4	97T5-7	79T6-10	93T6-18	-	75T7-9A	88T7-10	-
74T5-3	82T5-11	90T5-5	97T5-8A	79T6-11	93T6-2	-	76T7-1	88T7-11	-
74T5-4	82T5-12	90T5-6	97T5-9	79T6-12	93T6-3	-	76T7-10	88T7-13	-
74T5-5	82T5-13	90T5-7	97T5-9A	79T6-14	93T6-4	-	76T7-11	88T7-14	-
74T5-6	82T5-14	90T5-8	98T5-1	79T6-15	93T6-5	-	76T7-12	88T7-2	-
74T5-7	82T5-16	91T5-1	98T5-10	79T6-16	93T6-6	-	76T7-13	88T7-3	-
74T5-8	82T5-17	91T5-10	98T5-11	79T6-17	93T6-7	-	76T7-14	88T7-4	-
74T5-9	82T5-19	91T5-11	98T5-12	79T6-18	93T6-8	-	76T7-15	88T7-5A	-

Table 2, Archived Service Parts Topics Group 005 to 007

005 Fuel System Group	005 Fuel System Group	005 Fuel System Group	005 Fuel System Group	006 Injectors and Fuel Lines Group	006 Injectors and Fuel Lines Group	006 Injectors and Fuel Lines Group	007 Lubricating Oil System Group	007 Lubricating Oil System Group	007 Lubricating Oil System Group
75T5-1_S1	82T5-2	91T5-12	98T5-13	79T6-19	93T6-9	-	76T7-16	88T7-6	-
75T5-1	82T5-20	91T5-13	98T5-14	79T6-2	94T6-1	-	76T7-17	88T7-7	-
75T5-10	82T5-21	91T5-14	98T5-15	79T6-20	94T6-10	-	76T7-18	88T7-8	-
75T5-11	82T5-21A	91T5-15	98T5-16	79T6-3	94T6-11	-	76T7-19	88T7-9	-
75T5-12	82T5-22	91T5-16	98T5-17	79T6-4	94T6-12	-	76T7-20	89T7-1	-
75T5-13	82T5-23	91T5-17	98T5-18	79T6-5	94T6-13	-	76T7-21	89T7-10	-
75T5-2	82T5-24	91T5-18	98T5-19	79T6-6	94T6-14	-	76T7-2A	89T7-2	-
75T5-3	82T5-25	91T5-19	98T5-2	79T6-7	94T6-2	-	76T7-3	89T7-3	-
75T5-3A	82T5-3	91T5-2	98T5-20	79T6-8	94T6-3	-	76T7-4A	89T7-4A	-
75T5-4	82T5-4	91T5-20	98T5-2A	79T6-9	94T6-4	-	76T7-5	89T7-5	-
75T5-5	82T5-5	91T5-21	98T5-3	80T6-1	94T6-5	-	76T7-6	89T7-6	-
75T5-6	82T5-6	91T5-22	98T5-5	80T6-10	94T6-6	-	76T7-7	89T7-7	-
75T5-7	82T5-7	91T5-23	98T5-6	80T6-12	94T6-7A	-	76T7-7A	89T7-8	-
75T5-8	82T5-8	91T5-24	98T5-7	80T6-13	94T6-9	-	76T7-8	89T7-9A	-
75T5-8A	82T5-8A	91T5-25	98T5-8	80T6-14	95T6-1	-	76T7-9	90T7-1	-
75T5-8B	82T5-9	91T5-26	98T5-9	80T6-15	95T6-2	-	77T7-1	90T7-2	-

Table 2, Archived Service Parts Topics Group 005 to 007

005 Fuel System Group	005 Fuel System Group	005 Fuel System Group	005 Fuel System Group	006 Injectors and Fuel Lines Group	006 Injectors and Fuel Lines Group	006 Injectors and Fuel Lines Group	007 Lubricating Oil System Group	007 Lubricating Oil System Group	007 Lubricating Oil System Group
75T5-8D	83T5-10	91T5-27	99T5-1	80T6-16	95T6-3	-	77T7-10	91T7-1	-
75T5-9	83T5-11	91T5-28	99T5-10	80T6-17	95T6-4	-	77T7-11	91T7-10	-
76T5-1	83T5-12	91T5-29	99T5-11	80T6-18	95T6-5	-	77T7-12A	91T7-11	-
76T5-10	83T5-2	91T5-3	99T5-12	80T6-2	95T6-6	-	77T7-13	91T7-12	-
76T5-2	83T5-3	91T5-30	99T5-13	80T6-3	95T6-7	-	77T7-14	91T7-2	-
76T5-4	83T5-4	91T5-31	99T5-14	80T6-4	95T6-8	-	77T7-15	91T7-3	-
76T5-5	83T5-5	91T5-32	99T5-15	80T6-5	95T6-9	-	77T7-16	91T7-4	-
76T5-6	83T5-6	91T5-33	99T5-16	80T6-6	96T6-1	-	77T7-2	91T7-5	-
76T5-7	83T5-7	91T5-34	99T5-17	80T6-7	96T6-10	-	77T7-3	91T7-7	-
76T5-8	83T5-9	91T5-35	99T5-18	80T6-8	96T6-11	-	77T7-4	91T7-8	-
76T5-8A	84T5-1	91T5-36	99T5-19	80T6-9	96T6-2	-	77T7-4A	91T7-9	-
76T5-9	84T5-2	91T5-4	99T5-2	81T6-2	96T6-3	-	77T7-5	92T7-1	-
77T5-1	84T5-3	91T5-5	99T5-20	81T6-5	96T6-4	-	77T7-6	92T7-2	-
77T5-10	84T5-4	91T5-6	99T5-21	82T6-1	96T6-5	-	77T7-7	92T7-3	-
77T5-10A	84T5-5	91T5-7	99T5-22	82T6-10	96T6-6	-	77T7-8	92T7-4	-
77T5-11	84T5-6	91T5-8	99T5-23	82T6-11	96T6-7	-	77T7-8A	92T7-5	-

Table 2, Archived Service Parts Topics Group 005 to 007

005 Fuel System Group	005 Fuel System Group	005 Fuel System Group	005 Fuel System Group	006 Injectors and Fuel Lines Group	006 Injectors and Fuel Lines Group	006 Injectors and Fuel Lines Group	007 Lubricating Oil System Group	007 Lubricating Oil System Group	007 Lubricating Oil System Group
77T5-13	84T5-7	91T5-9	99T5-24	82T6-12	96T6-8	-	77T7-9	92T7-6	-
77T5-14	84T5-8	92T5-1	99T5-25	82T6-2	96T6-9	-	78T7-1	92T7-7A	-
77T5-15	84T5-9	92T5-10	99T5-26	82T6-3	97T6-1	-	78T7-10	92T7-8	-
77T5-16	85T5-1	92T5-11	99T5-27	82T6-4	97T6-10	-	78T7-11	93T7-1	-
77T5-17	85T5-10	92T5-11A	99T5-28	82T6-5	97T6-1-2	-	78T7-12	93T7-2A	-
77T5-18	85T5-2	92T5-12	99T5-29	82T6-7	97T6-2	-	78T7-13A	93T7-3	-
77T5-19	85T5-3	92T5-13	99T5-3	82T6-8	97T6-4	-	78T7-14	93T7-4	-
77T5-2	85T5-3A	92T5-14	99T5-4	82T6-9	97T6-5	-	78T7-15	93T7-5	-
77T5-20	85T5-4	92T5-15	99T5-5	83T6-1	97T6-6	-	78T7-16_S1	93T7-6	-
77T5-22	85T5-5	92T5-16	99T5-6	83T6-2	97T6-7	-	78T7-16	93T7-7	-
77T5-23	85T5-6	92T5-17	99T5-7	83T6-3	97T6-8	-	78T7-17	93T7-8	-
77T5-24	85T5-7	92T5-18	99T5-7A	84T6-1	97T6-9	-	78T7-18	93T7-9	-
77T5-3	85T5-8	92T5-19	99T5-8	84T6-2	98T6-1	-	78T7-19	94T7-2	-
77T5-4A	85T5-9	92T5-2	99T5-9	84T6-3	98T6-10	-	78T7-2	94T7-3	-
77T5-6	86T5-1	92T5-20	-	84T6-4	98T6-11	-	78T7-20	94T7-5A	-
77T5-7	86T5-10	92T5-21	-	84T6-5	98T6-12	-	78T7-3	94T7-7	-

Table 2, Archived Service Parts Topics Group 005 to 007

005 Fuel System Group	005 Fuel System Group	005 Fuel System Group	005 Fuel System Group	006 Injectors and Fuel Lines Group	006 Injectors and Fuel Lines Group	006 Injectors and Fuel Lines Group	007 Lubricating Oil System Group	007 Lubricating Oil System Group	007 Lubricating Oil System Group
77T5-8	86T5-10A	92T5-22	-	84T6-6	98T6-13	-	78T7-4	95T7-1	-
77T5-9	86T5-11	92T5-23	-	85T6-1	98T6-14	-	78T7-5	95T7-10	-
78T5-10	86T5-12	92T5-24	-	85T6-2	98T6-15	-	78T7-6	95T7-3	-
78T5-10A	86T5-13	92T5-25	-	85T6-3	98T6-16	-	78T7-7	95T7-4	-
78T5-11	86T5-14	92T5-26	-	85T6-4	98T6-2	-	78T7-7A	95T7-5	-
78T5-12	86T5-15	92T5-27	-	86T6-1	98T6-4	-	78T7-8	95T7-6	-

Table 3, Archived Service Parts Topics Group 008 to 015

008 Cooling System Group	008 Cooling System Group	009 Drive Units Group	010 Air Intake System Group	010 Air Intake System Group	011 Exhaust System Group	012 Compressed Air System Group	013 Electrical Equipment Group	014 Engine Testing Group	015 Instruments and Controls Group
00T8-1	86T8-5	01T9-1	00T10-1	85T10-1	01T11-1	00T12-1	00T13-1	75T14-5	00T15-1
00T8-2	86T8-6	01T9-2	00T10-2	85T10-2	01T11-10	00T12-2	00T13-2	-	00T15-2
00T8-3	86T8-7	01T9-3	00T10-3	85T10-3	01T11-2	00T12-3	00T13-3	-	01T15-1
00T8-4	86T8-8	01T9-4	00T10-4	85T10-4	01T11-4	00T12-4	00T13-4	-	01T15-2
00T8-5	86T8-9	01T9-5	00T10-5	85T10-5	01T11-5	00T12-5	01T13-1	-	73T15-1
00T8-6	87T8-1	02T9-1	01T10-1	85T10-5A	01T11-6	73T12-1A	01T13-2	-	74T15-1

Table 3, Archived Service Parts Topics Group 008 to 015									
008 Coolin g Syste m Group	008 Coolin g Syste m Group	009 Drive Units Group	010 Air Intake Syste m Group	010 Air Intake Syste m Group	011 Exhau st Syste m Group	012 Compr essed Air Syste m Group	013 Electri cal Equip ment Group	014 Engine Testin g Group	015 Instru ments and Contro ls Group
01T8-1	87T8-10	02T9-2	01T10-2	85T10-6	01T11-7	73T12-2	01T13-4	-	76T15-1
01T8-10	87T8-11	03T9-2	01T10-3	85T10-7	01T11-8	73T12-3	73T13-1	-	78T15-1
01T8-11	87T8-12	73T9-1	01T10-4	85T10-8	01T11-9	74T12-1	73T13-2	-	80T15-1
01T8-12	87T8-13	73T9-2	01T10-5	86T10-1	02T11-1	74T12-2	73T13-3	-	83T15-1
01T8-13	87T8-2	74T9-1A	01T10-6	86T10-10	73T11-2	74T12-3	73T13-4	-	89T15-1
01T8-14	87T8-3	74T9-2_MAY	01T10-7	86T10-11	73T11-2A	74T12-3A	73T13-5	-	99T15-2
01T8-15	87T8-4	74T9-2_NOV	01T10-8	86T10-12	73T11-4	74T12-4	74T13-1	-	99T15-3
01T8-16	87T8-5	74T9-3	02T10-1	86T10-2	73T11-5	74T12-5	74T13-2	-	-
01T8-17	87T8-6	75T9-1	02T10-2	86T10-2A	73T11-6	75T12-1	74T13-3A	-	-
01T8-18	87T8-8	75T9-2A	02T10-3	86T10-3	73T11-7	75T12-2	74T13-4A	-	-
01T8-19	87T8-9	75T9-3	02T10-4	86T10-4	74T11-1	76T12-1	76T13-1	-	-
01T8-2	88T8-1	75T9-4	02T10-5	86T10-5	74T11-2	76T12-2	76T13-2	-	-
01T8-20	88T8-10	76T9-1	02T10-6	86T10-6A	74T11-3	76T12-3	76T13-3	-	-
01T8-3	88T8-11	76T9-2	02T10-7	86T10-7	75T11-1	76T12-4	77T13-1	-	-
01T8-4	88T8-16	76T9-3	02T10-8	86T10-8	75T11-2	77T12-1	78T13-1	-	-
01T8-5	88T8-17	77T9-1	03T10-1	86T10-9	75T11-3	77T12-10	78T13-2	-	-

Table 3, Archived Service Parts Topics Group 008 to 015									
008 Coolin g Syste m Group	008 Coolin g Syste m Group	009 Drive Units Group	010 Air Intake Syste m Group	010 Air Intake Syste m Group	011 Exhau st Syste m Group	012 Compr essed Air Syste m Group	013 Electri cal Equip ment Group	014 Engine Testin g Group	015 Instru ments and Contro ls Group
01T8-6	88T8-18	77T9-2	03T10-10	87T10-1	75T11-4	77T12-11	79T13-1	-	-
01T8-7	88T8-19	78T9-1	03T10-11	87T10-10	76T11-1	77T12-2	80T13-1	-	-
01T8-8	88T8-2	78T9-2	03T10-12	87T10-2	77T11-	77T12-3	81T13-1	-	-
01T8-9	88T8-20	79T9-1	03T10-13	87T10-3	77T11-1	77T12-4	81T13-2	-	-
02T8-1	88T8-21	79T9-2	03T10-14	87T10-4	77T11-3	77T12-5	82T13-1	-	-
02T8-2	88T8-22	79T9-3	03T10-15	87T10-5	77T11-4	77T12-7	83T13-1	-	-
02T8-3	88T8-23	80T9-1	03T10-2	87T10-6	77T11-5	77T12-8	83T13-2	-	-
02T8-4	88T8-25	80T9-2	03T10-3	87T10-7	78T11-1	77T12-9	86T13-1	-	-
02T8-5	88T8-3	80T9-3	03T10-4	87T10-8	79T11-1	78T12-1	86T13-2	-	-
02T8-6	88T8-4	81T9-1	03T10-5	87T10-9	79T11-2	78T12-2	88T13-1	-	-
02T8-7	88T8-5	81T9-2	03T10-6	88T10-1	80T11-1	79T12-1	88T13-2	-	-
02T8-8	88T8-6	81T9-3	03T10-7	88T10-2	80T11-2	79T12-2	89T13-1	-	-
03T8-1	88T8-7	82T9-1	03T10-8	88T10-3	81T11-1	79T12-3	90T13-1	-	-
03T8-10	88T8-8	82T9-2	03T10-9	88T10-3A	81T11-2	79T12-4	91T13-1	-	-
03T8-11	88T8-9	84T9-1	04T10-1	88T10-4	81T11-3	80T12-1	91T13-2	-	-
03T8-12	89T8-1	84T9-2	04T10-10	88T10-5	81T11-4	80T12-2	92T13-1	-	-

Table 3, Archived Service Parts Topics Group 008 to 015									
008 Coolin g Syste m Group	008 Coolin g Syste m Group	009 Drive Units Group	010 Air Intake Syste m Group	010 Air Intake Syste m Group	011 Exhau st Syste m Group	012 Compr essed Air Syste m Group	013 Electri cal Equip ment Group	014 Engine Testin g Group	015 Instru ments and Contro ls Group
03T8- 2	89T8- 11	85T9- 1	04T10 -11	88T10 -6	82T11 -1	80T12 -3	92T13 -2	-	-
03T8- 3	89T8- 12	86T9- 1	04T10 -13	88T10 -7	82T11 -2	80T12 -4	93T13 -1A	-	-
03T8- 4	89T8- 2	86T9- 2	04T10 -2	88T10 -9	82T11 -3	80T12 -5	93T13 -2	-	-
03T8- 5	89T8- 3	86T9- 3	04T10 -7	89T10 -1	82T11 -4	81T12 -1	93T13 -3	-	-
03T8- 6	89T8- 4	87T9- 1	04T10 -8	89T10 -2	83T11 -1	81T12 -1A	94T13 -1	-	-
03T8- 8	89T8- 5	89T9- 1	04T10 -9	89T10 -3	83T11 -2	82T12 -1	94T13 -2	-	-
03T8- 9	89T8- 6	89T9- 2	73T10 -13S2	89T10 -4	83T11 -3	82T12 -2	95T13 -1	-	-
73T8- 21	89T8- 7	90T9- 1	74T10 -1	89T10 -5	83T11 -4	84T12 -1	96T13 -1	-	-
73T8- 5	89T8- 8	91T9- 1A	74T10 -2	90T10 -1	85T11 -1	85T12 -1	96T13 -3	-	-
73T8- 7	89T8- 9	93T9- 1	74T10 -5	90T10 -2	86T11 -1	85T12 -2	96T13 -4	-	-
73T8- 9	90T8- 1	94T9- 1	74T10 -6	90T10 -3	86T11 -2	86T12 -1	97T13 -1	-	-
74T8- 1	90T8- 3	94T9- 2	75T10 -1	90T10 -4	86T11 -2A	86T12 -2A	97T13 -2	-	-
74T8- 11	90T8- 4	94T9- 3	75T10 -10	90T10 -5	86T11 -3	87T12 -1	97T13 -3	-	-
74T8- 12	90T8- 5	97T9- 1	75T10 -2	90T10 -6	86T11 -4	88T12 -1	98T13 -2	-	-
74T8- 16	90T8- 6	98T9- 1	75T10 -3	90T10 -7	87T11 -1	88T12 -2	98T13 -3	-	-
74T8- 17	90T8- 7	99T9- 1	75T10 -4	91T10 -1a	87T11 -2	88T12 -3	99T13 -1	-	-

Table 3, Archived Service Parts Topics Group 008 to 015									
008 Coolin g Syste m Group	008 Coolin g Syste m Group	009 Drive Units Group	010 Air Intake Syste m Group	010 Air Intake Syste m Group	011 Exhau st Syste m Group	012 Compr essed Air Syste m Group	013 Electri cal Equip ment Group	014 Engine Testin g Group	015 Instru ments and Contro ls Group
74T8-18	90T8-8	99T9-2	75T10-6	91T10-2	88T11-1	88T12-4	99T13-2	-	-
74T8-19	90T8-9	99T9-3	75T10-7	91T10-3	88T11-2	88T12-4A	99T13-3	-	-
74T8-2	91T8-1	-	75T10-8	92T10-1	88T11-3	88T12-5	99T13-4	-	-
74T8-4	91T8-2	-	75T10-9	92T10-2	88T11-4	90T12-1	-	-	-
74T8-6A	91T8-3	-	76T10-10	92T10-3	90T11-1	90T12-2	-	-	-
74T8-9	91T8-4	-	76T10-11	92T10-4	90T11-2	90T12-3	-	-	-
75T8-13	91T8-5	-	76T10-12	92T10-5	90T11-3	90T12-4	-	-	-
75T8-14	92T8-1	-	76T10-1A	92T10-6	90T11-4	90T12-5A	-	-	-
75T8-15	92T8-2	-	76T10-2	93T10-1	91T11-1	92T12-1	-	-	-
75T8-17	92T8-3	-	76T10-3	93T10-2	91T11-2	93T12-1	-	-	-
75T8-20	92T8-4	-	76T10-4	93T10-3	91T11-3	93T12-2	-	-	-
75T8-21	92T8-5	-	76T10-5	93T10-4	91T11-4	93T12-3	-	-	-
75T8-4	92T8-6	-	76T10-6	93T10-5	93T11-1	94T12-1	-	-	-
75T8-5	92T8-7	-	76T10-7	93T10-6	93T11-2	94T12-4	-	-	-
75T8-7	92T8-8	-	76T10-7A	93T10-7	93T11-3	95T12-1	-	-	-
75T8-8	92T8-9	-	76T10-8	94T10-1	94T11-1	95T12-2	-	-	-

Table 3, Archived Service Parts Topics Group 008 to 015									
008 Coolin g Syste m Group	008 Coolin g Syste m Group	009 Drive Units Group	010 Air Intake Syste m Group	010 Air Intake Syste m Group	011 Exhau st Syste m Group	012 Compr essed Air Syste m Group	013 Electri cal Equip ment Group	014 Engine Testin g Group	015 Instru ments and Contro ls Group
76T8-1	93T8-1	-	76T10-9	94T10-2	94T11-2	96T12-1	-	-	-
76T8-10	93T8-10	-	77T10-1	94T10-3	94T11-3	96T12-2	-	-	-
76T8-11	93T8-11	-	77T10-2	94T10-4	94T11-4	96T12-3	-	-	-
76T8-12	93T8-12	-	77T10-3	94T10-5	94T11-5	96T12-4	-	-	-
76T8-14	93T8-2	-	77T10-4	94T10-6	94T11-6	99T12-1	-	-	-
76T8-15	93T8-3	-	77T10-5	94T10-7	95T11-1	99T12-2	-	-	-
76T8-17	93T8-4A	-	77T10-6	95T10-1	95T11-2_S1	99T12-3	-	-	-
76T8-18	93T8-5	-	78T10-1	95T10-2	96T11-1	99T12-4	-	-	-
76T8-3_S1A	93T8-7A	-	78T10-3	95T10-3	96T11-3A	99T12-5	-	-	-
76T8-3	93T8-8	-	78T10-4	95T10-4	97T11-1	99T12-6	-	-	-
76T8-4A	93T8-9	-	78T10-5	95T10-5	97T11-2	99T12-7	-	-	-
76T8-5	94T8-1	-	78T10-7	95T10-6	97T11-3	-	-	-	-
76T8-8	94T8-2	-	79T10-1	96T10-1	97T11-4	-	-	-	-
76T8-9_S1	94T8-3	-	79T10-10	96T10-2	97T11-5	-	-	-	-
77T8-11	95T8-1	-	79T10-11	96T10-3	97T11-6	-	-	-	-
77T8-20	95T8-2	-	79T10-12	96T10-4A	99811-1	-	-	-	-

Table 3, Archived Service Parts Topics Group 008 to 015

008 Coolin g Syste m Group	008 Coolin g Syste m Group	009 Drive Units Group	010 Air Intake Syste m Group	010 Air Intake Syste m Group	011 Exhau st Syste m Group	012 Compr essed Air Syste m Group	013 Electri cal Equip ment Group	014 Engine Testin g Group	015 Instru ments and Contro ls Group
77T8-21	95T8-3	-	79T10-13	96T10-4B	99811-2	-	-	-	-
77T8-24	95T8-4	-	79T10-2	96T10-5	99811-3	-	-	-	-
77T8-25	96T8-2	-	79T10-3	97T10-1	99811-4	-	-	-	-
77T8-4	96T8-3	-	79T10-4	97T10-1A	99811-5	-	-	-	-
77T8-5	97T8-1	-	79T10-5	97T10-2	99T11-1	-	-	-	-
77T8-7	97T8-2	-	79T10-6	97T10-3	99T11-2	-	-	-	-
77T8-9	97T8-3	-	79T10-7	97T10-4	99T11-3	-	-	-	-
78T8-1	97T8-4	-	79T10-8	97T10-5	-	-	-	-	-
78T8-10	97T8-5	-	79T10-9	97T10-6	-	-	-	-	-
78T8-12	97T8-6	-	80T10-1	97T10-7	-	-	-	-	-
78T8-13	97T8-7	-	80T10-10	97T10-8	-	-	-	-	-
78T8-15	97T8-8	-	80T10-11	98T10-1	-	-	-	-	-
78T8-16	98T8-1	-	80T10-2	98T10-2	-	-	-	-	-
78T8-3_S1	98T8-11	-	80T10-3	98T10-3	-	-	-	-	-
78T8-6	98T8-12	-	80T10-4	98T10-4	-	-	-	-	-
79T8-11	98T8-13	-	80T10-6	98T10-5	-	-	-	-	-

Table 3, Archived Service Parts Topics Group 008 to 015

008 Coolin g Syste m Group	008 Coolin g Syste m Group	009 Drive Units Group	010 Air Intake Syste m Group	010 Air Intake Syste m Group	011 Exhau st Syste m Group	012 Compr essed Air Syste m Group	013 Electri cal Equip ment Group	014 Engine Testin g Group	015 Instru ments and Contro ls Group
79T8-12	98T8-14	-	80T10-7	99T10-1	-	-	-	-	-
79T8-13	98T8-15	-	80T10-8	99T10-2	-	-	-	-	-
79T8-2	98T8-16	-	80T10-9	99T10-3	-	-	-	-	-
79T8-3	98T8-17	-	81T10-1	99T10-4	-	-	-	-	-
79T8-4	98T8-18	-	81T10-10	-	-	-	-	-	-
79T8-6	98T8-3	-	81T10-11	-	-	-	-	-	-
79T8-8	98T8-7	-	81T10-13	-	-	-	-	-	-
80T8-10	98T8-8	-	81T10-2	-	-	-	-	-	-
80T8-15	98T8-9	-	81T10-3_S1	-	-	-	-	-	-
80T8-16	99T8-1	-	81T10-3	-	-	-	-	-	-
81T8-4	99T8-10	-	81T10-4	-	-	-	-	-	-
81T8-7	99T8-11	-	81T10-5	-	-	-	-	-	-
81T8-8	99T8-12	-	81T10-6	-	-	-	-	-	-
82T8-11	99T8-13	-	81T10-7	-	-	-	-	-	-
82T8-12	99T8-14	-	81T10-8	-	-	-	-	-	-
82T8-13	99T8-15	-	81T10-9	-	-	-	-	-	-

Table 3, Archived Service Parts Topics Group 008 to 015

008 Coolin g Syste m Group	008 Coolin g Syste m Group	009 Drive Units Group	010 Air Intake Syste m Group	010 Air Intake Syste m Group	011 Exhau st Syste m Group	012 Compr essed Air Syste m Group	013 Electri cal Equip ment Group	014 Engine Testin g Group	015 Instru ments and Contro ls Group
82T8-14	99T8-2	-	82T10-1	-	-	-	-	-	-
82T8-4A	99T8-3	-	82T10-10	-	-	-	-	-	-
83T8-1	99T8-4	-	82T10-11	-	-	-	-	-	-
83T8-4	99T8-5	-	82T10-12	-	-	-	-	-	-
84T8-10	99T8-6	-	82T10-13	-	-	-	-	-	-
84T8-11	99T8-7	-	82T10-14	-	-	-	-	-	-
84T8-12	99T8-8	-	82T10-15	-	-	-	-	-	-
84T8-13	99T8-9	-	82T10-16	-	-	-	-	-	-
84T8-14	-	-	82T10-17	-	-	-	-	-	-
84T8-6	-	-	82T10-18	-	-	-	-	-	-
84T8-7	-	-	82T10-2	-	-	-	-	-	-
84T8-8	-	-	82T10-3	-	-	-	-	-	-
84T8-9	-	-	82T10-4A	-	-	-	-	-	-
85T8-1	-	-	82T10-5	-	-	-	-	-	-
85T8-10	-	-	82T10-6	-	-	-	-	-	-
85T8-2	-	-	82T10-7	-	-	-	-	-	-

Table 3, Archived Service Parts Topics Group 008 to 015									
008 Cooling System Group	008 Cooling System Group	009 Drive Units Group	010 Air Intake System Group	010 Air Intake System Group	011 Exhaust System Group	012 Compressed Air System Group	013 Electrical Equipment Group	014 Engine Testing Group	015 Instruments and Controls Group
85T8-3	-	-	82T10-8	-	-	-	-	-	-
85T8-4	-	-	82T10-9	-	-	-	-	-	-
85T8-5	-	-	83T10-1	-	-	-	-	-	-
85T8-5A	-	-	83T10-2A	-	-	-	-	-	-
85T8-6	-	-	83T10-3	-	-	-	-	-	-
85T8-8	-	-	83T10-4	-	-	-	-	-	-
85T8-9	-	-	83T10-5A	-	-	-	-	-	-
86T8-1	-	-	83T10-6	-	-	-	-	-	-
86T8-10	-	-	84T10-1	-	-	-	-	-	-
86T8-11	-	-	84T10-2	-	-	-	-	-	-
86T8-12	-	-	84T10-3	-	-	-	-	-	-
86T8-13	-	-	84T10-4	-	-	-	-	-	-
86T8-14	-	-	84T10-5	-	-	-	-	-	-
86T8-2	-	-	84T10-6	-	-	-	-	-	-
86T8-3	-	-	84T10-7	-	-	-	-	-	-
86T8-4	-	-	84T10-8	-	-	-	-	-	-

Table 4, Archived Service Parts Topics Group 016 to 023

016 Mount ing Adapt ations Group	017 Miscel laneou s Group	018 Specif ication s Group	019 Electr onic Contro ls Group	019 Electr onic Contro ls Group	020 Vehicl e Brakin g Group	021 Main Power Gener ator Group	022 Servic e Tools and Hardw are Group	022 Servic e Tools and Hardw are Group	023 Inform ation Produ cts Group
00T16 -1	73T17 -1	73T18 -1	00T19 -1	97T19 -15	73T20 -1_S1	73T21 -1	00T22 -1	80T22 -16	99T23 -1
00T16 -4	74T17 -1	73T18 -2A	00T19 -10	97T19 -16	73T20 -1	74T21 -1	00T22 -2	80T22 -17	-
01T16 -1	74T17 -2	73T18 -3A	00T19 -11	97T19 -17	74T20 -1	74T21 -2	00T22 -3	80T22 -18	-
73T16 -1	75T17 -1	73T18 -4	00T19 -12	97T19 -18	75T20 -1_S1	74T21 -3	01T22 -1	80T22 -19	-
73T16 -10	75T17 -2	73T18 -5	00T19 -13	97T19 -1A	75T20 -1	74T21 -4	02T22 -1	80T22 -20	-
73T16 -2	75T17 -3	73T18 -6	00T19 -14	97T19 -2	76T20 -1	76T21 -1A	73T22 -1	80T22 -21	-
73T16 -3_S1	76T17 -1	74T18 -1	00T19 -15	97T19 -3	76T20 -2	76T21 -2A	73T22 -10	80T22 -22	-
73T16 -3	76T17 -2	75T18 -1	00T19 -16	97T19 -4	76T20 -3	79T21 -1	73T22 -11	80T22 -23	-
73T16 -4	76T17 -3	75T18 -3A	00T19 -17	97T19 -5	76T20 -4	81T21 -1	73T22 -12	80T22 -24	-
73T16 -5	76T17 -4	76T18 -2	00T19 -18	97T19 -6	77T20 -1	82T21 -1	73T22 -13	80T22 -25	-
73T16 -6	76T17 -4A	77T18 -1	00T19 -2	97T19 -7	77T20 -2	82T21 -2	73T22 -14	80T22 -3	-
73T16 -7	76T17 -5	78T18 -1A	00T19 -20	97T19 -8	77T20 -3	91T21 -1	73T22 -2	80T22 -4	-
73T16 -8	76T17 -6	79T18 -1	00T19 -21	97T19 -9	78T20 -1	-	73T22 -3	80T22 -6	-
73T16 -9	77T17 -1	79T18 -2	00T19 -22	98T19 -1	78T20 -2	-	73T22 -4	80T22 -7	-
74T16 -1	77T17 -2	80T18 -1	00T19 -23	98T19 -2	78T20 -3	-	73T22 -5	80T22 -8	-

Table 4, Archived Service Parts Topics Group 016 to 023

016 Mount ing Adapt ations Group	017 Miscel laneou s Group	018 Specif ication s Group	019 Electr onic Contro ls Group	019 Electr onic Contro ls Group	020 Vehicl e Brakin g Group	021 Main Power Gener ator Group	022 Servic e Tools and Hardw are Group	022 Servic e Tools and Hardw are Group	023 Inform ation Produ cts Group
74T16 -10	77T17 -3	80T18 -2	00T19 -24	98T19 -26	78T20 -4	-	73T22 -6	80T22 -9	-
74T16 -11	77T17 -4	80T18 -3	00T19 -25	98T19 -27	78T20 -5	-	73T22 -7	81T22 -1	-
74T16 -12	77T17 -5	80T18 -4	00T19 -26	98T19 -28	79T20 -1	-	73T22 -8	81T22 -10	-
74T16 -13	77T17 -6	80T18 -5	00T19 -27	98T19 -29	79T20 -2	-	73T22 -9	81T22 -11	-
74T16 -2	77T17 -7	80T18 -6	00T19 -28	98T19 -3	79T20 -3	-	74T22 -1	81T22 -12	-
74T16 -3	78T17 -2	80T18 -7	00T19 -29	98T19 -30	80T20 -1	-	74T22 -10	81T22 -14	-
74T16 -4_S1	78T17 -3	81T18 -1	00T19 -3	98T19 -32	82T20 -1	-	74T22 -11	81T22 -15	-
74T16 -4	78T17 -4	82T18 -1	00T19 -30	98T19 -33	83T20 -1	-	74T22 -12	81T22 -16	-
74T16 -5	78T17 -5	83T18 -1	00T19 -31	98T19 -34	83T20 -2	-	74T22 -13	81T22 -2	-
74T16 -6	79T17 -7	83T18 -2	00T19 -32	98T19 -35	83T20 -3	-	74T22 -14A	81T22 -3	-
74T16 -7	80T17 -1	83T18 -3	00T19 -33	98T19 -36	83T20 -4	-	74T22 -15_S1	81T22 -5	-
74T16 -8	80T17 -2_S1	83T18 -4	00T19 -34	98T19 -37	84T20 -1	-	74T22 -15	81T22 -6	-
74T16 -9	80T17 -2_S2	83T18 -6	00T19 -35	98T19 -38	85T20 -1	-	74T22 -16	81T22 -7	-
75T16 -1	80T17 -2	84T18 -1	00T19 -36	98T19 -39	85T20 -2	-	74T22 -17	81T22 -8	-
75T16 -2A	80T17 -3	-	00T19 -37	98T19 -4	86T20 -2	-	74T22 -18	81T22 -9	-
75T16 -3	82T17 -1	-	00T19 -38	98T19 -40	87T20 -1	-	74T22 -19	83T22 -1	-

Table 4, Archived Service Parts Topics Group 016 to 023

016 Mount ing Adapt ations Group	017 Miscel laneou s Group	018 Specif ication s Group	019 Electr onic Contro ls Group	019 Electr onic Contro ls Group	020 Vehicl e Brakin g Group	021 Main Power Gener ator Group	022 Servic e Tools and Hardw are Group	022 Servic e Tools and Hardw are Group	023 Inform ation Produ cts Group
75T16 -4	84T17 -1	-	00T19 -39	98T19 -41	87T20 -4	-	74T22 -2	83T22 -2	-
75T16 -5	84T17 -2	-	00T19 -4	98T19 -42	88T20 -1	-	74T22 -20	84T22 -1	-
75T16 -6	84T17 -4	-	00T19 -40	98T19 -44	88T20 -2	-	74T22 -21	84T22 -2	-
76T16 -1	84T17 -5	-	00T19 -41	98T19 -45	88T20 -3	-	74T22 -22	84T22 -3	-
76T16 -2	84T17 -6	-	00T19 -42	98T19 -46	88T20 -4	-	74T22 -23	87T22 -1	-
76T16 -3	85T17 -1	-	00T19 -43	98T19 -47	88T20 -5	-	74T22 -24	87T22 -2	-
76T16 -4	85T17 -1A	-	00T19 -44	98T19 -5	89T20 -1	-	74T22 -25_S1	87T22 -3	-
76T16 -5	85T17 -2	-	00T19 -45	98T19 -6	89T20 -2	-	74T22 -25	87T22 -4	-
76T16 -6	85T17 -3	-	00T19 -46	99T19 -1	89T20 -3	-	74T22 -3	87T22 -5	-
76T16 -7	85T17 -4	-	00T19 -47	99T19 -10	90T20 -1	-	74T22 -4	87T22 -6	-
76T16 -8	86T17 -1	-	00T19 -48	99T19 -2	90T20 -2	-	74T22 -5	88T22 -1	-
76T16 -9	87T17 -1	-	00T19 -49	99T19 -21	91T20 -1	-	74T22 -6	88T22 -2	-
77T16 -1	87T17 -2	-	00T19 -5	99T19 -22A	91T20 -2	-	74T22 -7	88T22 -3	-
77T16 -2	88T17 -1	-	00T19 -50	99T19 -3	91T20 -3A	-	74T22 -8	88T22 -4	-
77T16 -3	94T17 -1	-	00T19 -51	99T19 -4	92T20 -1A	-	74T22 -9	88T22 -7	-
77T16 -4	99T17 -1	-	00T19 -52	99T19 -5	93T20 -1	-	75T22 -1	89T22 -1	-

Table 4, Archived Service Parts Topics Group 016 to 023

016 Mount ing Adapt ations Group	017 Miscel laneou s Group	018 Specif ication s Group	019 Electr onic Contro ls Group	019 Electr onic Contro ls Group	020 Vehicl e Brakin g Group	021 Main Power Gener ator Group	022 Servic e Tools and Hardw are Group	022 Servic e Tools and Hardw are Group	023 Inform ation Produ cts Group
77T16 -5	-	-	00T19 -6	99T19 -6A	95T20 -1	-	75T22 -10	89T22 -10	-
77T16 -6	-	-	00T19 -7	99T19 -7	96T20 -1	-	75T22 -11	89T22 -11	-
77T16 -7	-	-	00T19 -8	99T19 -8	96T20 -2	-	75T22 -12	89T22 -12	-
77T16 -8	-	-	00T19 -9	99T19 -9	98T20 -1	-	75T22 -14	89T22 -13	-
78T16 -1	-	-	01T19 -1	-	99T20 -1	-	75T22 -15	89T22 -14	-
78T16 -2	-	-	01T19 -10	-	-	-	75T22 -16	89T22 -15	-
78T16 -3	-	-	01T19 -11	-	-	-	75T22 -17	89T22 -16	-
79T16 -1	-	-	01T19 -12	-	-	-	75T22 -18	89T22 -17	-
79T16 -2	-	-	01T19 -13	-	-	-	75T22 -19	89T22 -19	-
79T16 -3	-	-	01T19 -14	-	-	-	75T22 -2	89T22 -2	-
79T16 -4	-	-	01T19 -15	-	-	-	75T22 -4A	89T22 -3	-
80T16 -1	-	-	01T19 -16	-	-	-	75T22 -5	89T22 -4	-
80T16 -2	-	-	01T19 -17	-	-	-	75T22 -6	89T22 -5	-
80T16 -3	-	-	01T19 -18	-	-	-	75T22 -7	89T22 -6	-
80T16 -4	-	-	01T19 -19	-	-	-	75T22 -8	89T22 -7	-
81T16 -1	-	-	01T19 -2	-	-	-	75T22 -9	89T22 -8	-

Table 4, Archived Service Parts Topics Group 016 to 023

016 Mount ing Adapt ations Group	017 Miscel laneou s Group	018 Specif ication s Group	019 Electr onic Contro ls Group	019 Electr onic Contro ls Group	020 Vehicl e Brakin g Group	021 Main Power Gener ator Group	022 Servic e Tools and Hardw are Group	022 Servic e Tools and Hardw are Group	023 Inform ation Produ cts Group
81T16 -2	-	-	01T19 -20	-	-	-	76T22 -10	89T22 -9	-
81T16 -3	-	-	01T19 -21	-	-	-	76T22 -11	90T22 -1	-
81T16 -4	-	-	01T19 -22	-	-	-	76T22 -2	90T22 -10	-
81T16 -5	-	-	01T19 -23	-	-	-	76T22 -3	90T22 -11	-
81T16 -6	-	-	01T19 -24	-	-	-	76T22 -4A	90T22 -12	-
82T16 -1	-	-	01T19 -25	-	-	-	76T22 -5	90T22 -13	-
82T16 -2	-	-	01T19 -26	-	-	-	76T22 -6	90T22 -14	-
82T16 -3	-	-	01T19 -28	-	-	-	76T22 -7	90T22 -15	-
82T16 -4	-	-	01T19 -29	-	-	-	76T22 -8	90T22 -16	-
82T16 -5	-	-	01T19 -3	-	-	-	76T22 -9	90T22 -17	-
82T16 -6	-	-	01T19 -30	-	-	-	77T22 -13	90T22 -18	-
82T16 -7	-	-	01T19 -31	-	-	-	77T22 -14	90T22 -19	-
83T16 -1	-	-	01T19 -32	-	-	-	77T22 -15	90T22 -2	-
83T16 -3	-	-	01T19 -33	-	-	-	77T22 -16	90T22 -20	-
84T16 -1	-	-	01T19 -4	-	-	-	77T22 -17	90T22 -21	-
84T16 -2	-	-	01T19 -5	-	-	-	77T22 -18	90T22 -22	-

Table 4, Archived Service Parts Topics Group 016 to 023

016 Mount ing Adapt ations Group	017 Miscel laneou s Group	018 Specif ication s Group	019 Electr onic Contro ls Group	019 Electr onic Contro ls Group	020 Vehicl e Brakin g Group	021 Main Power Gener ator Group	022 Servic e Tools and Hardw are Group	022 Servic e Tools and Hardw are Group	023 Inform ation Produ cts Group
85T16 -1	-	-	01T19 -6	-	-	-	77T22 -18A	90T22 -23	-
87T16 -1	-	-	01T19 -7	-	-	-	77T22 -19	90T22 -24	-
87T16 -2	-	-	01T19 -8	-	-	-	77T22 -20	90T22 -25	-
88T16 -1	-	-	01T19 -9	-	-	-	77T22 -21	90T22 -26	-
88T16 -10	-	-	02T19 -1	-	-	-	77T22 -23	90T22 -27	-
88T16 -2	-	-	02T19 -2	-	-	-	77T22 -24	90T22 -28	-
88T16 -3	-	-	02T19 -3	-	-	-	77T22 -25	90T22 -29	-
88T16 -4	-	-	02T19 -4	-	-	-	77T22 -26	90T22 -3	-
88T16 -5	-	-	02T19 -5	-	-	-	77T22 -27_S1	90T22 -30	-
88T16 -6	-	-	80T19 -1	-	-	-	77T22 -27	90T22 -31	-
88T16 -7	-	-	81T19 -1	-	-	-	77T22 -28	90T22 -32	-
88T16 -8	-	-	93T19 -1	-	-	-	77T22 -29	90T22 -33	-
89T16 -1	-	-	93T19 -2	-	-	-	77T22 -3	90T22 -4	-
89T16 -2	-	-	93T19 -3	-	-	-	77T22 -30	90T22 -5	-
90T16 -1	-	-	93T19 -4	-	-	-	77T22 -31	90T22 -6	-
90T16 -2	-	-	94T19 -1	-	-	-	77T22 -32	90T22 -7	-

Table 4, Archived Service Parts Topics Group 016 to 023

016 Mount ing Adapt ations Group	017 Miscel laneou s Group	018 Specif ication s Group	019 Electr onic Contro ls Group	019 Electr onic Contro ls Group	020 Vehicl e Brakin g Group	021 Main Power Gener ator Group	022 Servic e Tools and Hardw are Group	022 Servic e Tools and Hardw are Group	023 Inform ation Produ cts Group
91T16 -1	-	-	94T19 -10	-	-	-	77T22 -4	90T22 -8	-
91T16 -2	-	-	94T19 -13	-	-	-	77T22 -5	90T22 -9	-
92T16 -1A	-	-	94T19 -14	-	-	-	77T22 -7	91T22 -1	-
92T16 -2	-	-	94T19 -15	-	-	-	77T22 -9	91T22 -10	-
94T16 -1	-	-	94T19 -16	-	-	-	78T22 -1	91T22 -11	-
94T16 -2	-	-	94T19 -2	-	-	-	78T22 -10	91T22 -12	-
95T16 -1	-	-	94T19 -3	-	-	-	78T22 -11	91T22 -13	-
95T16 -2	-	-	94T19 -4	-	-	-	78T22 -13	91T22 -14	-
95T16 -3	-	-	94T19 -5	-	-	-	78T22 -14	91T22 -2	-
97T16 -1	-	-	94T19 -6	-	-	-	78T22 -2_S1	91T22 -3	-
99T16 -1	-	-	94T19 -7	-	-	-	78T22 -2	91T22 -4	-
-	-	-	94T19 -8	-	-	-	78T22 -3	91T22 -5	-
-	-	-	94T19 -9	-	-	-	78T22 -4	91T22 -6	-
-	-	-	95T19 -1	-	-	-	78T22 -5	91T22 -7	-
-	-	-	95T19 -10	-	-	-	78T22 -6	91T22 -8	-
-	-	-	95T19 -11	-	-	-	78T22 -7	91T22 -9	-

Table 4, Archived Service Parts Topics Group 016 to 023

016 Mount ing Adapt ations Group	017 Miscel laneou s Group	018 Specif ication s Group	019 Electr onic Contro ls Group	019 Electr onic Contro ls Group	020 Vehicl e Brakin g Group	021 Main Power Gener ator Group	022 Servic e Tools and Hardw are Group	022 Servic e Tools and Hardw are Group	023 Inform ation Produ cts Group
-	-	-	95T19 -12A	-	-	-	78T22 -8	92T22 -1	-
-	-	-	95T19 -13	-	-	-	78T22 -9	92T22 -2	-
-	-	-	95T19 -14	-	-	-	79T22 -1	92T22 -3	-
-	-	-	95T19 -15A	-	-	-	79T22 -10	92T22 -4	-
-	-	-	95T19 -16	-	-	-	79T22 -11	92T22 -5	-
-	-	-	95T19 -17	-	-	-	79T22 -12	92T22 -6	-
-	-	-	95T19 -18	-	-	-	79T22 -13	93T22 -1	-
-	-	-	95T19 -19	-	-	-	79T22 -14	93T22 -2	-
-	-	-	95T19 -2	-	-	-	79T22 -15	93T22 -3	-
-	-	-	95T19 -20	-	-	-	79T22 -16	93T22 -4	-
-	-	-	95T19 -21	-	-	-	79T22 -17	94T22 -1	-
-	-	-	95T19 -22	-	-	-	79T22 -18	94T22 -2	-
-	-	-	95T19 -23	-	-	-	79T22 -19	95T22 -1A	-
-	-	-	95T19 -24	-	-	-	79T22 -2	95T22 -2	-
-	-	-	95T19 -4	-	-	-	79T22 -20	95T22 -3	-
-	-	-	95T19 -5	-	-	-	79T22 -21	96T22 -1	-

Table 4, Archived Service Parts Topics Group 016 to 023

016 Mount ing Adapt ations Group	017 Miscel laneou s Group	018 Specif ication s Group	019 Electr onic Contro ls Group	019 Electr onic Contro ls Group	020 Vehicl e Brakin g Group	021 Main Power Gener ator Group	022 Servic e Tools and Hardw are Group	022 Servic e Tools and Hardw are Group	023 Inform ation Produ cts Group
-	-	-	95T19 -6	-	-	-	79T22 -22	96T22 -2	-
-	-	-	95T19 -7	-	-	-	79T22 -23	97T22 -1	-
-	-	-	95T19 -8	-	-	-	79T22 -24_De cembe r	97T22 -2	-
-	-	-	95T19 -9	-	-	-	79T22 -24_Se ptemb er	-	-
-	-	-	96T19 -13	-	-	-	79T22 -25	-	-
-	-	-	96T19 -16	-	-	-	79T22 -26	-	-
-	-	-	96T19 -17	-	-	-	79T22 -27	-	-
-	-	-	96T19 -18	-	-	-	79T22 -28	-	-
-	-	-	96T19 -19	-	-	-	79T22 -3	-	-
-	-	-	96T19 -1A	-	-	-	79T22 -30	-	-
-	-	-	96T19 -2	-	-	-	79T22 -31	-	-
-	-	-	96T19 -20	-	-	-	79T22 -32	-	-
-	-	-	96T19 -3	-	-	-	79T22 -33	-	-
-	-	-	96T19 -4	-	-	-	79T22 -4	-	-

Table 4, Archived Service Parts Topics Group 016 to 023									
016 Mount ing Adapt ations Group	017 Miscel laneou s Group	018 Specif ication s Group	019 Electr onic Contro ls Group	019 Electr onic Contro ls Group	020 Vehicl e Brakin g Group	021 Main Power Gener ator Group	022 Servic e Tools and Hardw are Group	022 Servic e Tools and Hardw are Group	023 Inform ation Produ cts Group
-	-	-	96T19 -5	-	-	-	79T22 -5	-	-
-	-	-	96T19 -6	-	-	-	79T22 -6	-	-
-	-	-	96T19 -7	-	-	-	79T22 -7A	-	-
-	-	-	96T19 -8	-	-	-	79T22 -8	-	-
-	-	-	97T19 -10	-	-	-	79T22 -9	-	-
-	-	-	97T19 -11	-	-	-	80T22 -1	-	-
-	-	-	97T19 -12	-	-	-	80T22 -11	-	-
-	-	-	97T19 -13	-	-	-	80T22 -14	-	-
-	-	-	97T19 -14	-	-	-	80T22 -15	-	-

Document History

Date	Details
2017-3-22	Module Created
2017-3-31	Updated Link to SPT Archive
2019-11-11	Non-Product Problem Solving (PPS)

