

User Guide

Zuper - Library Climate Control IoT System

Students

Amahdya Delkescamp - 256523

Andrei Cioanca - 266105

Claudiu Rediu - 266129

Dominika Kubicz - 266148

Flemming Vindelev - 251398

Michal Ciebien - 266908

Mihail Kanchev - 266106

Nikita Roskovs - 266900

Stefan Harabagiu - 266116

Supervisors

Kasper Knop Rasmussen

Knud Erik Rasmussen

Erland Ketil Larsen



Table of Contents

Table of Contents	1
Introduction	2
View Readings	3
Settings	5
Logging in	6
Open window	7






Introduction


The purpose of this document is to describe the usage of Climatizer app. It describes in simple steps how to properly use the app and how to use the basic features of the system.



View Readings

 Once the app is opened it will display the last temperature reading. Below the last reading there is scrollable bar with all readings from specific day (from current day by default)







 To switch between views and view other readings (humidity, CO2 level, light level) swipe to the left/right or press the specific tab you want to view



- 3. Press button showing the date in order to choose specific date to see the readings from.
 - Choose the date and press OK to validate choice. App will show all the reading from specific date selected if there were any







 Press refresh button in order to receive the latest readings. If the app has just been launched, it will get latest readings automatically



Settings

- 1. In order to change units, go to setting menu and choose 'Settings'
- 2. Check/uncheck the checkbox in order to have the temperature showed in Celsius/Fahrenheits. Press 'set' to validate your choice










Logging in

- 1. In order to login as Admin, go to settings menu and press 'Account'
- 2. Enter email and password and press 'Sign In' to validate your choice
- 3. Once you have logged in successfully you will see text displayed that you are logged in and the email you are logged in with.









Open window

- Once you have logged in, 'use window' button will appear (this button is accessible for logged in admins only)
- 2. Press 'use window' button in order to send a command to open the window

