



CPB Initiation

Structured communication and flow ramp to safely initiate cardiopulmonary bypass

- 1Closed Loop Communication
- 2Start Timer
- 3Forward Flow

Ensure pump is working.
Do not fill HRT (trickling forward).
- 4Open Venous

Open venous clamp first then communicate.
- 5Increase Drainage & Forward Flow

See Flow Ramp — Worked Example
- 6Confirm ALL Safety Items
 - Adequate venous drainage
 - CVP zero
 - No ejections
 - Good arterialline pressure
 - Colour difference in lines
 - 2.4 cardiac index
- 7Open Oxygenator / Arterial Line
Filter Purge Line

"Going on bypass"

- ☐ Sweep / FiO₂ on?
- ☐ +/- volatile agent on

"Arterial on"

"Venous open"

FLOW RAMP — WORKED EXAMPLE

Venous open	CVP	Arterial waveform	Flow	Line pressure
25%	8		1/4	80
50%	6		1/2	110
75%	4		3/4	150
100%	0		Full	180
Flat line = zero ejections				

FULL-FLOW CONFIRMATION

- ☐ Adequate venous drainage
- ☐ CVP zero
- ☐ No ejections
- ☐ Good arterialline pressure (less than 260)
- ☐ Colour difference in lines
- ☐ 2.4 cardiac index

- 8

Open Manifold And Start CDI Machine
- 9

Communication
- 10

Arterial + Venous Blood Sample + Act
- 11

Prepare For Cardioplegia

"Full flow"

+

"Cooling to 32 degrees"

or

"Staying warm"

or

"Drifting in temp"