

CPB Initiation

Structured communication and flow ramp to safely initiate cardiopulmonary bypass



1

Closed Loop Communication

2

Start Timer

3

Forward Flow

Ensure pump is working.
Do not fill HRT (trickling forward).

4

Open Venous

Open venous clamp first then communicate.

5

Increase Drainage & Forward Flow

See Flow Ramp — Worked Example

6

Confirm ALL Safety Items

- Adequate venous drainage
- CVP zero
- No ejections
- Good arterialline pressure
- Colour difference in lines
- 2.4 cardiac index

7

Open Oxygenator / Arterial Line Filter Purge Line

“Going on bypass”

- ☐ Sweep / FiO₂ on?
- ☐ +/- volatile agent on

“Arterial on”

“Venous open”

FLOW RAMP — WORKED EXAMPLE

Venous open	CVP	Arterial waveform	Flow	Line pressure
25%	8		1/4	80
50%	6		1/2	110
75%	4		3/4	150
100%	0		Full	180
Flat line = zero ejections				

FULL-FLOW CONFIRMATION

- ☐ Adequate venous drainage
- ☐ CVP zero
- ☐ No ejections
- ☐ Good arterialline pressure (less than 260)
- ☐ Colour difference in lines
- ☐ 2.4 cardiac index

8

Open Manifold And Start CDI Machine

9

Communication

10

Arterial + Venous Blood Sample + Act

11

Prepare For Cardioplegia

