```
function [To2s] = comp_Ts(To1,Po2_over_Po1, n, type, phi, MM)
R = 286.9;
target=R.*log(Po2_over_Po1);
T2=To1;
dT=0.01;
cp_int=zeros([1, n]);
for i=1:n
    while (cp_int(i) < target(i))</pre>
        T2(i) = T2(i) + dT;
        if strcmp(type, 'JetA')
            dcp_int = sp_heats_JetA(T2(i), phi(i), MM)*(dT/T2(i));
        else
            dcp_int = sp_heats(T2(i), type)*(dT/T2(i));
        end
        cp_int(i) = cp_int(i) + dcp_int;
    end
end
To2s = T2;
end
```

Published with MATLAB® R2013a