```
function [P2] = P_given_T_var_cp(T1, T2s, P1)

R = 286.9;
T = T2s;
dT = 0.01;
cp_int = [0 0];

for i=1:2
   while T(i) < T1(i)
        T(i) = T(i) + dT;
        increment = sp_heats(T(i))*(dT/T(i));
        cp_int(i) = cp_int(i) + increment;
   end
   P2(i) = P1(i)/(exp(cp_int(i)/R));
end
end</pre>
```

Published with MATLAB® R2013a