```
function [T] = var_cp_nozz(T1,T2s,eta_nozz)
dT = .01;
T=T2s;
denominator=[0 0];
for i=1:2
    while T(i)<T1(i)</pre>
        T(i)=T(i)+dT;
        increment = sp_heats(T(i)) .* dT;
        denominator(i) = denominator(i) + increment;
    end
    target(i)=-denominator(i).*eta_nozz(i);
    T(i)=T1(i);
    left=0;
    while left>target(i)
        T(i)=T(i)-dT;
        increment=sp_heats(T(i))*dT;
        left=left-increment;
    end
end
end
```

Published with MATLAB® R2013a