```
function [T] = var_cp_turb(T1,T2,eta_turb)
dT = .01;
T=T2;
numerator=[0 0];
for i=1:2
    while T(i)<T1(i)</pre>
        T(i)=T(i)+dT;
        increment = sp_heats(T(i)) .* dT;
        numerator(i) = numerator(i) + increment;
    end
    target(i)=-numerator(i)./eta_turb(i);
    T(i)=T1(i);
    left=0;
    while left>target(i)
        T(i)=T(i)-dT;
        increment=sp_heats(T(i))*dT;
        left=left-increment;
    end
end
end
```

Published with MATLAB® R2013a