EE 142 HW1

Vighnesh Iyer

Monday, August 28, 2017

1 Antenna Lengths

Many simple antennas, such as a dipole, are most efficient when they are a significant fraction of the wavelength (quarter or half). (a) For operation at 900 MHz, what is the half-wave dipole length? (b) At 2.4 GHz? (c) At 10 MHz? (d) Explain the choice of carrier frequency based on this information for portable wireless devices. (e) (Bonus) What is the downside of a very short antenna $(l \ll \lambda)$?

$$\lambda = \frac{c}{f}$$

$$\lambda_{900Mhz} = 0.33 \text{ m} \rightarrow 0.165 \text{ m dipole}$$

$$\lambda_{2.4Ghz} = 0.125 \text{ m} \rightarrow 0.0625 \text{ m dipole}$$

$$\lambda_{10Mhz} = 30 \text{ m} \rightarrow 15 \text{ m dipole}$$

To make an effective and small antenna the carrier frequency must be large, so a carrier of 2.4Ghz makes for a small enough antenna to fit in a portable device.

A very short antenna will suffer from a degradation of its radiation efficiency due to the relatively large resistive loss of the antenna compared with longer dipoles. We can model the resistive loss and radiation resistance as: (from the discussion presentation)

$$R_{loss} = \frac{L}{6\pi a} \sqrt{\frac{\pi f \mu}{2\sigma}}$$

$$R_{rad} = 20\pi^2 (\frac{L}{\lambda})^2$$
 Radiation Efficiency =
$$\frac{R_{rad}}{R_{rad} + R_{loss}}$$

where a is the dipole radius, L is the dipole length, λ is the wavelength, and f is the frequency. We can look at the scaling proportions:

$$R_{loss} \propto L \sqrt{\frac{1}{\lambda}}$$

$$R_{rad} \propto (\frac{L}{\lambda})^2$$
 Radiation Efficiency $\propto \frac{L}{L + \lambda^{3/2}}$
$$\lim_{L \to 0} \text{Radiation Efficiency} = 0$$

2 Minimum Detectable Signal

(a) What determines the minimum detectable signal for a receiver? (Hint: What do you hear on an analog radio when it's tuned to a channel without a station?) (b) What determines the largest signal? (Hint: Consider an audio amplifier that is driven with a signal that is too large for it to handle? Radio receivers also employ amplifiers that exhibit the same behavior.)

The minimum detectable signal at the receiver is determined by its noise floor and the required minimum SNR to decode the received signal for a given modulation mode. Some modulation modes like spread spectrum are more noise tolerant while others like a large constellation QAM are heavily impacted by a noisy channel.

Also important is the data rate and bandwidth of the signal at the transmitter. For a fixed transmit power, a low data rate will consume smaller bandwidth than a high data rate and thus can benefit from noise averaging to extract the signal from the noise at the receiver (determines the minimum SNR needed to decode).

The largest signal decodable at the receiver is determined by the modulation scheme and the linearity/saturation point of the front end amplifiers. For a simple modulation scheme like OOK, the receiver signal amplitude won't affect the decodability of the signal. Same is true for modes like FSK and PSK. However AM modes will suffer from amplifier saturation since the various signal levels will be hard to distinguish.

3 Received Signal Strength

(a) What's the typical received signal strength of a cellular phone? (b) What voltage does that impart onto the antenna? (c) How about for WLAN (Wi-Fi)? (Hint: Use the signal strength indicator of your WLAN utility or a program such as iStumbler on a Mac. There's also a very nice command line utility called "airport" that provides this information.)

A typical cellular signal strength at the receiver is around -75 dBm. The voltage imparted onto the antenna depends on its impedance, which is typically matched to 50 Ohms in the cellular band. $P = V^2/R \rightarrow 32pW = V^2/50 \rightarrow V = 40\mu V$