CS203 GPIO Demo Application Manual

GPIO setting: this only for FCC and latest bootloader version. This function will be enabled later on other countries reader.

To apply the settings by clicking "Set" button.

First Screen

TCP timeout: please set it to zero to avoid timeout at CS203

Notes : If you change any parameters on Server address or Client address, you must reset the CS203 device.