Interface Control Document

for

Bluetooth Controller Module

The Bluetooth Controller Module has the following commands,

- 1) Relay On command
- 2) Relay On with Time command
- 3) Relay Off command
- 4) Start Self Command

SNo	Command String	Description
1	"RlyOn"	Turns on the Relay
2	"RlyOn HH:MM:SS"	Turns on the Relay for time specified, (Timer)
		ON Time = $((HH * 3600) + (MM * 60) + SS)$ seconds
3	"RlyOff"	Turns off the Relay
4	"StTest"	Performs Self Test, in which, Usr_LED_1, Usr_LED_1
		and Relay are turned on for 2 seconds and turned off.

Note:

Relay off command will turn relay off immedeately and stop any running timers.