## **Home Assistant** LEVEL 3

## 1. Installation

- Home Assistant Operating System
- Home Assistant Container

## 2. ODROID

- Install Home Assistant Operating System
- WRITE THE IMAGE TO YOUR INSTALLATION
  MEDIA
- Install Home Assistant Container

## 3. Raspberry Pi

- Install Home Assistant Operating System
- SUGGESTED HARDWARE
- WRITE THE IMAGE TO YOUR INSTALLATION
  MEDIA
- Install Home Assistant Container
- PLATFORM INSTALLATION
- RESTART HOME ASSISTANT
- Install Home Assistant Core
- 4. Asus Tinkerboard
- 5. Intel NUC
- 6. Windows

- 7. macOS
- 8. Linux