## **DeviceHive** LEVEL 5

- 1. Raspberry Pi and Temperature Sensor
- 2. Configuring Raspberry Pi
- 3. Installing DeviceHive on Raspberry Pi
- 4. Access your device