# Setup Raspberry Pi in headless mode

Headless Mode means system runs without any primary input and output such as keyboard or monitor. The system won't use desktop environment and therefore GUI applications will not run.

#pi #headless

Last update: April 23, 2021

# **Table of Content**

- 1. Download OS Image
- 2. Burn Image to SDCard
- 3. Enable SSH
- 4. Add Wifi Network Info
- 5. Login to RPi
- 6. Update system
- 7. Expand Filesystem
- 8. Others


## 1. Download OS Image

Official images for recommended operating systems are available to download from the Raspberry Pi website download page.

Headless Mode is available in the *Raspberry Pi OS Lite* version, please follow the guide in the official download page.

### 2. Burn Image to SDCard

The application *balenaEtcher* from Balena is a very good image writer that will write OS image to SDCard. Download and install it, then run it. Just follow the guided steps.



Etcher is writing OS image

After copying the image to a SDCard, File Explorer may have trouble seeing the content of that SDCard. A simple fix is to pull the SDCard out then plug it back in. It should appear with a partition named **boot**.

#### 3. Enable SSH

For security reasons, ssh is no longer enabled by default. To enable it, place a blank text file called *ssh* in the root of the boot partition on the SDCard.

### 4. Add Wifi Network Info

To add network info, create a text file called wpa\_supplicant.conf and place that in the root of the boot partition on SDCard too.

#### $wpa\_supplicant.conf$

```
country=US
ctrl_interface=DIR=/var/run/wpa_supplicant GROUP=netdev
update_config=1


network={
    ssid="NETWORK-NAME"
    psk="NETWORK-PASSWORD"
}
```

boot (F:) → ✓ ♂	Search boot (F:)	م
Name	Date modified	Туре
LICENCE.broadcom	5/27/2020 11:22 AM	BROADCON
ssh	11/27/2020 10:06	File
start.elf	8/20/2020 6:56 AM	ELF File
start_cd.elf	8/20/2020 6:56 AM	ELF File
start4db.elf	8/20/2020 6:56 AM	ELF File
start4x.elf	8/20/2020 6:56 AM	ELF File
wpa_supplicant.conf	11/27/2020 10:07	CONF File

Added ssh and wpa\_supplicant.conf in boot partition

# 5. Login to RPi

Power RPi up and wait for the power led gets stable. Use any Network Scanner to detect the IP of the RPi. A plugin on MobaXterm can be used too.



Scan for RPi IP

For the official Raspberry Pi OS, the default user name is pi, with password raspberry, on the host raspberrypi.

```
~ $ ssh pi@raspberrypi
pi@raspberrypi's password:
Linux raspberrypi 5.4.51+ #1333 Mon Aug 10 16:38:02 BST 2020 armv6l

The programs included with the Debian GNU/Linux system are free software; the exact distribution terms for each program are described in the individual files in /usr/share/doc/*/copyright.

Debian GNU/Linux comes with ABSOLUTELY NO WARRANTY, to the extent permitted by applicable law.

/usr/bin/xauth: file /home/pi/.Xauthority does not exist

SSH is enabled and the default password for the 'pi' user has not been changed. This is a security risk - please login as the 'pi' user and type 'passwd' to set a new password.

pi@raspberrypi:~ $ pi@raspberrypi:~ $ pi@raspberrypi:~ $ |
```

Login on ssh to RPi

### Review Network Settings

This command should list the network connection in the first line for wlan0:

```
iwconfig
```

This command should show info for wlan0:

```
ifconfig
```

This command should list the wlan0 network with details:

```
iwlist wlan0 scan
```

To edit or review the wifi settings, run this command:

```
sudo nano /etc/wpa_supplicant/wpa_supplicant.conf
```

#### Connect to an other Wifi network

Open the wpa-supplicant configuration file in nano:

```
sudo nano /etc/wpa_supplicant/wpa_supplicant.conf
```

Go to the bottom of the file and add the following:

```
network={
    ssid="NETWORK-NAME"
    psk="NETWORK-PASSWORD"
}
```

Reconfigure the interface with:

```
wpa_cli -i wlan0 reconfigure
```

Verify whether it has successfully connected using ifconfig wlan0

# 6. Update system

(optional)

To get the latest version of RPi OS and its packages, please update the system by entering below commands:

```
sudo apt-get update
sudo apt-get upgrade -y
```

## 7. Expand Filesystem

(optional)

To use all of available space on the SDCard, expand the filesystem by running:

```
sudo raspi-config
```

Select Advanced Options > Expand Filesystem

Then reboot the system.

### 8. Others

(optional)

Please read the Save Power post.

#### Show who is logged on and what they are doing

Use w command from procps package.

```
08:53:52 up 2:21, 2 users, load average: 0.02, 0.06, 0.07
        TTY
                FROM
                                LOGIN@ IDLE JCPU PCPU WHAT
USER
                                        0.00s 1.54s 0.05s w
                fe80::1936:b4d4: 06:34
рi
        pts/0
                fe80::1936:b4d4: 06:34
                                        2:18m 0.74s 0.74s -bash
        pts/1
```

### **Comments**