
Schema di collegamento - Connection diagram - Schemas de branchement -Schaltplan - Esquemas de conexión



Motors

Elettropompe trifase una velocità – Single speeds, three phase electric pumps – Electropompes triphasé une vitesses – Fliehkraftpumpen eine Drehzahlstufen – Electro bombas trifásico una velocidades

Collegamento - Connection - Connexion - Schaltung -Conexión



Collegamento - Connection - Connexion - Schaltung -Conexión BIANCO

ROSSO = RED - ROUGE - ROT - ROJO / BIANCO = WHITE - BLANC - WEIβ - BLANCO / NERO = BLACK - NOIR - SCHWARZ - NEGRO

L1 - L2 - L3 = Linea - Supply - Reseau - Netz - Red
Per invertire la rotazione invertire due fasi - To change the rotation reverse two phases - Pour changer le sens de rotation inverser deux phases - Zur Drehrichtungsänderung zwei Phasen vertauschen - Para invertir el sentido de rotación invertir dos fases