Waldorf Microwave 2/XT Controller Number Assignment Software release 2.09

Contr. No.	Range	Parameter	Value Range
1	0127	Modulation wheel MSB	0127
2	0127	Breath control MSB	0127
4	0127	Foot controller MSB	0127
5	0127	Glide Time	0127
7	0127	Channel Volume	0127
10	0127	Panning left	64centerright 63
12	01	Chorus 0:off 1:on	
14		Filter Env Attack	0127
15	0127	Filter Env Decay	0127
16	0127	Filter Env Sustain	0127
17	0127	Filter Env Release	0127
18	0127	Amp Env Attack	0127
19	0127	Amp Env Decay	0127
20	0127	Amp Env Sustain	0127
21	0127	Amp Env Release	0127
22	03	Glide Type	<pre>0:portamento 1:fingered port. 2:glissando 3:fingered gliss.</pre>
23	01	Glide Mode	0:exp. 1:linear
24	0127	LFO1 Rate	0127
25	05	LF01 Shape	0:sin 1:tri 2:square 3:saw
4:random			5 007
2.6	0 107	7.700 P. I	5:S&H
26		LFO2 Rate	0127
27		LFO2 Delay	0:off 1:retrigger 2127:1126
28 4:random	05	LFO2 Shape	0:sin 1:tri 2:square 3:saw
4.Landom			5:S&H
29	02	Filter Env Trigger	0:normal 1:single 2:retrigger
30	0127	LFO1 Delay	0:off 1:retrigger 2127:1126
31	02	Amp Env Trigger	0:normal 1:single 2:retrigger
32	01	Bank Select	0:Bank A 1:Bank B
33	16112	Osc 1 Octave	-4+4 (in steps of 12)
34	5676	Osc 1 Semitone	-12+12
35	0127	Osc 1 Detune	-64+63
36	0121	Osc 1 Pitchbend Scale	0120:semitones 121:harmonic
122:global			
37	0127	Osc 1 Keytrack	-100%+200%
38	16112	Osc 2 Octave	-4+4 (in steps of 12)
39	5676	Osc 2 Semitone	-12+12
40	0127	Osc 2 Detune	-64+63
41	01	Osc 2 Sync	0:off 1:on
42	0121	Osc 2 Pitchbend Scale	<pre>0120:semitones 121:harmonic 122:global</pre>
43	0127	Osc 2 Keytrack	-100%+200%
44	01	Osc 2 Link	0:off 1:on
45	0 127	Wayo 1 Toyol	0127
46	0127 0127	Wave 1 Level Wave 2 Level	
			0127
47	012/	RingMod Level	0127

```
48
               0..127 Noise Level
                                               0..127
        50
               0..127 Filter 1 Cutoff
                                               0..127
        51
                0..127 Filter 1 Keytrack
                                               -200%..+197%
        52
                0..127 Filter 1 Env Amount
                                               -64..+63
        53
                0..127 Filter 1 Env Velocity
                                               -64..+63
                0..9
                                               0:24dB LP 1:12dB LP
                                                                     2:24dB BP
        54
                       Filter 1 Type
                                               3:12dB BP 4:12dB HP 5:sinX>12L
                                               6:Waveshaper 7:Dual
                                                                     8:FM-
Filter
                                               9:S&H->L12dB
        55
                0..127 Amp Keytrack
                                               -200%..+197%
        56
                0..127
                       Filter 1 Resonance
                                               0..127
        57
                0..127 Amp Volume
                                               0..127
        58
               0..127 Amp Env Velocity
                                               -64..+63
        60
               0..127 Filter 2 Cutoff
                                               0..127
        61
                0..1
                       Filter 2 Type
                                               0:6dB LP 1:6dB HP
               0..127 Filter 2 Keytrack
                                               -200%..+197%
        62
        64
               0..127 Sustain Switch 0..127
        65
                0..127 Portamento Switch
                                               0..127
               0..127 Sostenuto Switch
                                               0..127
        66
        70
               0..127 Wavetable
                                               Wavetable 001..128
                       Wave 1 Startwave
        71
               0..63
                                               00..60 61:triangle
                                               62:square 63:saw
        72
               0..127 Wave 1 Phase
                                               0:free 1..127:3..357 degree
                       Wave 1 Env Amnt.
        73
               0..127
                                               -64..+63
        74
                0..127
                       Wave 1 Env Vel. Amnt.
                                               -64..+63
        75
               0..127
                       Wave 1 Keytrack
                                               -200%..+197%
                       Wave 1 Limit
        76
                                               0:off 1:on
               0..1
        77
               0..63
                       Wave 2 Startwave
                                               00..60 61:triangle
                                               62:square 63:saw
        78
               0..127 Wave 2 Phase 0:free 1..127:3..357 degree
               0..127 Wave 2 Env Amnt.
        79
                                               -64..+63
        80
               0..127 Wave 2 Env Vel. Amnt.
                                               -64..+63
        81
                0..127 Wave 2 Keytrack
                                               -200%..+197%
        82
                0..1
                       Wave 2 Limit
                                               0:off 1:on
        83
                0..1
                       Wave 2 Link
                                               0:off 1:on
        85
                0..127 Free Env Time 1
                                               0..127
                0..127 Free Env Level 1
                                               -64..+63
        86
                0..127 Free Env Time 2
        87
                                               0..127
                0..127 Free Env Level 2
        88
                                               -64..+63
                0..127 Free Env Time 3
        89
                                               0..127
               0..127
                       Free Env Level 3
        90
                                               -64..+63
        91
               0..127 Free Env Release Time
                                               0..127
        92
               0..127 Free Env Release Level -64..+63
        93
               0..2
                       Free Env Trigger
                                               0:normal 1:single 2:retrigger
        102
                                               0:off 1:on 2:hold
               0..2
                       Arp Active
        103
               0..9
                       Arp Range
                                               1..10 Octaves
        104
               0..15
                       Arp Clock
                                               1/1..1/32
               0..127 Arp Tempo
                                               0:external 1..127:50..300BPM
        105
        106
               0..3
                       Arp Direction
                                               0:up 1:down 2:alternate 3:random
               0..16
                       Arp Pattern
                                               0:off 1:user 2..16:Pattern 1..15
        107
                       Arp Note Order
                                               0:by note 1:note rev 2:as played
        108
               0..3
                                               3:reversed
               0..1
0..1
        109
                                               0:root note 1:last note
                       Arp Velocity
                                               0:off 1:on
        110
                       Arp Reset
        111
               0..15
                       Arp Pattern Length
                                               1..16
```