




Here are images on how to connect your motor to the motor driver shield





Pins being used

DC Motors:



Motor 1: digital pin 11

Motor 2: digital pin 3

Motor 3: digital pin 5

Motor 4: digital pin 6

Pins being used



Servo Motors:

Servo 1: digital pin 9

Servo 2: digital pin 10





Shift registers:

Digital pins 4, 7, 8, and 12



Not Connected:

Digital pins 2 and 13

Analog A0 to A5

Also Pins 1 and 0