Make uEnv.txt to Boot from MMC0

In this case, we loaded the boot images from MMC1 interface(eMMC) and used the file system present on the MMC0(MiroSD card), Challenge for you is to change this uEnv.txt such that boot images are loaded from MMC0(MicroSD).