Increase the AUTOLOAD timings .

you might have observed that , when the uboot boots it just waits for 5 seconds before going to auto loading mode(reading uEnv.txt , loading ulmage, etc). Within 5 seconds if you press "space" bar then you will get the uboot command prompt.

Challenge for you is to increase that autoload timing to 10 seconds and confirm this change by testing on the hardware. you have to change the uboot source code and then rebuild it to generate the uboot image.