Product	Sensor Readings	Descriptive (What?)	Diagnostic (Why?)	Predictive (What next?)	Prescriptive (What to do?)
Industrial Water Pump	Vibration: 7.2 mm/s; Bearing Temperature: 82°C; Outlet Pressure: 2.1 bar	Vibration and temperature are elevated, while water outlet pressure has decreased.	Possible bearing wear, shaft misalignment, or a partially blocked inlet.	Continued operation may lead to bearing failure and unexpected water supply interruption.	Inspect bearings and alignment, check the inlet filter, and compare readings against manufacturer limits before restarting.
Smart GreenHouse Irrigation System	Soil Moisture: 28%; Air Temperature: 36°C; Humidity: 42%	Soil moisture is low while greenhouse temperature is high.	Insufficient irrigation, high evaporation, or a clogged drip line may be responsible.	Soil moisture may fall further, causing plant water stress and reduced crop growth.	Activate drip irrigation based on crop-specific moisture thresholds, inspect emitters, and monitor soil moisture after watering.
Commercial Cold-Storage Room	Air Temperature: 9°C; Target Temperature: 2–5°C; Door Open Time: 12 minutes	Storage temperature is above the assumed target range.	Frequent door opening, poor door seals, excessive loading, or refrigeration problems may explain the temperature rise.	Continued temperature excursions may shorten food shelf life and increase spoilage risk.	Check door seals, minimise door opening, inspect refrigeration performance, and move vulnerable stock to verified safe storage if necessary.
Agricultural Tractor	Engine Oil Temperature: 118°C; Vibration: 6.5 mm/s; Engine Load: 92%	Engine temperature and vibration are high under heavy load.	Possible cooling-system problems, low oil level, excessive load, or mechanical wear.	Continued operation could cause overheating, component damage, and unplanned downtime.	Reduce load and stop safely if readings exceed manufacturer limits; check coolant, oil, and vibration sources before resuming work.
Industrial Conveyor Belt	Motor Temperature: 91°C; Vibration: 8.1 mm/s; Motor Current: 18 A	Motor temperature and vibration are elevated, indicating abnormal operating conditions.	Possible bearing wear, belt misalignment, excessive friction, or motor overload.	The conveyor may experience motor failure, belt damage, or production downtime.	Stop the conveyor if safety limits are exceeded, inspect alignment and bearings, check the load, and perform maintenance before restarting.