Product specification

BWC 25 SWC 31 BWC 47 SWC 63



Galvanised steel stay wires Bare catenary wires / messengers





Use

- Dead-ending of galvanised steel stay wires.
- Dead-ending of galvanised steel bare catenary wires.

Stay wire/Bare catenary wire clamp

Installation

- 1. Insert the bail in the pole hardware (pole level) or in the stay rod eye (ground level).
- 2. Pass the collar around the bail.
- 3. Pass the clamp body in the collar.
- 4. Insert the stay wire or bare catenary wire in the clamp body.
- 5. Adjust the load in the wire by pulling the wire in the clamp body. The dead-ending is achieved automatically.











Range

Reference	Nominal Ø / Type of cable	Range	Min. breaking load
BWC25	Ø 2.5 mm / Single Strand	2.3 - 2.7 mm	750 daN
SWC31	Ø 3.1 mm / Single Strand	2.9 - 3.3 mm	900 daN
BWC47	Ø 4.7 mm / 7x1.57 mm	4.4 – 5.1 mm	1800 daN
SWC63	Ø 6.3 mm / 7x2.10 mm	6.0 – 6.6 mm	2 800 daN

Characteristics

Reference	Materials			Waight	Packaging
	Body	Jaws	Bail	Weight	
BWC25 – SWC31	Aluminium	Treated	Stainless	0.052 kg	100 units
BWC47 – SWC63	alloy	steel	steel	0.165 kg	50 units