

1-2 => suspend Ay Rat tout 5/w The poles for 7m 2-3=> Suspend A4 Root toul b/w The poly for 38 m 37 Connect A4 Red tout to existing OFDC & C12 (FALS968) Install and clip 32 mm duct to side of pole. Haul Ay Pat toul through 32mm duct (8 m)

Supply and install pedestal and IFDB (FABU777)

MT 15m in concrete and lay 1x Riggy
47 leave drop off for ## 394A Townson a val
3-5 = Trench 3.3 m En Growel and lay 2x Rigg
5-67 MT 3m in concrete.

5-6 > clip 1x Rugg to on the fence for 25m.
6 > leave Drop off for # 392 A PANAMA rd,
5 > 7 > MT 4.6 m in concrete and lay 1x Rugg.
7 > leave Drop off for # 392 Danama road