## #132082 (#2/179 McLEOD ROAD)

- 1 -> Connect 2x Ruggedized at the dropott (Tube 607)
- 1-2-> OSB. Trench 7m in Grass and Lay Jomm duct Haul 2x Ruggedized through Jomm duct
- 2-3-> Haul 2xRuggedized through existing somm duct which customer has been buried
  - 3 -> Install Handhole (customer provided)
  - 3-> Leave a dropott for #2/179 mcleod Road in Handhole
- 3-4-> Haul IXRuggedized through existing Somm duct which has been buried by customer
  - 4-> Leave a dropott for (#3/179 mcleod Road'