5.5 Faraday Rotation – Ferromagnetic properties

Module:5 Microwave Passive components

Course: BECE305L - Antenna and Microwave Engineering

-Dr Richards Joe Stanislaus

Assistant Professor - SENSE

Email: richards.stanislaus@vit.ac.in



Module:5 <u>Microwave Passive components</u> 6 hours

 Microwave Networks - ABCD, 'S' parameter and its properties. E-Plane Tee, H-Plane Tee, Magic Tee and Multi-hole directional coupler. Principle of Faraday rotation, isolator, circulator and phase shifter.

Source of the contents: Pozar

Magnet – North and South

١


- Magnet North and South
- Two magnets when placed close

N


N S

S

- Magnet North and South
- Two magnets when placed close
- They tend to align with North and south



- Magnet North and South
- Two magnets when placed close
- They tend to align with North and south




- Magnet North and South
- Two magnets when placed close
- They tend to align with North and south
- Space around magnet
 - Allows magnetic field in a certain pattern
- This can be measured by placing iron filings around the magnet




S


- Magnet North and South
- Two magnets when placed close
- They tend to align with North and south
- Space around magnet
 - Allows magnetic field in a certain pattern
- This can be measured by placing iron filings around the magnet




- Magnet North and South
- Two magnets when placed close
- They tend to align with North and south
- Space around magnet
 - Allows magnetic field in a certain pattern
- This can be measured by placing iron filings around the magnet
- Once magnet is placed, the filings align in a manner




- Magnet North and South
- Two magnets when placed close
- They tend to align with North and south
- Space around magnet
 - Allows magnetic field in a certain pattern
- This can be measured by placing iron filings around the magnet
- Once magnet is placed, the filings align in a manner
- A magnetic compass (which is also a small magnet) when placed around – gets aligned to the filings direction(along field lines)




- Magnet North and South
- Two magnets when placed close
- They tend to align with North and south
- Space around magnet
 - Allows magnetic field in a certain pattern
- This can be measured by placing iron filings around the magnet
- Once magnet is placed, the filings align in a manner
- A magnetic compass (which is also a small magnet) when placed around – gets aligned to the filings direction(along field lines)



- Magnet North and South
- Two magnets when placed close
- They tend to align with North and south
- Space around magnet
 - Allows magnetic field in a certain pattern
- This can be measured by placing iron filings around the magnet
- Once magnet is placed, the filings align in a manner
- A magnetic compass (which is also a small magnet) when placed around – gets aligned to the filings direction(along field lines)



 Consider the magnetic field between two magnets




S

- Consider the magnetic field between two magnets
- In air medium/vacuum, the field lines remain the same.
 Air/vacuum allows/permits the magnetic fields to pass through normally.
 And so does many other materials.


 μ_0 : Ability of vacuum to create internal

magnetic fields



- Consider the magnetic field between two magnets
- In air medium/vacuum, the field lines remain the same.
 Air/vacuum allows/permits the magnetic fields to pass through normally.
 And so does many other materials.
 μ₀: Ability of vacuum to create internal magnetic fields
- For <u>iron</u>, the magnetic fields are warped into the medium.
 This is because, fields are formed inside the material.

 $\mu = \mu_0 \mu_r$: Ability of Iron to create internal H field



1.1 Introduction - Until now

- Reciprocal networks (Response of network was independent of direction of signal flow $S_{ij} = S_{ji}$)
- Component was passive, and materials were isotropic.

- Anisotropic materials and active devices produce non-reciprocal behaviour.
- Nonreciprocity a useful property in devices like circulators and isolators.
- Nonreciprocity an ancillary property in devices like transistor amplifiers, ferrite phase shifters.

- Anisotropic materials and active devices produce non-reciprocal behaviour.
- Nonreciprocity a useful property in devices like circulators and isolators.
- Nonreciprocity an ancillary property in devices like transistor amplifiers, ferrite phase shifters.
- Most practical materials for some microwave applications –
 Ferrimagnetic compounds known as ferrites.
 Example: Yttrium iron garnet (YIG) and materials composed of iron oxides, various elements like aluminium, cobalt, manganese and nickel.

- Anisotropic materials and active devices produce non-reciprocal behaviour.
- Nonreciprocity a useful property in devices like circulators and isolators.
- Nonreciprocity an ancillary property in devices like transistor amplifiers, ferrite phase shifters.
- Most practical materials for some microwave applications Ferrimagnetic compounds known as ferrites.
 Example: Yttrium iron garnet (YIG) and materials composed of iron oxides, various elements like aluminium, cobalt, manganese and nickel.
- Ferromagnetic materials (iron, steel)
- Ferrimagnetic compounds have high resistivity and significant anisotropy at microwave frequencies.

- Magnetic anisotropy is induced by applying a DC magnetic bias field.
- Field aligns the magnetic dipoles in ferrite material to produce a net(zero) magnetic dipole moment
 Causing the magnetic dipoles to precess(change in orientation of rotation axis) at frequency controlled by strength of the bias field.

- Magnetic anisotropy is induced by applying a DC magnetic bias field.
- Field aligns the magnetic dipoles in ferrite material to produce a net(zero) magnetic dipole moment
 Causing the magnetic dipoles to precess(change in orientation of rotation axis) at frequency controlled by strength of the bias field.
- A circularly polarized microwave signal when in the same direction as this precession, will interact strongly with dipole moments.
- Oppositely polarized field interacts less strongly.

- Magnetic anisotropy is induced by applying a DC magnetic bias field.
- Field aligns the magnetic dipoles in ferrite material to produce a net(zero)
 magnetic dipole moment
 Causing the magnetic dipoles to precess(change in orientation of rotation
 axis) at frequency controlled by strength of the bias field.
- A circularly polarized microwave signal when in the same direction as this precession, will interact strongly with dipole moments.
- Oppositely polarized field interacts less strongly.
- For a given direction of rotation, sense of polarization changes with direction of propagation,
 Microwayo signal will propagate through magnetically biased forrito
 - Microwave signal will propagate through magnetically biased ferrite differently in different directions. (Used in circulators, isolators, gyrators)

 Interaction with applied microwave signal – controlled by adjusting the strength of the bias field.
 Leads to control devices: phase shifters, switches, tunable resonators and filters.

1.3 Para-electric materials

- Almost dual of ferrimagnetic materials.
- Example: Lithium niobate, barium titanate: Dielectric property can be controlled with application of DC bias electric field.

1.3 Para-electric materials

- Almost dual of ferrimagnetic materials.
- Example: Lithium niobate, barium titanate: Dielectric property can be controlled with application of DC bias electric field.
- Paraelectric materials variable phase shifters and other control components.
- Isotropic and reciprocal.

1.3 Para-electric materials

- Almost dual of ferrimagnetic materials.
- Example: Lithium niobate, barium titanate: Dielectric property can be controlled with application of DC bias electric field.
- Paraelectric materials variable phase shifters and other control components.
- Isotropic and reciprocal.
- High dielectric constants and loss tangents when used in bulk form, modern generally use thin films of paraelectric material layered on a substrate.
- Advantage: Need for large and heavy magnet or biasing coil is eliminated.

- To develop many microwave non-reciprocal devices.
- Ferrites: Complex solids represented by $M^{+2}O$. Fe₂O₃. M^{+2} : ion of a divalent metal (Cobalt, nickel, zinc, magnesium, cadmuim, iron, manganese, chromium, copper, etc).

- To develop many microwave non-reciprocal devices.
- Ferrites: Complex solids represented by $M^{+2}O$. Fe₂O₃. M^{+2} : ion of a divalent metal (Cobalt, nickel, zinc, magnesium, cadmuim, iron, manganese, chromium, copper, etc).
- Specific resistance of ferrites: order of $10^7 10^8 \Omega m$ (10^{14} times than that of metal)
- Relative permittivity $\varepsilon_r \sim 10-15$
- Loss tangent $\tan \delta \approx 10^{-4}$ (low loss at microwave frequencies)

• For magnetically saturated ferrite, magnetized in z direction with RF field propagating in z-direction

Permeability of ferrite: (It is asymmetric tensor) $\tilde{\mu} = \mu_0 \begin{bmatrix} \mu & -jK & 0 \\ jK & \mu & 0 \\ 0 & 0 & 1 \end{bmatrix}$

• For magnetically saturated ferrite, magnetized in z direction with RF field propagating in z-direction

field propagating in $z - \mu = \mu_0$ [$\mu = \mu_0$ [$\mu = \mu_0$] Permeability of ferrite: (It is asymmetric tensor) $\tilde{\mu} = \mu_0$ [$\mu = \mu_0$ [$\mu = \mu_0$] $\mu = \mu_0$ [$\mu = \mu_0$

- Relative permeability of ferrites μ_r are of the order of several thousands.
 - Ferrites are good dielectrics but exhibit magnetic anisotropy.


•

• For magnetically saturated ferrite, magnetized in z direction with RF field propagating in z-direction

field propagating in $z - \mu = \mu_0$ [$\mu = \mu_0$ [$\mu = \mu_0$] Permeability of ferrite: (It is asymmetric tensor) $\tilde{\mu} = \mu_0$ [$\mu = \mu_0$ [$\mu = \mu_0$] $\mu = \mu_0$ [$\mu = \mu_0$

- Relative permeability of ferrites μ_r are of the order of several thousands.
 - Ferrites are good dielectrics but exhibit magnetic anisotropy.
- Non-reciprocal electrical properties (for microwave propagation)
 - 1) The transmission coefficient is not same for different direction
 - 2) Non-reciprocal rotation of the plane of polarization.

- Magnetic properties of ferrites results from magnetic dipole moment m due to the electron spin.
- Permeability tensor: Existence of magnetic dipole moments (due to primarily from electron spin)




- Magnetic properties of ferrites results from magnetic dipole moment m due to the electron spin.
- Permeability tensor: Existence of magnetic dipole moments (due to primarily from electron spin)
- · Magnetic dipole moment of an electron due to its spin

$$m = \frac{qh}{2m_e} = 9.27 \times 10^{-24} \text{A} - \text{m}^2$$

h: Plank's constant by 2π .

q: Electron charge

 m_e : mass of the electron



- Magnetic properties of ferrites results from magnetic dipole moment m due to the electron spin.
- Permeability tensor:

 Existence of magnetic dipole moments (due to primarily from electron spin)
- · Magnetic dipole moment of an electron due to its spin


$$m = \frac{qh}{2m_e} = 9.27 \times 10^{-24} \text{A} - \text{m}^2$$

h: Plank's constant by 2π .

q: Electron charge

 m_e : mass of the electron


 An electron in orbit around a nucleus gives rise to an effective current loop, thus an additional magnetic moment.




- Magnetic properties of ferrites results from magnetic dipole moment m due to the electron spin.
- In the absence of any source, net angular momentum of full shell is zero.
- Only electron spins in the incomplete shell are effective to produce a net dipole moment per atom.

- Magnetic properties of ferrites results from magnetic dipole moment m due to the electron spin.
- In the absence of any source, net angular momentum of full shell is zero.
- Only electron spins in the incomplete shell are effective to produce a net dipole moment per atom.
- Ferrite: Can be considered as collection of N effective spinning electrons per unit volume.
- Total magnetic dipole moment $\mathbf{M} = N\mathbf{m}$.

 In absence of external magnetic field, dipole moments are oriented at random and combined effect is negligibly small, material does not show magnetization.



- In absence of external magnetic field, dipole moments are oriented at random and combined effect is negligibly small, material does not show magnetization.
- <u>Precession:</u> the slow movement of the axis of a spinning body around another axis due to a torque (such as gravitational influence)




- In absence of external magnetic field, dipole moments are oriented at random and combined effect is negligibly small, material does not show magnetization.
- <u>Precession:</u> the slow movement of the axis of a spinning body around another axis due to a torque (such as gravitational influence)
- If <u>Steady external magnetic field</u> H_0 is present in the direction other than that of \mathbf{m} of an electron, m precesses gyromagnetically around H_0 due to the torque

 $\tau = \mathbf{m} \times \mu \mathbf{H_0}$ And trends to align the electron spin with $\mathbf{H_0}$.

- In absence of external magnetic field, dipole moments are oriented at random and combined effect is negligibly small, material does not show magnetization.
- <u>Precession:</u> the slow movement of the axis of a spinning body around another axis due to a torque (such as gravitational influence)
- If Steady external magnetic field \mathbf{H}_0 is present in the direction other than that of \mathbf{m} of an electron, m precesses gyromagnetically around H_0 due to the torque

 $\tau = \mathbf{m} \times \mu \mathbf{H_0}$ And trends to align the electron spin with $\mathbf{H_0}$.


• Frequency of precessions $f_0(MHz) \approx 2.8H_0$ (oersted) Gyromagnetic ratio = $\gamma = 2.8 \, MHz/oersted$



• torque $\tau = \mathbf{m} \times \mu \mathbf{H_0}$

Frequency of precessions $f_0(MHz) \approx 2.8H_0$ (oersted) Gyromagnetic ratio = $\gamma = 2.8 \, MHz/oersted$.


- Direction of precession determined by $\mathbf{H_0}$ and is clockwise looking along $\mathbf{H_0}$.
- Angle of precession, $\psi = \angle H_0 m$ decreases due to friction.




• torque $\tau = \mathbf{m} \times \mu \mathbf{H_0}$


Frequency of precessions $f_0(MHz) \approx 2.8H_0$ (oersted) Gyromagnetic ratio = $\gamma = 2.8 \, MHz/oersted$.


- Direction of precession determined by $\mathbf{H_0}$ and is clockwise looking along $\mathbf{H_0}$.
- Angle of precession, $\psi = \angle \mathbf{H_0m}$ decreases due to friction.
- Ferrite is magnetized with magnetization momentum ${\bf M}$ when the electron spins are aligned with ${\bf H_0}$.




 Hysteresis: The behaviour of magnetization and demagnetization of ferrite.










Schematic Illustration of Domain Structure at Various Stages of the Magnetization Process










Schematic Illustration of Domain Structure at Various Stages of the Magnetization Process







 Hysteresis: The behaviour of magnetization and demagnetization of ferrite.





Direction of propagation

Magnetization **M**


RF


 Hysteresis: The behaviour of magnetization and demagnetization of ferrite.





 Hysteresis: The behaviour of magnetization and demagnetization of ferrite.





Saturation

Remanence

 $H_{\mathcal{S}}$

 \mathbf{B}_0

 B_s


2.2 Hysteresis in Ferrite

 Hysteresis: The behaviour of magnetization and demagnetization of ferrite.

• Ferrite has high remanence value,


 B_r : sample remains magnetized even when applied external domagnetic field $\mathbf{H_0}$ is reduced to zero from its saturation

magnetization H_s .




- 1) If Ferrite sample is magnetized to saturation in its plane, in direction to RF magnetic field $\psi = 0^{\circ}$, then for small RF signal strength, minimum interaction between
- Effective RF relative permeability $\mu_r \approx 1$

ferrite and RF magnetic field.



- 1) If Ferrite sample is magnetized to saturation in its plane, in direction to RF magnetic field $\psi=0^{\circ}$, then for small RF signal strength, minimum interaction between ferrite and RF magnetic field.
- Effective RF relative permeability $\mu_r \approx 1$
- 2) If Ferrite sample is magnetized to saturation in direction perpendicular to RF magnetic field $\psi = 90^{\circ}$, maximum interaction takes place between ferrite medium and RF magnetic field.
- Effective RF relative permeability $\mu_r = \frac{\mu^2 K^2}{\mu^2}$ where μ and K are components of permeability tensor $K = \frac{\gamma_m 4\pi M_S}{\omega}$.




In the frequency range of interest where $\frac{\gamma_m 4\pi M_s}{\omega} < 1$, and with small place applied magnetic field, the effective RF relative permeability becomes:

$$\mu_r \approx 1 - \left(\frac{\gamma_m 4\pi M_s}{\omega}\right)^2$$

Where the ferrite's magnetization = $4\pi M_s$.


When $\omega = \gamma_m 4\pi M_s$, magnetic loss becomes significant and the μ_r equation changes.




- The propagation constant of TEM wave in ferrite $\beta = \omega \sqrt{\mu_r \mu_0 \varepsilon_r \varepsilon_0}$
- When the ferrite is magnetized with

$$\mu_r = \begin{cases} 1, & non interacting state \\ \frac{\mu^2 - K^2}{\mu^2}, & Interacting state \end{cases}$$

 Propagation constant changes its state with the direction of magnetization.



• In addition to external steady magnetic field, if RF or microwave circularly polarized magnetic field **H** at frequency $f \approx f_0$ is applied perpendicular to $\mathbf{H_0}$,




• In addition to external steady magnetic field, if RF or microwave circularly polarized magnetic field **H** at frequency $f \approx f_0$ is applied perpendicular to $\mathbf{H_0}$,

When the direction of rotation of **H** and **M** coincide:

the angle of precession ψ of **M** and also the amplitude of induced precession will tend to increase at $f=f_0$ and reach a steady state due to magnetic frictional loss.

The energy continuously supplied by the RF field is dissipathe ferrite.



 In addition to external steady magnetic field, if RF or microwave circularly polarized magnetic field H at frequency $f \approx f_0$ is applied perpendicular to $\mathbf{H_0}$,

When the direction of rotation of **H** and **M** coincide:

the angle of precession ψ of M and also the amplitude of induced precession will tend to increase at $f = f_0$ and reach a steady state due to magnetic frictional loss.

The energy continuously supplied by the RF field is dissipa the ferrite.

When the interaction between RF/Microwave field and electrons is reduced: Low losses in ferrite.

• In addition to external steady magnetic field, if RF or microwave circularly polarized magnetic field **H** at frequency $f \approx f_0$ is applied perpendicular to $\mathbf{H_0}$,

When the direction of rotation of H and M coincide:

the angle of precession ψ of **M** and also the amplitude of induced precession will tend to increase at $f = f_0$ and reach a steady state due to magnetic frictional loss.

The energy continuously supplied by the RF field is dissipated as heat in

the ferrite.

When the interaction between RF/Microwave field and electrons is reduced: Low losses in ferrite.


When H and M rotate in opposite direction:

Ferrite dissipates no time averaged power, and hence exhibits low losses.

• Hence a resonance (gyromagnetic) with

a peak of loss exists for microwave propagation in ferrites, for clockwise polarization of ${\bf H}$ coinciding with ${\bf M}$

a flat low loss for opposite polarization



• Hence a resonance (gyromagnetic) with

a peak of loss exists for microwave propagation in ferrites, for clockwise polarization of ${\bf H}$ coinciding with ${\bf M}$

a flat low loss for opposite polarization


Clockwise polarization:

$$B_t^+ = \mu_0 M^+ + B^+ = \mu_+ H^+$$

Anticlockwise polarization

$$B_t^- = \mu_0 M^- + B^- = \mu_- H^-$$

Two complex permeabilities μ_+ , μ_-




$$\mu_{+} = \mu'_{+} - j\mu''_{+}$$

$$\mu_{-} = \mu'_{-} - j\mu''_{-}$$

Real and imaginary parts of μ_{-} : are independent of applied steady magnetic field.

 μ_+ : Resonant behaviour at H_0 value




$$\mu_+ = \mu'_+ - \mathrm{j}\mu''_+$$

$$\mu_- = \mu'_- - j\mu''_-$$

Real and imaginary parts of μ_- : are independent of applied steady magnetic field.

 μ_+ : Resonant behaviour at H_0 value


Linearly polarized: Combination of Two circularly polarized. Therefore Non-reciprocal behaviour of ferrite materials to microwave propagation. $Re(\mu)$



$$\mu_{+} = \mu'_{+} - j\mu''_{+}$$
 $\mu_{-} = \mu'_{-} - j\mu''_{-}$

Plane circularly polarized wave propagating in H₀ direction will have two propagation constants

$$\beta^+ =$$
 $\beta^- =$




$$\mu_{+} = \mu'_{+} - j\mu''_{+}$$
 $\mu_{-} = \mu'_{-} - j\mu''_{-}$

Plane circularly polarized wave propagating in H₀ direction will have two propagation constants

$$\beta^+ = \omega \sqrt{\varepsilon \mu_+} = \frac{2\pi}{\lambda^+}$$
 Clockwise

$$\beta^- = \omega \sqrt{\varepsilon \mu_-} = \frac{2\pi}{\lambda^-}$$
 AntiClockwise

Which results in plane of polarization to rotate. (Non-reciprocal one)



$$\mu_{+} = \mu'_{+} - j\mu''_{+}$$
 $\mu_{-} = \mu'_{-} - j\mu''_{-}$

Plane circularly polarized wave propagating in H₀ direction will have two propagation constants


$$\beta^+ = \omega \sqrt{\varepsilon \mu_+} = \frac{2\pi}{\lambda^+}$$
 Clockwise

$$\beta^- = \omega \sqrt{\varepsilon \mu_-} = \frac{2\pi}{\lambda^-}$$
 AntiClockwise

Which results in plane of polarization to rotate. (Non-reciprocal pone)

Rotation of Electric field of linearly polarized wave passing through a magnetized ferrite is


Faraday rotation in ferrites.



$$\mu_{+} = \mu'_{+} - j\mu''_{+}$$
 $\mu_{-} = \mu'_{-} - j\mu''_{-}$ with $\beta^{+} = \omega\sqrt{\varepsilon\mu_{+}} = \frac{2\pi}{\lambda^{+}}$ (CW), $\beta^{-} = \omega\sqrt{\varepsilon\mu_{-}} = \frac{2\pi}{\lambda^{-}}$ (CCW)

Linearly polarized TEM wave propagates in ferrite along +z axis.

$$\mathbf{E} = \overline{a}_{x} E_{x}$$
 at $z = 0$




$$\mu_{+} = \mu'_{+} - j\mu''_{+}$$
 $\mu_{-} = \mu'_{-} - j\mu''_{-}$ with $\beta^{+} = \omega\sqrt{\varepsilon\mu_{+}} = \frac{2\pi}{\lambda^{+}}$ (CW), $\beta^{-} = \omega\sqrt{\varepsilon\mu_{-}} = \frac{2\pi}{\lambda^{-}}$ (CCW)

Linearly polarized TEM wave propagates in ferrite along +z axis.

$$\mathbf{E} = \bar{a}_x E_x$$
 at $z = 0$

The linearly polarized wave – decomposed into sum of CW and CCW circularly polarized waves.



$$\mu_{+} = \mu'_{+} - j\mu''_{+}$$
 $\mu_{-} = \mu'_{-} - j\mu''_{-}$ with $\beta^{+} = \omega\sqrt{\varepsilon\mu_{+}} = \frac{2\pi}{\lambda^{+}}$ (CW), $\beta^{-} = \omega\sqrt{\varepsilon\mu_{-}} = \frac{2\pi}{\lambda^{-}}$ (CCW)


Linearly polarized TEM wave propagates in ferrite along +z axis.

$$\mathbf{E} = \bar{a}_x E_x$$
 at $z = 0$

The linearly polarized wave – decomposed into sum of CW and CCW circularly polarized waves.

The component waves propagate at different phase constants β^+ , β^- .

Two electric field vectors rotate at different rates.




$$\mu_{+} = \mu'_{+} - j\mu''_{+}$$
 $\mu_{-} = \mu'_{-} - j\mu''_{-}$ with $\beta^{+} = \omega\sqrt{\varepsilon\mu_{+}} = \frac{2\pi}{\lambda^{+}}$ (CW), $\beta^{-} = \omega\sqrt{\varepsilon\mu_{-}} = \frac{2\pi}{\lambda^{-}}$ (CCW)

Over a distance λ , resultant polarized wave undergoes phase shift of $(\beta^+ + \beta^-)\lambda = 4\pi$


$$\lambda = \frac{4\pi}{\beta^{+} + \beta^{-}} = \frac{2\lambda^{+}\lambda^{-}}{\lambda^{+} + \lambda^{-}} \quad \text{with angle } \frac{(\beta^{+} - \beta^{-})\lambda}{2} = \frac{(\beta^{+} - \beta^{-})}{(\beta^{+} + \beta^{-})} 2\pi$$

Rotation per unit distance $\theta = \frac{(\beta^+ - \beta^-)\lambda}{2}$

Application in ferrite isolators



 Permeability tensor: Existence of magnetic dipole moments (due to primarily from electron spin)




- Permeability tensor: Existence of magnetic dipole moments (due to primarily from electron spin)
- · Magnetic dipole moment of an electron due to its spin

$$m = \frac{qh}{2m_e} = 9.27 \times 10^{-24} \text{A} - \text{m}^2$$

h: Plank's constant by 2π .

q: Electron charge

 m_e : mass of the electron



- Permeability tensor: Existence of magnetic dipole moments (due to primarily from electron spin)
- · Magnetic dipole moment of an electron due to its spin


$$m = \frac{qh}{2m_e} = 9.27 \times 10^{-24} \text{A} - \text{m}^2$$

h: Plank's constant by 2π .


q: Electron charge

 m_e : mass of the electron

 An electron in orbit around a nucleus gives rise to an effective current loop, thus an additional magnetic moment.



- An electron in orbit around a nucleus gives rise to an effective current loop, thus an additional magnetic moment.
- This is generally insignificant when compared to magnetic moment due to spin.



- An electron in orbit around a nucleus gives rise to an effective current loop, thus an additional magnetic moment.
- This is generally insignificant when compared to magnetic moment due to spin.
- Lande'g factor: measure of relative contributions of orbital moment and the spin moment to the total magnetic moment

q = 1 when moment is due only to orbital motion.

g = 2 moment is due to spin only.

Most ferrite materials: g: in the range of 1.98 - 2.01 (g=2)

