AR# 6192: Synopsys FPGA Compiler: writes out absolete timing constrains in XNF (basnu:179) / AR# 61920: Zynq-7000 - Errors when running PS USB Peripheral Driver Examples in (Xilinx Answer 58277)

### AR# 61920

# Zynq-7000 - Errors when running PS USB Peripheral Driver Examples in (Xilinx Answer 58277)

Search for Another Answer

## Description

I am following the steps in (Xilinx Answer 58277) to run PS USB Peripheral Driver Examples in OSL 2014.2.

However, I am receiving the following errors:

root@zynq:/mnt# insmod g\_mass\_storage.ko file=/tmp/my\_file

g\_mass\_storage: Unknown symbol fsg\_common\_set\_ops (err 0)

g\_mass\_storage: Unknown symbol fsg\_common\_set\_sysfs (err 0)

g\_mass\_storage: Unknown symbol fsg\_common\_run\_thread (err 0)

g\_mass\_storage: Unknown symbol fsg\_common\_free\_luns (err 0)

g\_mass\_storage: Unknown symbol fsg\_common\_create\_luns (err 0)

g\_mass\_storage: Unknown symbol fsg\_common\_set\_cdev (err 0)

g\_mass\_storage: Unknown symbol fsg\_common\_free\_buffers (err 0)

g\_mass\_storage: Unknown symbol fsg\_common\_set\_nluns (err 0)

g\_mass\_storage: Unknown symbol fsg\_common\_remove\_luns (err 0)

g\_mass\_storage: Unknown symbol fsg\_common\_set\_inquiry\_string (err 0)

g\_mass\_storage: Unknown symbol fsg\_common\_set\_num\_buffers (err 0)

g\_mass\_storage: Unknown symbol fsg\_config\_from\_params (err 0)

insmod: can't insert 'g\_mass\_storage.ko': unknown symbol in module, or unknown parameter

#### Solution

The example in (Xilinx Answer 58277) was running on an older kernel version.

For later branch kernels, (for example xilinx-v2014.2) some .ko files should be inserted first.

Feedback

Refer to below wiki link for more information on the Zynq Linux USB Device Driver.

http://www.wiki.xilinx.com/Zynq+Linux+USB+Device+Driver

Below are the required commands for the USB examples for mass storage and Ethernet in OSL 2014.2.

#### Mass storage:

```
insmod configfs.ko
insmod libcomposite.ko
insmod usb_f_mass_storage.ko

dd if=/dev/zero of=/tmp/my_file bs=1024 count=4096
insmod /mnt/g_mass_storage.ko file=/tmp/my_file
```

#### **Ethernet:**

```
insmod configfs.ko
insmod libcomposite.ko
insmod u_ether.ko
insmod usb_f_ss_lb.ko
insmod usb_f_ecm.ko
insmod usb_f_ecm_subset.ko
insmod usb_f_eem.ko
insmod usb_f_eem.ko
insmod usb_f_rndis.ko
insmod g_ether.ko
```

Was this Answer Record helpful?

Yes 🖒 No 🧖

# Feedback

#### **Linked Answer Records**

#### **Associated Answer Records**

\$\frac{1}{2}\$ Answer Number       \$\frac{1}{2}\$ Answer Title       \$\frac{1}{2}\$ Version Found       \$\frac{1}{2}\$ Version Resolved
---

Answer Number	Answer Title	Version Found	Version Resolved
58277	Zynq-7000 PS USB Peripheral Driver Examples - Mass Storage and Ethernet	N/A	N/A

AR# 61920		
Date	10/22/2014	
Status	Active	
Туре	General Article	
Devices	• SoC	

♠ ENGLISH ∨

© 2020 Xilinx

Privacy

Legal

Supply Chain Transparency

Contact

Feedback