Step 9 - Virtual Counter (CNTVCT_EL0) 1
Reference Note 1
Learning Objectives 1
1. What is CNTVCT_EL0? 1
2. Why Do We Need a Virtual Counter? 2
3. Architecture View 2
Counter Relationship 2
4. Physical vs Virtual Time 3
Physical Time 3
Virtual Time 3
5. Virtual Counter Formula 3
6. Example 1 - No Virtualization 4
7. Example 2 - Virtualization Enabled 4
8. Why Not Create Another Counter? 5
9. VM Startup Example 5
10. Physical and Virtual Counter Comparison 6
11. Relationship to Timers 6
Common Misconceptions 7
Misconception 1 7
Misconception 2 7
Misconception 3 7
Key Takeaways 8
Knowledge Check 8
Q1 8
Q2 8
Q3 8
Q4 8
Q5 9
Answer Key 9

Step 9 - Virtual Counter (CNTVCT_EL0)

Reference Note

This chapter is based on concepts described in the ARM Generic Timer Architecture documentation.

The Virtual Counter provides a **virtualized view of time** derived from the same System Counter used by the Physical Counter. It allows software to observe a timeline that differs from physical time while still using the same underlying hardware time source.

Learning Objectives

After completing this chapter, you should understand:

- Purpose of `CNTVCT_EL0`
- Difference between Physical and Virtual Time
- Relationship between `CNTPCT_EL0` and `CNTVCT_EL0`
- Why virtualization requires a virtual counter
- Introduction to `CNTVOFF_EL2`
- When Physical and Virtual counters are identical

1. What is CNTVCT_EL0?

`CNTVCT_EL0` is the **Virtual Counter Register**.

It provides a virtualized view of the System Counter.

Register	Purpose
CNTPCT_EL0	Physical Time
CNTVCT_EL0	Virtual Time

2. Why Do We Need a Virtual Counter?

Without virtualization:

Component	Time Seen
Hypervisor	Physical Time
Guest OS A	Physical Time
Guest OS B	Physical Time

Everyone sees:

The same time value

This can be problematic because:

- Guest OS can observe host uptime
- Guest migration becomes difficult
- VM snapshot/restore becomes difficult
- VM start time cannot be controlled

ARM solves this using a Virtual Counter.

3. Architecture View

Component	Description
System Counter	Master source of time
Physical Counter	Direct view of System Counter
Virtual Counter	Offset-adjusted view of System Counter

Counter Relationship

Source	Derived Counter

System Counter	CNTPCT_EL0
System Counter + Offset Logic	CNTVCT_EL0

4. Physical vs Virtual Time

Physical Time

Question answered:

What is the actual hardware time?

Accessed through:

CNTPCT_EL0

Virtual Time

Question answered:

What time should this software environment see?

Accessed through:

CNTVCT_EL0

5. Virtual Counter Formula

The Virtual Counter is calculated using:

CNTVCT = CNTPCT - CNTVOFF_EL2

where:

CNTPCT = Physical Counter
CNTVOFF_EL2 = Virtual Offset
CNTVCT = Virtual Counter

This is one of the most important formulas in the ARM Generic Timer architecture.

6. Example 1 - No Virtualization

Suppose:

Parameter	Value
CNTPCT	1,000,000
CNTVOFF_EL2	0

Calculation:

CNTVCT
=
1,000,000 - 0
=
1,000,000

Result:

Register	Value
CNTPCT	1,000,000
CNTVCT	1,000,000

The counters are identical.

7. Example 2 - Virtualization Enabled

Suppose:

Parameter	Value
CNTPCT	1,000,000
CNTVOFF_EL2	250,000

Calculation:

CNTVCT

=

1,000,000 - 250,000

=

750,000

Result:

Register	Value
CNTPCT	1,000,000
CNTVCT	750,000

The guest observes a different timeline.

8. Why Not Create Another Counter?

ARM could have implemented:

Option	Description
Counter #1	Physical Time
Counter #2	Virtual Time
Counter #3	Guest Time

Instead ARM implemented:

Component	Purpose
One System Counter	Real source of time
Offset Register	Virtualization mechanism

Benefits:

- Lower hardware complexity
- Better scalability
- Easier virtualization

9. VM Startup Example

Suppose:

Parameter	Value
Current Physical Counter	100,000,000
Desired Guest Start Time	0

Compute:

CNTVOFF_EL2 = 100,000,000

Result:

CNTVCT = 100,000,000 - 100,000,000 = 0

Guest believes:

System just booted

even though the hardware has been running much longer.

10. Physical and Virtual Counter Comparison

Feature	Physical Counter	Virtual Counter
Register	CNTPCT_EL0	CNTVCT_EL0
Time View	Hardware Time	Virtual Time
Uses Offset	No	Yes
Virtualization Support	No	Yes
Same System Counter Source	Yes	Yes

11. Relationship to Timers

The counters feed different timers.

Counter	Timer
CNTPCT_EL0	Physical Timer
CNTVCT_EL0	Virtual Timer

This means:

Timer Type	Time Source
Physical Timer	Physical Counter
Virtual Timer	Virtual Counter

Common Misconceptions

Misconception 1

Virtual Counter is a second hardware counter

False.

There is only one System Counter.

Misconception 2

CNTVCT always differs from CNTPCT

False.

When:

CNTVOFF_EL2 = 0

the counters are identical.

Misconception 3

Virtualization requires another clock

False.

ARM uses:

Offset-Based Virtualization

not a second clock source.

Key Takeaways

Concept	Key Point
CNTVCT_EL0	Virtual Counter Register
Purpose	Virtualized view of time
Source	System Counter
Formula	CNTVCT = CNTPCT − CNTVOFF_EL2
Additional Hardware Counter	Not required
Time Source	Same as Physical Counter

Knowledge Check

Q1

What does `CNTVCT_EL0` represent?

Q2

What is the relationship between `CNTPCT_EL0` and `CNTVCT_EL0`?

Q3

What is the purpose of `CNTVOFF_EL2`?

Q4

When are the Physical and Virtual Counters identical?

Q5

Does ARM use a second hardware counter for virtualization?

Answer Key

Question	Answer
Q1	Virtualized view of time
Q2	CNTVCT = CNTPCT − CNTVOFF_EL2
Q3	Defines the virtual time offset
Q4	When CNTVOFF_EL2 = 0
Q5	No. ARM uses offset-based virtualization