


VMS and ANPR User Manual

URI :- http://122.176.105.30:9125/


User Id:- admin

Password: - admin

1. Login Page



2. **Landing Dashboard Page**: The main dashboard provides an overview of all available features and camera feeds.




AJEEVI Technologies Pvt. Ltd. Microsoft Certified BizSpark Partner

Smart City IoT Hardware Manufacturer & Technology Integrators


Corporate Office: Unit NO. 505, Ansal API, Corporate Park, Sector-142, Noida, U.P- 201301
Toll Free NO: 1800-2740-100, Mobile NO. 9821820498, contactus@ajeevi.com, www.ajeevi.com



3. Live Feed: - Click on the "Live Feed" menu to view real-time camera footage.




4. Add Camera:- Add a new camera by selecting the "Add Camera" menu option.




5. **Recording**:- Access stored video recordings by clicking on "Storage" > "Recording".

Fb: www.facebook.com/ajeevitech, Twitter: www.twitter.com/ajeevitech, LinkedIn: www.linkedin.com/in/ajeevitech






6. **ANPR Details**:- View Automatic Number Plate Recognition (ANPR) details under the "ANPR" section.



 Video Analytics Alerts :- Get alerts based on the video analytics by selecting the "Video Analytics" menu.






8. Alert Image Viewing: - Click on an alert image to see a detailed view.



 User Management - Add User Management" > "Add User". Add new users and assign roles by navigating to "User





10. **User Management -** All Users Users"

View all existing users by clicking on "User Management" > "All

