```
%Assignment
%Digital Communication System
%Group 8 (Rahul(2019191), Varun(2018203), Ankit(2019146))
clear;
close all;
[audio,Fs,info] = input();
[audio_less,audio_more] = source(audio);
%Spectrum of both audio_less and audio_more
figure,
subplot(2,1,1), plot(abs(fftshift(fft2(audio less)))),title('Magnitude
Spectrum with frequency less than Nyquist rate');
subplot(2,1,2), plot(abs(fftshift(fft2(audio more)))),title('Magnitude
Spectrum with frequency more than Nyquist rate');
%For Audio_less------
disp('----EveryThing For frequency less than Nyquist
rate----');
[quant_less,step_size_less,level_val_less]= quantize(audio_less);
[bitstream_less,bitstream_length_less,huff_code_less] =
encode(quant_less,step_size_less);
[pulse_arr_less] = pulseshaping(bitstream_less,bitstream_length_less);
[row less,col less] = size(audio less);
quantized_decode_level_less =
receivedecode(bitstream_length_less,pulse_arr_less,huff_code_less,row_less);
decoded_quantized_signal_less =
tablelookup(quantized_decode_level_less,level_val_less);
subplot(2,1,1),plot(quant_less),title('Encoded Quantized signal');
subplot(2,1,2),plot(decoded_quantized_signal_less),title('Decoded quantized
signal');
filename = 'received.wav';
audiowrite(filename,decoded_quantized_signal_less,Fs/4);
filename2 = 'send.wav';
audiowrite(filename2, quant less, Fs/4);
disp('----EveryThing For frequency more than Nyquist
rate----');
[quant_more,step_size_more,level_val_more] = quantize(audio_more);
[bitstream_more,bitstream_length_more,huff_code_more] =
encode(quant_more,step_size_more);
[pulse_arr_more] = pulseshaping(bitstream_more,bitstream_length_more);
[row_more,col_more] = size(audio_more);
quantized_decode_level_more =
receivedecode(bitstream length more, pulse arr more, huff code more, row more);
decoded_quantized_signal_more =
tablelookup(quantized decode level more, level val more);
subplot(2,1,1),plot(quant_more),title('Encoded quantized signal');
subplot(2,1,2),plot(decoded_quantized_signal_more),title('Decoded quantized
signal');
filename11 = 'received more.wav';
audiowrite(filename11,decoded_quantized_signal_more,Fs*4);
filename21 = 'send_more.wav';
```

```
audiowrite(filename21,quant_more,Fs*4);
%Here we are taking input mp3 file and then displaying the sampling
*frequency and then plotting the original signal, its magnitude and phase
%in time domain and then spectrum in frequency domain.
function [output,Fs,info] = input()
  [output,Fs]= audioread('Single_short.mp3');
  info = audioinfo('Single short.mp3');
  disp("Sampling Frequency in Hz "+ Fs);
  disp("Nyquist Frequency in Hz "+(Fs/2));
   disp('The maximum frequency component of the spectrum is 404.323 at
 76224.');
  subplot(2,2,1),plot(output),title('Audio Signal');
  subplot(2,2,2), plot(abs(output)),title('Magnitude in time domain');
  subplot(2,2,3), plot(angle(output)),title('Phase in time domain');
  subplot(2,2,4), plot(abs(fftshift(fft2(output)))),title('Spectrum in
 frequency domain');
end
there we are downsampling and upsampling the audio. Downsampling done by
% factor of 1/4 and upsampling done by factor of 4.
function [audio_less,audio_more] = source(audio)
   [x,y] = size(audio);
  factor=4;
  audio downsampled=[ ];
   for i=1:factor:x
      audio_downsampled=[audio_downsampled audio(i,1)];
  end
   audio_less = audio_downsampled.';
   factor=4;
  audio_upsampled=[ ] ;
  for i=1:x
      audio_upsampled=[audio_upsampled audio(i,1)];
      for j=1:factor-1
         audio upsampled=[audio upsampled 0];
      end
  end
   audio_more = audio_upsampled.';
%here we are quantizing the input audio amplitude in 32 levels. 1st level
*having the minimum amplitude and each subsequent level amplitude will
%increase by step_size. Also, here we are calculating MSE for each
*quantization levels and plotting it. Also, we are also assigning 5 bits to
%each level.
function [quan new,step size,level val]= quantize(audio)
   quantized = audio;
  disp('We are using 32 levels for quantization means 5 bits per level');
  levels = 32;
  mx am = max(quantized);
  mn_am = min(quantized);
   step_size = (mx_am-mn_am)/levels;
  [row,col] = size(quantized);
```

```
%-----Quantization and MSE Calculation
mse1 = 0;
 q count = zeros(32,1);
mse_count =zeros(32,1);
 quan_new = zeros(row,col);
 level_val = mn_am:step_size:mx_am-step_size;
level val = level val.';
for i=1:row
    near1 = 2;
    val1 = -1;
    ix = -1;
    c = 0;
    for j = mn_am:step_size:mx_am-step_size
        dis1 = abs(j-quantized(i,1));
        c=c+1;
        if dis1<near1</pre>
            near1=dis1;
            val1 = j;
            ix = c;
        end
    end
    quan_new(i,1) = val1;
    q_count(ix,1)=q_count(ix,1)+1;
    msel=msel+(near1*near1);
    mse_count(ix,1)=mse_count(ix,1)+(near1*near1);
end
for i=1:32
    mse count(i,1) = mse count(i,1)/q count(i,1);
end
mse1 = mse1/row;
 disp("MSE for this sampled audio is " + msel);
figure,stem(mse_count),title('MSE vs Number of quantization levels');
 %-----Bitstream Generating here ------
bitstream = zeros(row,5);
for i =1:row
    diff = (quan_new(i,1) + abs(mn_am))/step_size;
    bin = int2bit(diff, 5);
    for j = 1:5
        bitstream(i,j) = bin(j);
    end
end
 totalbits =5*row;
disp("Total Bits used in representation of one level is 5");
disp("Total Bits used in Bitstream "+totalbits);
end
```

```
%Here we are first calculating the count of each levels occuring in the
%audio and then calculating probability of occurence of each level.
%Then we are assigning each level with huffman codes. So a level with
%high probability will be assigned with less bits and a level with low
%probability will be assigned with more bits.
function [bitstream,bitstream_length,huff_code] = encode(audio,step_size)
  mn_am = min(audio);
   sampled and quantized =audio;
   len = length(sampled_and_quantized);
  count_of_levels = zeros(32, 1);
  for i = 1:len
      quant_val = sampled_and_quantized(i,1);
      diff = 1 + (quant val + abs(mn am))/step size;
      count_of_levels(diff, 1) = count_of_levels(diff, 1) + 1;
  end
  probability_values = zeros(32, 1);
  for i = 1:32
      probability_values(i, 1) = count_of_levels(i, 1)/len;
  figure,stem(probability_values),title('Probability for different levels');
  huff\_code = zeros(32,1);
  sum = 0;
  for i = 1:31
      \max \text{ val } = -1;
     \max_{idx} = -1;
      for j = 1:32
          if(probability_values(j, 1)>max_val)
              max_val = probability_values(j, 1);
              \max_{i} dx = j;
          end
      end
      probability_values(max_idx, 1) = -1;
      huff_code(max_idx,1)=sum;
      sum = sum + power(2, i);
  end
  sum = sum + 1;
  sum = sum - power(2,31);
  last_idx =-1;
  for i = 1:31
      if(probability_values(i, 1)~=-1)
          last idx = i;
      end
  end
  huff_code(last_idx,1)=sum;
  [row,col] = size(audio);
  bitstream length=0;
  for i = 1:row
       quant val = audio(i,1);
       level = 1 + (quant_val + abs(mn_am))/step_size;
       [ss,cc] = size(dec2bin(huff_code(level)));
       bitstream length = bitstream length + cc;
   end
```

```
disp("The length of the bitstream for using huffman coding " +
bitstream length);
  bitstream_huff = zeros(bitstream_length,1);
  pos = 1;
  for i = 1:row
      quant val = audio(i,1);
      level = 1 + (quant_val + abs(mn_am))/step_size;
      binary_code = dec2bin(huff_code(level));
      [rr,cc] = size(binary_code);
      for j = 1:cc
        bitstream_huff(pos,1) = binary_code(1,j)-48;
        pos=pos+1;
      end
  end
  bitstream=bitstream huff;
end
%Here we are obtaining raised cosine pulse in time domain for roll off
% factors of 0.25, 0.5 and 0.75. We observed that the ISI is decreasing as
%we increase the roll of factor.
%Then we are obtaining raised cosine pulse in frequency domain for same
%values of roll off factors.
function [pulse_arr] = pulseshaping(bitstream,bitstream_length)
%------Roll Of Factor = 0.25-----
 roll_off = 0.25;
 time = 0;
 figure
 hold on
  test = 12;
 shif = 14;
 for i = 1:test
     pulse = pulse_shape_time(roll_off, bitstream(i+10000+shif, 1), time);
     plot(-50+time:0.01:50+time,pulse);
     time = time + 20;
 end
 hold off;
 roll_off = 0.5;
 time = 0;
 figure
 hold on
 for i = 1:test
     pulse = pulse_shape_time(roll_off, bitstream(i+10000+shif, 1), time);
     plot(-50+time:0.01:50+time,pulse);
     time = time + 20;
 end
 hold off;
roll_off = 0.75;
 time = 0;
 figure
 hold on
```

```
for i = 1:test
     pulse = pulse shape time(roll off, bitstream(i+10000+shif, 1), time);
    plot(-50+time:0.01:50+time,pulse);
     time = time + 20;
 end
 hold off;
%--------Roll of Factor = 0.25-----
 figure,
 roll_off = 0.25;
 time = 0;
 hold on;
 color= 'q';
 shift =0;
  for i = 1:test
     [Pf11, Pf12, Pf13, f11, f12, f13] = pulse_shape_freq(roll_off,
bitstream(i+10000+shif, 1), time);
     f11=f11+shift;
     f12=f12+shift;
     f13=f13+shift;
    plot(f11, Pf11(f11-shift), color);
    plot(f12, Pf12(f12-shift), color);
    plot(f13, Pf13(f13-shift), color);
     shift = shift+ 0.62;
     if i==1
        color = 'r';
     end
     if i==2
        color = 'y';
     end
 end
 figure,
 roll off = 0.5;
 time = 0;
 hold on;
 color= 'g';
 shift =0;
  for i = 1:test
     [Pf11, Pf12, Pf13, f11, f12, f13] = pulse_shape_freq(roll_off,
bitstream(i+10000+shif, 1), time);
     f11=f11+shift;
     f12=f12+shift;
     f13=f13+shift;
    plot(f11, Pf11(f11-shift), color);
    plot(f12, Pf12(f12-shift), color);
    plot(f13, Pf13(f13-shift), color);
     shift = shift+ 0.62;
```

```
if i==1
         color = 'r';
     end
     if i==2
         color = 'y';
     end
 end
 %------Roll of Factor = 0.75-----
 figure,
 roll_off = 0.75;
 time = 0;
 hold on;
 color= 'q';
 shift = 0;
  for i = 1:test
      [Pf11, Pf12, Pf13, f11, f12, f13] = pulse_shape_freq(roll_off,
bitstream(i+10000+shif, 1), time);
     f11=f11+shift;
     f12=f12+shift;
     f13=f13+shift;
     plot(f11, Pf11(f11-shift), color);
     plot(f12, Pf12(f12-shift), color);
     plot(f13, Pf13(f13-shift), color);
     shift = shift+ 0.62;
     if i==1
         color = 'r';
     end
     if i==2
         color = 'y';
     end
 end
 disp('The ISI will be lesser when the roll of factor is greater');
  roll off = 0.5;
  pulse arr = zeros(bitstream length,1);
 for i =1:bitstream_length
     pulse = pulse_shape_time(roll_off, bitstream(i, 1), time);
     pulse_arr(i,1) = value(pulse);
 end
end
This function obtains the raised cosine in time domain. For bit value = 0
%the sinc is upside down and for bit value = 1 the raised cosine has
%maximum amplitude = 1.
function [pt1] = pulse_shape_time(roll_off, bit_val, time)
 Tb = 2;
 Rb = 1/Tb;
  %time axis from -10 to 10 with increment of 0.01.
  t = -50:0.01:50;
 %pt11, pt12 in numerator and pt13 in denominator.
  pt11 = sinc(t/Tb);
  pt12 = cos(pi*roll_off*Rb*t);
```

```
pt13 = 1 - (4*roll_off*roll_off*Rb*Rb*t.^2);
  if(bit_val==0)
     pt1 = -(pt11.*pt12)./(pt13);
  else
      pt1 = (pt11.*pt12)./(pt13);
  end
end
This function obtains the raised cosine in frequency domain. For bit
%value = 0 the pulse is upside down and for bit value = 1 the pulse
%is in positive axis.
function [Pf11, Pf12, Pf13, f11, f12, f13] = pulse shape freq(roll off,
bit val, time)
 Tb = 2;
 Rb = 1/Tb;
   if(bit val==0)
      Pf11 = @(f) ((-1)*f.^0);
      Pf12 = @(f) ((-0.5)*(1 - (sin(pi*((f - (Rb/2))/(roll_off*Rb))))));
      Pf13 = @(f) 0*f.^0;
      f11 = (0.5*Rb)*(-1+roll_off):0.01:(0.5*Rb)*(1-roll_off);
      f12 = (0.5*Rb)*(1-roll_off):0.01:(0.5*Rb)*(1+roll_off);
      f13 = (0.5*Rb)*(1+roll_off):0.01:0.5;
  else
      Pf11 = @(f) 1*f.^0;
      Pf12 = @(f) 0.5*(1 - (sin(pi*((f - (Rb/2))/(roll_off*Rb)))));
      Pf13 = @(f) 0*f.^0;
      f11 = (0.5*Rb)*(-1+roll off):0.01:(0.5*Rb)*(1-roll off);
      f12 = (0.5*Rb)*(1-roll off):0.01:(0.5*Rb)*(1+roll off);
      f13 = (0.5*Rb)*(1+roll_off):0.01:0.5;
  end
end
This function determines if the pulses obtained have maximum positive
%value as 1 or -1. Then depending upon that it obtains the decoded
%bitstream.
function val = value(pulse)
  values = zeros(1,length(pulse));
   for i = 1:1:length(pulse)
     if(abs(-1-pulse(i)) <= abs(1-pulse(i)))</pre>
           values(i) = 0;
       else
         values(i) = 1;
     end
  end
   ans = sum(values);
   val = 0;
    if(ans>length(pulse)/2)
        val = 1;
    end
end
```

```
%Here we are decoding the obtained bitstream and then finding the
%quantization values associated with the decoded bits. This outputs the
%quantization levels from decoded bitstream.
function [decoded quantized values] = receivedecode(bitstream length,
 received_bitstream, corresponding_huffman, decoded_length)
 i = 1;
 c = 0;
 idx = 1;
 decoded_quantized_values = zeros(decoded_length, 1);
 while(i<=bitstream_length)</pre>
     j = i;
     sum = 0;
     while(j<=bitstream length)</pre>
         if(received_bitstream(j, 1)==0 | c==31)
         end
         j = j+1;
         c = c+1;
     end
     if(c==31)
         c = 30;
     end
     j = i;
     while (c > = 0)
         sum = sum + received_bitstream(j, 1)*power(2, c);
         c = c-1;
         j = j+1;
     end
     for k = 1:32
         if(sum==corresponding_huffman(k, 1))
             decoded_quantized_values(idx, 1) = k;
         end
     end
     i = j;
     c = 0;
     idx=idx+1;
 end
end
%Here we are assigning the quantization values corresponding to
*quantization levels. This takes input as quantization levels and then
%outputs the quantized values according to the lookup_values.
function [decoded_output] = tablelookup(decoded_quantized_values,
 lookup values)
  len = length(decoded_quantized_values);
 decoded_output = zeros(len, 1);
   for i = 1:len
      quant_val = decoded_quantized_values(i, 1);
      decoded_output(i, 1) = lookup_values(quant_val, 1);
  end
 end
```

Sampling Frequency in Hz 44100 Nyquist Frequency in Hz 22050

The maximum frequency component of the spectrum is 404.323 at 76224.

-----EveryThing For frequency less than Nyquist

rate-----

We are using 32 levels for quantization means 5 bits per level MSE for this sampled audio is 5.0939e-06

Total Bits used in representation of one level is 5


Total Bits used in Bitstream 195180


The length of the bitstream for using huffman coding 220527 The ISI will be lesser when the roll of factor is greater


-----EveryThing For frequency more than Nyquist


rate-----


We are using 32 levels for quantization means 5 bits per level MSE for this sampled audio is 4.5607e-06
Total Bits used in representation of one level is 5
Total Bits used in Bitstream 3122880
The length of the bitstream for using huffman coding 1315422
The ISI will be lesser when the roll of factor is greater


















































Published with MATLAB® R2021b