bdd Solcelle Solcelle Ports: in Power: 5V in Control: 24V out CellePower: 10V in Sollys: stråling out SolarControler: 20V In ground: 0V Solcelle Sensor Switch Ports: Ports: Ports: out Solspænding: 20V in Power: 5V in Control: 24V in sollys: stråling out Cellepower: 10V In Solspænding: 20V In Solsensspænding: 20V In ground: 0V out Solsensspænding: 20V out SolarControler: 20V