SURVEYING & LEVELLING

- 1. The important instrument used for measuring horizontal and vertical angles in surveying is Theodolite.
- 2. A branch of surveying in which horizontal and vertical distances are determined by taking angular observations with an instrument is known as Tacheometry survey.
- 3. The lower silved plate is the main scale plate graduated ranging from in clock wise direction is 0° to 360°.
- 4. The vertical axis of the theodolite is the axis about which the instrument rotates in the horizontal plane is called as azimuthal axis.
- 5. It is an imaginary line passing through the intersection of the cross hairs of the diaphragm and the optical center of the objectives is called as line collimation.
- 6. The line joining the points of commencement to point of tangency is called long chord.
- 7. The method generally adopted, where degreg of accuracy desired in the measurement of horizontal angle is Reiteration method.
- 8. The processing of setting the theodolite exactly over station mark is known Centering.
- 9. The line passing through the center of the inner spindle, outer spindle and bearing in the tribach is known as Vertical axis.
- 10. The angle on vertical circle other than zero is called 360° or Index error
- 11. A curve whose radius varies gradually from infinity to finite value equal to the radius of circular curve to be connected is known as transition curve.
- 12. The grid method is used when the area to be contoured is small and ground is not much undulating.
- 13. The plumb bob is used for Centreing the instruments exactly over the ground station.
- 14. In Indirect method of contouring, reduced level of a point is also called Spot level.
- 15. The contouring method used for determination of contours along a fixed route such as roads is cross section method.
- 16. The area enclosed by various contours can be measured by Planimeter.

- 17. The process of placing the contours proportionally between the plotted ground points is called interpolation contour.
- 18. The angle between the back tangent and the forward tangent Is known s Angle of intersection.
- 19. The principle of tachometry is based on the property of Isosceless triangle.
- 20. Reconnaissance survey is to be conducted before the selection of survey station.
- 21. The accuracy of the electromagnetic distance measurement is 10⁵.
- 22. Least count is the smallest value that can be read from the instrument.
- 23. The curve which is having a single arc of circle connecting the two straight is called simple curve.
- 24. Length of long chord (L) in terms of geometry of curve is $\frac{2r \sin(\theta/2)}{\theta}$.
- 25. The least count of vernier is 20".
- 26. Regular curve pattern followed by a railway (or) highway alignment is called Curve.
- 27. The process of turning the telescope about the axis in a horizontal plane through 180° is known as Reversing.
- 28. Expand EDM- Electronic distance measurement.
- 29. The leveling head is usually consists of two parallel triangular plates are know as Tribach plate.
- 30. The instrument which is a combination of an electronic theodilite and an electronic distance meter is know as Total station.
- 31. Horizontal axis is also called as trunion axis.
- 32. The vertical circle of the theodilite is on the left side of the observer and the observation taken is called as Face left observation.
- 32. Electronic Theodolite is also called as Theomat.
- 33. The transits are most commonly used In precise work.
- 34. Expand GPS Global position system.
- 35. Expand ODM- Optical distance measurement.



- 36. Distomat use Infra-red rays to measure distance.
- 37. Least count of Theodolite is 20 seconds.
- 38. Expand FRL Finished road level.
- 39. Surveying is the art of measuring slope, horizontal and vertical distance between objects.
- 40. In plane tabiling inaccessible points may be located by the Intersection method.

THANK YOU