



Carefully Made Shaft Collars and Couplings
Since 1937

One-Piece Rigid Coupling Installation Instructions

Part Number: MCLC-25-25-F

1. Align the coupling on the two shafts to be connected. There should be no misalignment.
2. Tighten the M6 Nypatch® screws in two stages. Starting with the inside screws, tighten to half the recommended seating torque of 16 Nm. Repeat for the outside screws, again tightening to half of the recommended seating torque.
3. On two-piece couplings be sure to maintain the gap between the two halves during installation.
4. Tighten screws to the full recommended seating torque of 16 Nm following the same pattern, beginning with the inside screws first.

http://www.ruland.com/ti_installation-rigid-coupling.php?recordID=MCLC-25-25-F