

base taps Q W F Р В R S Т G Α Z X C D ٧ sticky shift bkspc nav


7	L	U	Υ	, -
M	N	Е	-	0
К	н	!	= .	? /
space	key repeat			
	_			


					•
	insert				
	return option		tab <mark>cmd</mark>		
	esc		delete		
•			shift	bkspc	
		,			S


			_	
	end	home		
left	down	up	right	
	page down	page up		
space ctrl	key repeat			











		up				
	left	down	right	middle click		
scroll left	scroll down	scroll up	scroll right			
left click	right click					

				num
option	cmd			
		shift	bkspc	

				1
	7	8	9	
-	4	5	6	0
-	1	2	3	/
space ctrl	key repeat			

	2x clr 3x clr all	ext pwr off	tog out bt II usb	
bt sel	bt sel 2	bt sel 1	bt sel 0	bt sel 4
bt disc	bt disc 2			

	bright up	vol up	
	bright down	vol dn	
play pause	next		

