EE910: Digital Communication Systems-I

Adrish Banerjee

Department of Electrical Engineering Indian Institute of Technology Kanpur Kanpur, Uttar Pradesh India

April 25, 2022



Lecture #3A: Digital Modulation: An Introduction



Introduction

- In a digital communication system, the source to be transmitted is discrete both in time and amplitude
- Digital information carrying signals must be first converted to an analog waveform prior to transmission
- At the receiving end, analog signals are converted back to a digital format before presentation to the end user
- The conversion process at the transmitting end is known as modulation
- The receiving end is known as demodulation or detection
- In digital wireless communication systems, the modulating signal may be represented as a time sequence of symbols or pulses, where each symbol has M finite states.
- Each symbol represents n bits of information where n = log₂ M bits/symbol.



Adrish Banerjee EE910: Digital Communication SystemsDepartment of Electrical Engineering Indian Institute of Technology Kanpur Kanpur, Uttar Pradesh India

Advantages of Digital Modulation over Analog

- Greater noise immunity (due to its finite process)
- Robustness to channel impairments
- Easier multiplexing of various forms of information like voice, data, video
- Security -by using coding techniques to avoid jamming
- Accommodation of digital error control codes which detect and/or correct transmission errors
- Equalization to improve the performance of over all communication link
- Supports complex signal conditioning and processing methods



Introduction

- Factors that influence digital modulation:
 - Low BER at low received signal-to-interference noise ratio (SINR)
 - Should performs well in multi-path and fading
 - Should have high spectral efficiency
 - Essentially, good BER performance at a low SINR under conditions of co-channel interference, and fading.
- The performance of a modulation scheme is often measured in terms of its power efficiency and bandwidth efficiency.
- The power efficiency is the ability of a modulation technique to preserve the fidelity (acceptable BER) of the digital message at low power levels
- Bandwidth efficiency is a measure of how many bits per symbol that we can reliably send over the communication system.



Adrish Banerjee

<u>EE9</u>10: Digital Communication Systems-I

Department of Electrical Engineering Indian Institute of Technology Kanpur Kanpur, Uttar Pradesh India

Introduction

- The source information is normally represented as a baseband (low-pass) signal
- Because of signal attenuation, it is necessary to move the baseband signal spectrum to reside at a much higher frequency band centered at f_c , called the carrier frequency, in the radio spectrum
- At the receiver end, the demodulation process removes the carrier frequency to recover the baseband information signal
- We choose different carrier frequencies for different signals
- Modulation/demodulation process facilitates channel assignment and reduces interference from other transmissions
- The modulation can be classified into two categories:
 - Linear modulation
 - Nonlinear modulation
- Also modulation can be memoryless or with memory.



Memoryless Modulation

- ullet In a memoryless modulation scheme, the binary sequence is parsed into subsequences each of length k.
- Each sequence is mapped into one of the $s_m(t)$, $1 \le m \le 2^k$, signals regardless of the previously transmitted signals.
- This modulation scheme is equivalent to a mapping from $M=2^k$ messages to M possible signals as shown in figure.



4□ > 4□ > 4 = > 4 = > ■ 900

Adrish Banerjee EE910: Digital Communication Systems-I Department of Electrical Engineering Indian Institute of Technology Kanpur Kanpur, Uttar Pradesh India

Modulation with memory

- In a modulation scheme with memory, the mapping is from the set of the current k bits and the past (L-1)k bits to the set of possible $M=2^k$ messages.
- In this case the transmitted signal depends on the current k bits as well as the most recent L-1 blocks of k bits. This defines a finite-state machine with $2^{(L-1)k}$ states.



Modulation with memory

• If at time instant $\ell-1$ the modulator is in state $S_{\ell-1} \in \{1,2,...,2^{(L-1)k}\}$ and the input sequence is $I_\ell \in \{1,2,...,2^k\}$, then the modulator transmits the output $s_{m_\ell}(t)$ and moves to new state S_ℓ according to mappings

$$m_{\ell} = f_m(S_{\ell-1}, I_{\ell}) \tag{1}$$

$$S_{\ell} = f_{\mathfrak{s}}(S_{\ell-1}, I_{\ell}) \tag{2}$$

- Parameters k and L and functions $f_m(\cdot, \cdot)$ and $f_s(\cdot, \cdot)$ completely describe the modulation scheme with memory.
- Parameter *L* is called the constraint length of modulation.



Adrish Banerjee EE910: Digital Communication Systems-I Department of Electrical Engineering Indian Institute of Technology Kanpur Kanpur, Uttar Pradesh India

Representation of digitally modulated signals

- The case of L=1 corresponds to a memoryless modulation scheme.
- The modulator in a digital communication system maps a sequence of k binary symbols which in case of equiprobable symbols carries k bits of information into a set of corresponding signal waveforms $s_m(t)$, $1 \le m \le M$, where $M = 2^k$.



Representation of digitally modulated signals

- We assume that these signals are transmitted at every T_s seconds, where T_s is called the signaling interval.
- This means that in each second

$$R_s = \frac{1}{T_s} \tag{3}$$

symbols are transmitted.

- Parameter R_s is called the signaling rate or symbol rate.
- ullet Since each signal carries k bits of information, the bit interval T_b , i.e., the interval in which 1 bit of information is transmitted, is given by

$$T_b = \frac{T_s}{k} = \frac{T}{\log_2 M} \tag{4}$$

40 > 4A > 4E > 4E > E 990

Adrish Banerjee EE910: Digital Communication Systems-I Department of Electrical Engineering Indian Institute of Technology Kanpur Kanpur, Uttar Pradesh India

Representation of digitally modulated signals

• The bit rate R is given by

$$R = kR_s = R_s \log_2 M \tag{5}$$

• If the energy content of $s_m(t)$ is denoted by \mathcal{E}_m , then the average signal energy is given by

$$\mathcal{E}_{avg} = \sum_{m=1}^{M} p_m \mathcal{E}_m \tag{6}$$

where p_m indicates the probability of the m-th signal (message probability).



Representation of digitally modulated signals

ullet In the case of equiprobable messages, $p_m=rac{1}{M}$, and therefore,

$$\mathcal{E}_{\text{avg}} = \frac{1}{M} \sum_{m=1}^{M} \mathcal{E}_{m} \tag{7}$$

- ullet If all signals have the same energy, then $\mathcal{E}_{\it m}=\mathcal{E}$ and $\mathcal{E}_{\it avg}=\mathcal{E}.$
- The average energy for transmission of 1 bit of information, or average energy per bit, when the signals are equiprobable is given by

$$\mathcal{E}_{bavg} = \frac{\mathcal{E}_{avg}}{k} = \frac{\mathcal{E}_{avg}}{\log_2 M} \tag{8}$$

4 D > 4 A > 4 B > 4 B > B = 40 Q A

Adrish Banerjee EE910: Digital Communication Systems-I Department of Electrical Engineering Indian Institute of Technology Kanpur Kanpur, Uttar Pradesh India

Representation of digitally modulated signals

ullet If all signals have equal energy of ${\mathcal E}$, then

$$\mathcal{E}_b = \frac{\mathcal{E}}{k} = \frac{\mathcal{E}}{\log_2 M} \tag{9}$$

• If a communication system is transmitting an average energy of \mathcal{E}_{bavg} per bit, and it takes T_b seconds to transmit this average energy, then the average power sent by the transmitter is

$$P_{avg} = \frac{\mathcal{E}_{bavg}}{T_b} = R\mathcal{E}_{bavg} \tag{10}$$

which for the case of equal energy signals becomes

$$P = R\mathcal{E}_b \tag{11}$$

EE910: Digital Communication Systems-I

Department of Electrical Engineering Indian Institute of Technology Kanpur Kanpur, Uttar Pradesh India