

VNM APEX WHEEL

Quick Guide





















- VNM Apex Wheel
- USB A male to GX-12 male spring cable
- Allen key set and Mounting screws
- **Button Stickers**
- Wire for Slipring




- RS-485 Port
- GX-12 Port connect to PC via spring cable
- Reset/DFU (Short press for Reset/ Long press 3s for into DFU mode)
- Header Port connect via slipring




Paddle is adjustable horizontally:

- Paddle Shifter zone: 0 13,5mm
- Paddle Clutch zone: 0 13,5mm







Adjust VNM Paddle Shifter





- 1. Paddle Shifter
- 2. Hexagon Head Allen H2.5
- 3. Magnet D12x4






Add a magnet to increase the strength of the Paddle Shifter





Turning the knob to up or down the trip of paddle shifter



Mounting Dimention VNM Apex Wheel

