# A/V Angel Self-Training: Camera

August 10, 2025

C3VOC



https://github.com/voc/engelschulung

#### General

- We will stream, record and publish nearly all talks with your help
- You can operate the cameras and video mixer
- At do-not-record talks we also need angels
- We (people from c3voc) will be there to help
- The live stream video signal will also be the final recording
- We aim for consistent quality, but everybody make mistakes don't blame yourself!

# Camera Hardware

#### Hardware Camera Controls Panasonic



Figure 1: Panasonic Cam

Cameras are in manual mode because of difficult lighting situation.

**Left Ring/red** Focus - control sharpness of the image.

Middle Ring/green Zoom - vary the focal length.

Right Ring/blue Iris - will have to be adjusted throughout the day. If there is anything wrong, contact C3VOC helpdesk.

#### **Zoom Control Panasonic**



- For smooth zoom use the zoom buttons.
- Gentle touch ⇒ slow zoom
- Top Buttons fixed speed

Figure 2: Panasonic Cam

### Display Indicators Panasonic



Figure 3: Panasonic Display Indicators

**Rec Indicator** The recording must always run, even during the break.

Focal Indicator Use only manual focus!

Remaining Time It must have enough remaing time before talk.

#### Alert

Alert the A/V-Technician if something's wrong.

### Hardware Camera Controls JVC



Figure 4: JVC Cam

Cameras are in manual mode because of difficult lighting situation.

**Left Ring/red** Focus - control sharpness of the image.

Middle Ring/green Zoom - vary the focal length.

Right Ring/blue Iris - will have to be adjusted throughout the day. For lighting issues talk to the A/V tech via intercom.

### Zoom Control JVC



- For smooth zoom use the zoom buttons.
- Gentle touch ⇒ slow zoom
- Top Buttons fixed speed

Figure 5: JVC Cam

# Display Indicators JVC



Figure 6: Panasonic Display Indicators

Rec Indicator The recording must always run, even during the break.

Focal Indicator Use only manual focus!

#### **Alert**

Alert the A/V-Technician if something's wrong.

# Tripod



**Figure 7:** Tripod

- Should be level check the water bubble.
- Variable brakes can be adjusted to your needs.
- Tilt axis should be balanced, so that the camera doesn't tilt up or down on its own.
- Pan axis is needed all of the time. Set it so you can do smooth pans all over the stage.

#### **Alert**

Alert the A/V-Technician if something's wrong or misplaced.

### **SD-Card Recording**

- Two SD-Cards in every Camera
- Backup Recording
- Turn on Recording before first shift in the morning -> Red Dot somewhere in the Display.
- Control Recording Time remaining.

#### **Alert**

Alert the A/V-Technician if something's wrong or not running.

# Next Steps

### Hands-On Training

- Please do hands-on training!
  - The only way to get proficient with the tripod is to feel it
  - Feel free to try things in a break between talks
- VOC A/V-Techs are there to help you