


# LED Matrix Panel

## 16 Series Display Screen

### User Manual



Please read the user manual carefully before use


CoolLEDM ①

## General User Manual

### Product Introduction


This product is a package of LED flexible display screen. It is controlled by a mobile app and a remote control, and supports various functions such as text input, animation, graffiti, and rhythm. It is characterized by being lightweight, flexible, waterproof, and easy to install. It is often used in places such as car rear window glass, shop window glass, industrial zone entrances, and parking lot entrances.

### Product Accessories



Note: The USB version is powered directly through the USB interface and does not include a power adapter.

### Connection Diagram



1


## General User Manual

### Precautions

1. Do not excessively bend or forcefully tear the screen, as it may damage the screen circuit.
2. Do not use other power adapter to power the device, as it may damage the device.
3. Before pasting and installing, ensure that the surface of the pasted position is clean and dry.


### APP Download

Please scan the QR code with a "Browser" to download the application. Alternatively, search for "CoolLED1248" in the App Store or Google Play to download the app.



(3 in 1)

If you are unable to scan this 3-in-1 QR code for download, you can also scan the following two QR codes for download.




2

## General User Manual

### Connect the device

Before connecting the device, please connect the device correctly according to the connection diagram, power on the device, and keep the device turned on to ensure successful connection and use.

1. Please allow the application to request the necessary permissions to ensure the normal operation of the application.
2. To use the application, the phone's Bluetooth needs to be turned on. Please authorize the opening of Bluetooth in the application.



3. The application will automatically search for the display device and display it in the device list. If the search fails, pull down to refresh the device list to search again.
4. Please click on the device to be connected and wait for the device to connect successfully. If the connection fails, pull down to refresh the device list and reconnect the device.

**Warning:** Do not use Bluetooth in your phone's settings to connect your device! Please open the APP and connect the device in the device list.


3

## General User Manual

### APP Interface Description

Note: The interface description below is for reference only, and the actual interface of the app may be updated. Please refer to the actual interface.

#### 1. Device List



- Tips:
1. Please pull down to search for devices.
  2. If the device cannot be found after multiple searches, please check if the permissions are turned on and turn the device off and on again.

4

## General User Manual

#### 2. Program List



Note: The program numbers on this interface correspond to the program numbers on the remote control panel.

5

## General User Manual

#### 3. Add Text



6

## General User Manual

#### 4. Add Graffiti



7

## General User Manual

#### 5. Add Animation



#### 6. Material



8

## General User Manual

#### 7. Pixel Editing



Instructions for using the toolbar:

- 1. The paintbrush icon allows you to draw pixels in the editing area when selected.
- 2. The clear icon allows you to clear all pixel content when clicked.
- 3. The eraser icon allows you to erase unwanted pixels in the editing area when selected.
- 4. The move icon allows you to move the pixel editing area when selected. (This function is only effective when the pixel area exceeds the display area.)
- 5. The zoom out button allows you to zoom out the pixel editing area when clicked.
- 6. The zoom in icon allows you to zoom in the pixel editing area when clicked.

Note: You can also zoom the editing area by placing two fingers on the area and spreading them apart or pinching them together.

9

## General User Manual

#### 8. Rhythm



Note: Some devices may not support the "Device microphone" function.

10

## General User Manual

#### 9. Settings



11

## General User Manual

#### 10. Editing Toolbar




Instructions for use:

- 1. The edit button allows you to edit the content again when clicked.
- 2. The copy button allows you to copy the content when clicked.
- 3. The delete button allows you to delete the content when clicked.
- 4. The top button allows you to bring the content to the top when clicked.
- 5. The bottom button allows you to send the content to the bottom when clicked.
- 6. The order adjustment button allows you to drag and adjust the content order by holding it down and moving it up or down.

12

## General User Manual

### Remote Control Instructions



Remote Control Binding and Unbinding:

1. Confirm that the device is in normal working condition.
2. Press and hold the "ON" button on the remote control for about 5 seconds. The screen controller will make a "Beep" sound and display a "Binding Icon" to indicate a successful binding.
3. Press and hold the "OFF" button on the remote control for about 5 seconds. The screen controller will make a "Beep" sound and

13

## General User Manual

Note:

1. Please pull out the battery gasket of the remote control before use.
2. The maximum communication distance of the remote control is 5 meters. Please use it within the effective range.
3. The program numbers on the remote control correspond to the program numbers in the program list of the app. If the app does not have content corresponding to the selected program number, the default content will be displayed.
4. If you select the auto power off function, it will be disabled if you turn off the device using the remote control or the app before the scheduled power off time.
5. After successful binding, only the bound remote control can control the device.

### Help and Feedback

1. If you want to know more about the product, usage operations, and solutions to common problems, please check the [Help Center] in the APP settings menu.
2. If you have any comments, suggestions or need help about our products, please contact us through [Contact Us] in the APP settings menu.

14