

OPERATION AND MAINTENANCE MANUAL – PART 8

EXCITATION SYSTEM – DRAWINGS AND PART LISTS

DOCUMENT NO.: VIN/90/PCS/400018/EX/OMM008/A

Plant Name : VINH-SON HYDRO POWER STATION
Location : VIETNAM
Plant Type : STATIC EXCITATION SYSTEM
Plant Rating : 40MVA

A	Revised after Commissioning	2011-10-20	HL Cheng	Davor Tomerlin	Davor Tomerlin
-	Initial Issue	2011-04-20	HL Cheng	Davor Tomerlin	Davor Tomerlin
Rev	Description	Date	Prepared	Checked	Approved
					

Copyright © ALSTOM 2008. We reserve all rights in this document and in the information contained therein. Reproduction, use or disclosure to third parties without express authority is strictly forbidden.

SOMMAIRE / TABLE OF CONTENTS

Chapters		Remarks	
		Yes	No
Section 8	Drawings and parts lists		
8.1	List of equipment drawings		
8.2	Data sheets and suppliers' documentation		
8.2.1	Data sheets of Electronic boards		
8.2.2	Supplier's documents		
8.3	Appended documents		

Section 8 Drawings and parts lists

8.1 List of equipment drawings

Drawing designation		Project doc number
Electrical diagram		VIN90PCS40018EXELE001
Mechanical drawing		VIN90PCS40018EXMEC001
Parts List		VIN90PCS40018EXDOC002
Cable List		VIN90PCS40018EXDOC003
Controgen Setting List		VIN90PCS40018EXDOC004
Report of Equipment Settings & Factory Test		VIN90PCS40018EXFAT001

8.2 Data sheets and suppliers' documentation

8.2.1 Data sheets of Electronic boards

Board	Data sheet	Order n°
X20CP1485	PTP20A43128	1
X20IF1082	PTP20A43169	2
X20AO4632	PTP20A43053	3
X20DI9371	PTP20A43041	4
X20AI4632	PTP20A43133	5
X20TB12	PTP20A43063	6
X20BC0087	PTP20A43171	7
X20PS9400	PTP20A43035	8
X20BB80	PTP20A43062	9
X20BM11	PTP20A43061	10
X20AT4222	PTP20A43073	11
X20D09322	PTP20A43047	12
LCP	PTP12A45028	13
PMF175	PTP20A45054	14
TPI163	PTP12A45027	15
TPT214	PTP12A45020	16
TTM211	PTP12A45022	17
X20ZF0001	UPA100737	18

8.2.2 Supplier's documents

Component	Document reference	Order n°
Protection relay MX3IPG2A	MDE/C133 2561 001	19
Field Breaker	-	20
Filter FN 660	-	21
Instantaneous relays 62 type	-	22
Instantaneous relays 55 type	-	23
Transducer TMP-HI	-	24
DC Power supply Unit	-	25
Fuse Disconnecting Switch	-	26
FL HUB	-	27
FL Switch	-	28
Diode Bridge	-	29
Excitation thyristor Bridge	-	30

8.3 Appended documents

"Commissioning guide"

P T P 2 0 A 4 7 5 3 8