
## **LoTEM SENSOR CALBRATION**

50 Meters



The LoTEM sensor can be calibrated with any of the PHOENIX System 2000 Receivers. Use the Off-Line WinHost Table Editor for MTU or MTU-A equipment or the V8 and RXU Startup.tbl Editor for the V-8/RXU equipment to set the following parameters in the STARTUP.TBL file or use the On-Line Parameter Table editor.

CCMN 0.0 CCMX 0.0 CPHC 0.0 HAMP -0.235 HNOM 50 HxSN TDEMssss