


## USB > Serial converter with auto-reset circuit for ESP32 Ext power config via 3V3 rail



Sheet: /USB > Serial Converter/ File: usbserial.sch Title: Size: A4 Date: KiCad E.D.A. kicad (5.1.8)-1 ld: 11/12

