

Computer Architecture Faculty of Computer Science & Engineering - HCMUT

Chapter 4: The Processor

Binh Tran-Thanh thanhbinh@hcmut.edu.vn

This chapter contents

- The basic units in the CPU
- Functions of the major components in the CPU
- Instruction execution at hardware level
- Performance and trace off among CPUs



This chapter outcomes

Students who complete this course will be able to:

 Explain the structure of a computer system and deeply understand how it works at the hardware level.




Introduction

- CPU performance factors
 - Instruction count
 - Determined by ISA and compiler
 - CPI and Cycle time
 - Determined by CPU hardware
- We will examine two MIPS implementations
 - A simplified version
 - A more realistic pipelined version
- Simple subset, shows most aspects
 - Memory reference: lw, sw
 - Arithmetic/logical: add, sub, and, or, slt
 - Control transfer: beq, j




The simplified processor.





8/19/2021

MIPS Instruction Execution Cycle



1. Instruction Fetch:

- Get instruction from memory
- Address is in Program Counter (PC) Register

2. Instruction Decode:

- Find out the operation required and control signals
- Get operand(s) needed for operation

3. Execution:

- Perform the required operation
- 4. Memory:
 - Access memory (load/store)
- 5. Write Back:
 - Store the result of the operation




Instruction Execution

- PC → instruction memory, fetch instruction
- Register numbers → register file, read registers
- Depending on instruction class
 - Use ALU to calculate
 - Arithmetic result
 - Memory address for load/store
 - Branch target address
 - Access data memory for load/store
 - PC ← target address or PC + 4



CPU Overview






Multiplexers Can't just join wires together Use multiplexers Add Add Data Register # Address ALU + Address Registers Instruction Register # **Data** Instruction memory Register # memory Data



Control





8/19/2021

Logic Design Basics


- Information encoded in binary
 - Low voltage = 0, High voltage = 1
 - One wire per bit
 - Multi-bit data encoded on multi-wire buses
- Combinational element
 - Operate on data
 - Output is a function of input
- State (sequential) elements
 - Store information



Combinational Elements


- AND-gate
 - Y = A & B

- Multiplexer
 - Y = S ? I1: I0




Adder

$$Y = A + B$$




- Arithmetic/Logic Unit
 - Y = F(A, B)





Sequential Elements


- Register: stores data in a circuit
 - Uses a clock signal to determine when to update the stored value
 - Edge-triggered: update when Clk changes from 0 to 1





Sequential Elements


- Register with write control
 - Only updates on clock edge when write control input is 1
 - Used when stored value is required later





Clocking Methodology

- Combinational logic transforms data during clock cycles
 - Between clock edges
 - Input from state elements, output to state element
 - Longest delay determines clock period






Building a Datapath

- Datapath
 - Elements that process data and addresses in the CPU
 - Registers, ALUs, mux's, memories, ...
- We will build a MIPS data-path incrementally
 - Refining the overview design




Instruction type (review)



- Note:
 - All MIPS instructions are 32-bit wise
 - All MIPS instructions contain 6-bit OP (most significant)




Instruction Fetch





Instruction Fetch (cont.)






R-Format Instructions

Read two register operands

Perform arithmetic/logical operation

Write register result

Collection of 32 registers, aka register file




a. Registers

b. ALU



R-Format Instructions (example)

add \$S0, \$a0, \$t0





Your turn


- Assume: \$4 = 104, \$5 = 105, ..., \$31 = 131
- What is the value of read data 1 if we assign 6 to read register 1?
- What is the value of read data 2 if read register 2 = 12?
- If write register = 10 and Write data = 12
 - Which register is written and
 - What value is that (in case RegWrite = 0/1)?





Load/Store Instructions

- Read register operands
- Calculate address using 16-bit offset
 - Use ALU, but sign-extend offset
- Load: Read memory and update register
- Store: Write register value to memory






Branch Instructions

- Read register operands
- Compare operands
 - Use ALU, subtract and check Zero output
- Calculate target address
 - Sign-extend displacement
 - Shift left 2 places (word displacement)
 - Add to PC + 4
 - Already calculated by instruction fetch



Branch Instructions






Composing the Elements

- First-cut data path does an instruction in one clock cycle
 - Each datapath element can only do one function at a time
 - Hence, we need separate instruction and data memories
- Use multiplexers where alternate data sources are used for different instructions



R-Type/Load/Store Datapath

add \$S0, \$a0, \$t0






Faculty of Computer Science and Engineering

R-Type/Load/Store Datapath

lw \$S0, 4(\$a0)






Faculty of Computer Science and Engineering

R-Type/Load/Store Datapath


sw \$S0, 4(\$a0)





Faculty of Computer Science and Engineering

Full Datapath





8/19/2021


ALU Control

- ALU used for
 - Load/Store: F = add
 - Branch: F = subtract
 - R-type: F depends on funct field

ALU control	Function	
0000	AND	
0001	OR	
0010	add	
0110	subtract	
0111	set-on-less-than	
1100	NOR	

Closer look at a 1-bit ALU

ALU control			Function	
Ainvert	Binvert	Operation	FULLCUOLI	
0	0	00	AND	
0	0	01	OR	
0	0	10	ADD	
0	1	10	SUB	
0	1	11	SLT	
1	1	00	NOR	




Without SLT implementation



Closer look at a 1-bit ALU

ALU control			Eupetion	
Ainvert	Binvert	Operation	Function	
0	0	00	AND	
0	0	01	OR	
0	0	10	ADD	
0	1	10	SUB	
0	1	11	SLT	
1	1	00	NOR	

With SLT implementation





ALU Control


- Assume 2-bit ALUOp derived from opcode
 - Combinational logic derives ALU control

opcode	ALUOp	Operation	funct	ALU function	ALU control
lw	00	load word	XXXXXX	add	0010
SW	00	store word	XXXXXX	add	0010
beq	01	branch equal	XXXXXX	subtract	0110
R-type	10	add	100000	add	0010
		subtract	100010	subtract	0110
		AND	100100	AND	0000
		OR	100101	OR	0001
		set-on-less-than	101010	set-on-less-than	0111




The Main Control Unit

Control signals derived from instruction






Datapath With Control






R-Type Instruction






Load Instruction





Branch-on-Equal Instruction





Exercise

What are the values of control signal of following instructions?

```
bne $s1, $s2, exit
sw $s1, 4($a0)
```




Implementing Jumps



- Jump uses word address
- Update PC with concatenation of
 - Top 4 bits of old PC
 - 26-bit jump address
 - **00**
- Need an extra control signal decoded from opcode



Datapath With Jumps Added





Performance Issues

- Longest delay determines clock period
 - Critical path: load instruction
 - Instruction memory → register file → ALU → data memory → MUX.
- Not feasible to vary period for different instructions
- Violates design principle
 - Making the common case fast
- We will improve performance by pipelining



Your turn


What is critical path of following instructions:

bne, sw



Pipelining Analogy

- Pipelined laundry: overlapping execution
 - Parallelism improves performance





MIPS Pipeline

- Five stages, one step per stage
 - IF: Instruction fetch from memory
 - ID: Instruction decode & register read
 - EX: Execute operation or calculate address
 - MEM: Access memory operand
 - WB: Write result back to register




Pipeline Performance

- Assume time for stages is
 - 100ps for register read or write
 - 200ps for other stages
- Compare pipelined datapath with single-cycle datapath

Instr	Instr fetch	Register read	ALU op	Memory access	Register write	Total time
lw	200ps	100 ps	200ps	200ps	100 ps	800ps
SW	200ps	100 ps	200ps	200ps		700ps
R-format	200ps	100 ps	200ps		100 ps	600ps
beq	200ps	100 ps	200ps			500ps



Pipeline Performance





Pipeline Speedup

- If all stages are balanced
 - i.e., all take the same time

 - Time between instructions pipelined
 Time between instructions nonpipelined
 Number of stages
- If not balanced, speedup is less
- Speedup due to increased throughput
 - Latency (time for each instruction) does not decrease
- What is the value of pipeline CPI?



Pipelining and ISA Design

- MIPS ISA designed for pipelining
 - All instructions are 32-bits
 - Easier to fetch and decode in one cycle
 - c.f. x86: 1- to 15-byte instructions
 - Few and regular instruction formats
 - Can decode and read registers in one step
 - Load/store addressing
 - Can calculate address in 3rd stage, access memory in 4th stage
 - Alignment of memory operands
 - Memory access takes only one cycle



Hazards


- Situations that prevent starting the next instruction in the next cycle
- Structure hazards
 - A required resource is busy
- Data hazard
 - Need to wait for previous instruction to complete its data read/write
- Control hazard
 - Deciding on control action depends on previous instruction



Structure Hazards

Assume Instruction Memory and Data Memory are in the same

single memory





Structure Hazards


- Conflict for use of a resource
- In MIPS pipeline with a single memory
 - Load/store requires data access
 - Instruction fetch would have to stall for that cycle
 - Would cause a pipeline "bubble"
- Hence, pipelined datapaths require separate instruction/data memories
 - Or separate instruction/data caches



Data Hazards

 An instruction depends on completion of data access by a previous instruction


```
add $s0, $t0, $t1
sub $t2, $s0, $t3
```





Data Hazards (bubble, stall, delay)


 An instruction depends on completion of data access by a previous instruction






Forwarding (aka Bypassing)

- Use result when it is computed
 - Don't wait for it to be stored in a register
 - Requires extra connections in the datapath





Pipeline visualization






How many stalls?

```
Example 1
  lw $2, $1, $3
  and $12, $2, $5
  or $13, $6, $2
  add $14, $12, $2
  sw $14, 100($2)
Example 2
       addi $2, $0, 10
  Loop: addi $2, $2, -1
       bne $2, $0, Loop
```



Load-Use Data Hazard

- Can't always avoid stalls by forwarding
 - If value not computed when needed
 - Can't forward backward in time!






8/19/202

59

Code Scheduling to Avoid Stalls

- Reorder code to avoid use of load result in the next instruction
- C code for A = B + E; C = B + F;





How many stalls? And ...

```
lw $10, 20($1)
      bne $10, $9, else
      sub $11, $2, $3
      add $12, $11, $4
      i exit
else: lw $13, 24($12)
      add $14, $5, $12
exit:
```




Control Hazards

- Branch determines flow of control
 - Fetching next instruction depends on branch outcome
 - Pipeline can't always fetch correct instruction
 - Still working on ID stage of branch
- In MIPS pipeline
 - Need to compare registers and compute target early in the pipeline
 - Add hardware to do it in ID stage



Stall on Branch

 Wait until branch outcome determined before fetching next instruction






Branch Prediction

- Longer pipelines can't readily determine branch outcome early
 - Stall penalty becomes unacceptable
- Predict outcome of branch
 - Only stall if prediction is wrong
- In MIPS pipeline
 - Can predict branches not taken
 - Fetch instruction after branch, with no delay



MIPS with Predict Not Taken





More-Realistic Branch Prediction

- Static branch prediction
 - Based on typical branch behavior
 - Example: loop and if-statement branches
 - Predict backward branches taken
 - Predict forward branches not taken
- Dynamic branch prediction
 - Hardware measures actual branch behavior
 - e.g., record recent history of each branch
 - Assume future behavior will continue the trend
 - When wrong, stall while re-fetching, and update history




Pipeline Summary

- Pipelining improves performance by increasing instruction throughput
 - Executes multiple instructions in parallel
 - Each instruction has the same latency
- Subject to hazards
 - Structure, data, control
- Instruction set design affects complexity of pipeline implementation



Single clock cycle vs Pipeline vs Multiple clock cycle






Pipeline: 7 cycles, cycles time = 1 secs

Multiple clock cycle

Instruction	#cycles					
Load	5	IF	ID	EXE	MEM	WB
Store	4	IF	ID	EXE	MEM	
Branch	3	IF	ID	EXE		
Arithmetic/logical	4	IF	ID	EXE	WB	
Jump	2	IF	ID			



MIPS Pipelined Datapath
Instruction fetch ID: Instruction decode/ EX: Execute/ MEM: Memor






8/19/2021

Pipeline registers

Need registers between stages

To hold information produced in previous








Pipeline Operation

- Cycle-by-cycle flow of instructions through the pipelined datapath
 - "Single-clock-cycle" pipeline diagram
 - Shows pipeline usage in a single cycle
 - Highlight resources used
 - c.f. "multi-clock-cycle" diagram
 - Graph of operation over time
- We'll look at "single-clock-cycle" diagrams for load & store



IF for Load, Store, ...









ID for Load, Store, ...


Instruction decode






EX for Load








MEM for Load






WB for Load








Corrected Datapath for Load






EX for Store








MEM for Store





WB for Store








Multi-Cycle Pipeline Diagram

Form showing resource usage






82


Single-Cycle Pipeline Diagram

State of pipeline in a given cycle





Pipelined Control (Simplified)






Pipelined Control


Control signals derived from instruction

As in single-cycle implementation





Pipelined Control





8/19/2021

Data Hazards in ALU Instructions


Consider this sequence:

```
sub $2, $1, $3
and $12, $2, $5
or $13, $6, $2
add $14, $2, $2
sw $15, 100($2)
```

- We can resolve hazards with forwarding
 - How do we detect when to forward?



Dependencies & Forwarding





Detecting the Need to Forward

- Pass register numbers along pipeline
 - e.g., ID/EX.RegisterRs = register number for Rs sitting in ID/EX pipeline register
- ALU operand register numbers in EX stage are given by
 - ID/EX.RegisterRs, ID/EX.RegisterRt
- Data hazards when
 - 1a. EX/MEM.RegisterRd = ID/EX.RegisterRs
 - 1b. EX/MEM.RegisterRd = ID/EX.RegisterRt
 - 2a. MEM/WB.RegisterRd = ID/EX.RegisterRs
 - 2b. MEM/WB.RegisterRd = ID/EX.RegisterRt

Fwd from EX/MEM pipeline reg

Fwd from MEM/WB pipeline reg




Detecting the Need to Forward

- But only if forwarding instruction will write to a register!
 - EX/MEM.RegWrite, MEM/WB.RegWrite
- And only if Rd for that instruction is not \$zero
 - EX/MEM.RegisterRd ≠ 0, MEM/WB.RegisterRd ≠ 0




No Forwarding



a. No forwarding



Forwarding Path





b. With forwarding

Forwarding Conditions

- EX hazard
 - if (EX/MEM.RegWrite and (EX/MEM.RegisterRd ≠ 0) and (EX/MEM.RegisterRd = ID/EX.RegisterRs)) ForwardA = 10
 - if (EX/MEM.RegWrite and (EX/MEM.RegisterRd ≠ 0) and (EX/MEM.RegisterRd = ID/EX.RegisterRt)) ForwardB = 10



Forwarding Conditions

- MEM hazard
 - if (MEM/WB.RegWrite and (MEM/WB.RegisterRd ≠ 0) and (MEM/WB.RegisterRd = ID/EX.RegisterRs)) ForwardA = 01
 - if (MEM/WB.RegWrite and (MEM/WB.RegisterRd ≠ 0) and (MEM/WB.RegisterRd = ID/EX.RegisterRt)) ForwardB = 01



Double Data Hazard

Consider the sequence:

```
add $1,$1,$2
add $1,$1,$3
add $1,$1,$4
```

- Both hazards occur
 - Want to use the most recent
- Revise MEM hazard condition
 - Only fwd if EX hazard condition isn't true




Revised Forwarding Condition

MEM hazard if (MEM/WB.RegWrite and $(MEM/WB.RegisterRd \neq 0)$ and not (EX/MEM.RegWrite and (EX/MEM.RegisterRd ≠ 0) (EX/MEM.RegisterRd = ID/EX.RegisterRs)) (MEM/WB.RegisterRd = ID/EX.RegisterRs)) ForwardA = 01if (MEM/WB.RegWrite and $(MEM/WB.RegisterRd \neq 0)$ and not (EX/MEM.RegWrite and (EX/MEM.RegisterRd # 0) and (EX/MEM.RegisterRd = ID/EX.RegisterRt)) (MEM/WB.RegisterRd = ID/EX.RegisterRt)) ForwardB = 01




Datapath with Forwarding





Load-Use Data Hazard





Load-Use Hazard Detection

- Check when using instruction is decoded in ID stage
- ALU operand register numbers in ID stage are given by
 - IF/ID.RegisterRs, IF/ID.RegisterRt
- Load-use hazard when
 - ID/EX.MemRead and (ID/EX.RegisterRt = IF/ID.RegisterRs) or (ID/EX.RegisterRt = IF/ID.RegisterRt))
- If detected, stall and insert bubble




How to Stall the Pipeline

- Force control values in ID/EX register to 0
 - EX, MEM and WB do nop (no-operation)
- Prevent update of PC and IF/ID register
 - Using instruction is decoded again
 - Following instruction is fetched again
 - 1-cycle stall allows MEM to read data for lw
 - Can subsequently forward to EX stage




Load-Use Data Hazard





Datapath with Hazard Detection






Stalls and Performance

- Stalls reduce performance
 - But are required to get correct results
- Compiler can arrange code to avoid hazards and stalls
 - Requires knowledge of the pipeline structure



Branch Hazards






Reducing Branch Delay

- Move hardware to determine outcome to ID stage
 - Target address adder
 - Register comparator
- Example: branch taken

```
36: sub $10, $4, $8
40: beq $1, $3, 7
44: and $12, $2, $5
48: or $13, $2, $6
52: add $14, $4, $2
56: slt $15, $6, $7
```




Example: Branch Taken (clock 3) sub \$10, \$4, \$8 before<1> before<2>





Example: Branch Taken (clock 4)





Data Hazards for Branches

 If a comparison register is a destination of 2nd or 3rd preceding ALU instruction

Can resolve using forwarding



Data Hazards for Branches


 If a comparison register is a destination of preceding ALU instruction or 2nd preceding load instruction

Need 1 stall cycle.



Data Hazards for Branches

- If a comparison register is a destination of immediately preceding load instruction
 - Need 2 stall cycles





Dynamic Branch Prediction

- In deeper and superscalar pipelines, branch penalty is more significant
- Use dynamic prediction
 - Branch prediction buffer (aka branch history table)
 - Indexed by recent branch instruction addresses
 - Stores outcome (taken/not taken)
 - To execute a branch
 - Check table, expect the same outcome
 - Start fetching from fall-through or target
 - If wrong, flush pipeline and flip prediction



1-Bit Predictor: Shortcoming

Inner loop branches mispredicted twice!

```
outer: ...

inner: ...

beq ..., ..., inner

...


beq ..., ..., outer
```

- Mispredict as taken on last iteration of inner loop
- Then mispredict as not taken on first iteration of inner loop next time around



2-Bit Predictor

Only change prediction on two successive mispredictions





Calculating the Branch Target

- Even with predictor, still need to calculate the target address
 - 1-cycle penalty for a taken branch
- Branch target buffer
 - Cache of target addresses
 - Indexed by PC when instruction fetched
 - If hit and instruction is branch predicted taken, can fetch target immediately



Exceptions and Interrupts

- "Unexpected" events requiring change in flow of control
 - Different ISAs use the terms differently
- Exception
 - Arises within the CPU
 - e.g., undefined opcode, overflow, syscall, ...
- Interrupt
 - From an external I/O controller
- Dealing with them without sacrificing performance is hard



Handling Exceptions

- In MIPS, exceptions managed by a System Control Coprocessor (CP0)
- Save PC of offending (or interrupted) instruction
 - In MIPS: Exception Program Counter (EPC)
- Save indication of the problem
 - In MIPS: Cause register
 - We'll assume 1-bit
 - 0 for undefined opcode, 1 for overflow
- Jump to handler at 8000 00180



An Alternate Mechanism

- Vectored Interrupts
 - Handler address determined by the cause
- Example:
 - Undefined opcode: C000 0000
 - Overflow: C000 0020
 - **C**000 0040
- Instructions either
 - Deal with the interrupt, or
 - Jump to real handler



Handler Actions

- Read cause, and transfer to relevant handler
- Determine action required
- If restartable
 - Take corrective action
 - use EPC to return to program
- Otherwise
 - Terminate program
 - Report error using EPC, cause, ...




Exceptions in a Pipeline

- Another form of control hazard
- Consider overflow on add in EX stage
 - add \$1, \$2, \$1
 - Prevent \$1 from being clobbered
 - Complete previous instructions
 - Flush add and subsequent instructions
 - Set Cause and EPC register values
 - Transfer control to handler
- Similar to mispredicted branch
 - Use much of the same hardware



Pipeline with Exceptions





Exception Properties

- Restartable exceptions
 - Pipeline can flush the instruction
 - Handler executes, then returns to the instruction
 - Refetched and executed from scratch
- PC saved in EPC register
 - Identifies causing instruction
 - Actually PC + 4 is saved
 - Handler must adjust



Exception Example

Exception on add in


```
40 sub $11, $2, $4
44 and $12, $2, $5
48 or $13, $2, $6
4C add $1, $2, $1
50 slt $15, $6, $7
54 lw $16, 50($7)
```

Handler

```
80000180 sw $25, 1000($0)
80000184 sw $26, 1004($0)
```


• • •







Exception Example (clock 7) bubble (nop) bubble bubble bubble





124

Multiple Exceptions

- Pipelining overlaps multiple instructions
 - Could have multiple exceptions at once
- Simple approach: deal with exception from earliest instruction
 - Flush subsequent instructions
 - "Precise" exceptions
- In complex pipelines
 - Multiple instructions issued per cycle
 - Out-of-order completion
 - Maintaining precise exceptions is difficult!



Imprecise Exceptions

- Just stop pipeline and save state
 - Including exception cause(s)
- Let the handler work out
 - Which instruction(s) had exceptions
 - Which to complete or flush
 - May require "manual" completion
- Simplifies hardware, but more complex handler software
- Not feasible for complex multiple-issue out-of-order pipelines



Instruction-Level Parallelism (ILP)

- Pipelining: executing multiple instructions in parallel
- To increase ILP
 - Deeper pipeline
 - Less work per stage ⇒ shorter clock cycle
 - Multiple issue
 - Replicate pipeline stages \Rightarrow multiple pipelines
 - Start multiple instructions per clock cycle
 - CPI < 1, so use Instructions Per Cycle (IPC)
 - E.g., 4GHz 4-way multiple-issue
 - 16 BIPS, peak CPI = 0.25, peak IPC = 4
 - But dependencies reduce this in practice



Multiple Issue

- Static multiple issue
 - Compiler groups instructions to be issued together
 - Packages them into "issue slots"
 - Compiler detects and avoids hazards
- Dynamic multiple issue
 - CPU examines instruction stream and chooses instructions to issue each cycle
 - Compiler can help by reordering instructions
 - CPU resolves hazards using advanced techniques at runtime



Speculation

- "Guess" what to do with an instruction
 - Start operation as soon as possible
 - Check whether guess was right
 - If so, complete the operation
 - If not, roll-back and do the right thing
- Common to static and dynamic multiple issue
- Examples
 - Speculate on branch outcome
 - Roll back if path taken is different
 - Speculate on load
 - Roll back if location is updated



Compiler/Hardware Speculation

- Compiler can reorder instructions
 - e.g., move load before branch
 - Can include "fix-up" instructions to recover from incorrect guess
- Hardware can look ahead for instructions to execute
 - Buffer results until it determines they are actually needed
 - Flush buffers on incorrect speculation



Speculation and Exceptions

- What if exception occurs on a speculatively executed instruction?
 - e.g., speculative load before null-pointer check
- Static speculation
 - Can add ISA support for deferring exceptions
- Dynamic speculation
 - Can buffer exceptions until instruction completion (which may not occur)



Static Multiple Issue

- Compiler groups instructions into "issue packets"
 - Group of instructions that can be issued on a single cycle
 - Determined by pipeline resources required
- Think of an issue packet as a very long instruction
 - Specifies multiple concurrent operations
 - ⇒ Very Long Instruction Word (VLIW)



Scheduling Static Multiple Issue

- Compiler must remove some/all hazards
 - Reorder instructions into issue packets
 - No dependencies with a packet
 - Possibly some dependencies between packets
 - Varies between ISAs; compiler must know!
 - Pad with nop if necessary




MIPS with Static Dual Issue

- Two-issue packets
 - One ALU/branch instruction
 - One load/store instruction
 - 64-bit aligned
 - ALU/branch, then load/store
 - Pad an unused instruction with nop

Address	Instruction type	Pipeline Stages						
n + 00	ALU/branch	IF	D	EX	MEM	WB		
n + 04	Load/store	IF	D	EX	MEM	WB		
n + 08	ALU/branch		느	ID	EX	MEM	WB	
n + 12	Load/store		느	ID	EX	MEM	WB	
n + 16	ALU/branch			IF	ID	EX	MEM	WB
n + 20	Load/store			IF	ID	EX	MEM	WB



MIPS with Static Dual Issue





Hazards in the Dual-Issue MIPS

- More instructions executing in parallel
- EX data hazard
 - Forwarding avoided stalls with single-issue
 - Now can't use ALU result in load/store in same packet

```
add $t0, $s0, $s1
lw $s2, 0($t0)
```

- Split into two packets, effectively a stall
- Load-use hazard
 - Still one cycle use latency, but now two instructions
- More aggressive scheduling required



Scheduling Example

Schedule this for dual-issue MIPS

```
Loop: lw $t0, 0($s1)  # $t0=array element

addu $t0, $t0, $s2  # add scalar in $s2

sw $t0, 0($s1)  # store result

addi $s1, $s1,-4  # decrement pointer

bne $s1, $zero, Loop # branch $s1!=0
```

	ALU/branch	Load/store	cycle
Loop:	nop	lw \$t0, 0(\$s1)	1
	addi \$s1, \$s1,-4	nop	2
	addu \$t0, \$t0, \$s2	nop	3
	bne \$s1, \$zero, Loop	sw \$t0, 0(\$s1)	4



Loop Unrolling

- Replicate loop body to expose more parallelism
 - Reduces loop-control overhead
- Use different registers per replication
 - Called "register renaming"
 - Avoid loop-carried "anti-dependencies"
 - Store followed by a load of the same register
 - Aka "name dependence"
 - Reuse of a register name



Loop Unrolling Example

- \blacksquare IPC = 14/8 = 1.75
 - Closer to 2, but at cost of registers and code size

	ALU/branch	Load/store	cycle
Loop:	addi \$s1, \$s1,-16	lw \$t0, 0(\$s1)	1
	nop	lw \$t1, 12(\$s1)	2
	addu \$t0, \$t0, \$s2	lw \$t2, 8(\$s1)	3
	addu \$t1, \$t1, \$s2	lw \$t3, 4(\$s1)	4
	addu \$t2, \$t2, \$s2	sw \$t0, 16(\$s1)	5
	addu \$t3, \$t4, \$s2	sw \$t1, 12(\$s1)	6
	nop	sw \$t2, 8(\$s1)	7
	bne \$s1, \$zero, Loop	sw \$t3, 4(\$s1)	8



Dynamic Multiple Issue

- "Superscalar" processors
- CPU decides whether to issue 0, 1, 2, ... each cycle
 - Avoiding structural and data hazards
- Avoids the need for compiler scheduling
 - Though it may still help
 - Code semantics ensured by the CPU



Dynamic Pipeline Scheduling


- Allow the CPU to execute instructions out of order to avoid stalls
 - But commit result to registers in order
- Example

```
lw $t0, 20($s2)
addu $t1, $t0, $t2
sub $s4, $s4, $t3
slti $t5, $s4, 20
```

Can start sub while addu is waiting for lw



Dynamically Scheduled CPU





Register Renaming

- Reservation stations and reorder buffer effectively provide register renaming
- On instruction issue to reservation station
 - If operand is available in register file or reorder buffer
 - Copied to reservation station
 - No longer required in the register; can be overwritten
 - If operand is not yet available
 - It will be provided to the reservation station by a function unit
 - Register update may not be required



Speculation

- Predict branch and continue issuing
 - Don't commit until branch outcome determined
- Load speculation
 - Avoid load and cache miss delay
 - Predict the effective address
 - Predict loaded value
 - Load before completing outstanding stores
 - Bypass stored values to load unit
 - Don't commit load until speculation cleared



Why Do Dynamic Scheduling?

- Why not just let the compiler schedule code?
- Not all stalls are predicable
 - e.g., cache misses
- Can't always schedule around branches
 - Branch outcome is dynamically determined
- Different implementations of an ISA have different latencies and hazards



Does Multiple Issue Work?

- Yes, but not as much as we'd like
- Programs have real dependencies that limit ILP
- Some dependencies are hard to eliminate
 - e.g., pointer aliasing
- Some parallelism is hard to expose
 - Limited window size during instruction issue
- Memory delays and limited bandwidth
 - Hard to keep pipelines full
- Speculation can help if done well



Fallacies

- Pipelining is easy (!)
 - The basic idea is easy
 - The devil is in the details
 - e.g., detecting data hazards
- Pipelining is independent of technology
 - So why haven't we always done pipelining?
 - More transistors make more advanced techniques feasible
 - Pipeline-related ISA design needs to take account of technology trends
 - e.g., predicated instructions



Pitfalls

- Poor ISA design can make pipelining harder
 - e.g., complex instruction sets (VAX, IA-32)
 - Significant overhead to make pipelining work
 - IA-32 micro-op approach
 - e.g., complex addressing modes
 - Register update side effects, memory indirection
 - e.g., delayed branches
 - Advanced pipelines have long delay slots



Concluding Remarks

- ISA influences design of datapath and control
- Datapath and control influence design of ISA
- Pipelining improves instruction throughput using parallelism
 - More instructions completed per second
 - Latency for each instruction not reduced
- Hazards: structural, data, control
- Multiple issue and dynamic scheduling (ILP)
 - Dependencies limit achievable parallelism
 - Complexity leads to the power wall

