

1 Basic equations

1.1 Introduction

Convection: using fluid to move heat or mass (species)

Transport energy and control temperature:

- environment: temperature in room.
- bio systems: blood, skin.
- technologies: heat exchanger, cars. \\$ 23 billion market!
- food heating

Big picture: conservation of mass, force-momentum balance, 1st law of thermodynamics, transport models, conservation of species → governing equations and **boundary conditions**. → solution methods.

1.2 Mass and Momentum equation

Continuity - mass conservation

rate of accumulation of mass inside = net rate of mass flow into volume through surface.

$$\frac{\partial \rho}{\partial t} + \frac{\partial \rho u}{\partial x} + \frac{\partial \rho v}{\partial y} + \frac{\partial \rho w}{\partial z} = 0 \quad (1.1)$$

general 3-D continuity equation. If ρ is constant, then

$$\frac{\partial u}{\partial x} + \frac{\partial v}{\partial y} + \frac{\partial w}{\partial z} = 0 \quad (1.2)$$

Momentum transport (3 direcitions). I=II+III, where

I: Time rate of momentum of fluid in volume

II: net force on fluid in volume

III: net rate pf momentum transport into volume.

x - direction:

$$I := \frac{\partial}{\partial t} (\rho dx dy dz u) = \frac{\partial(\rho u)}{\partial t} dx dy dz \quad (1.3)$$

For III, first calc the flow in x -dir

$$[(\rho u dy dz)u]_x - [(\rho u dy dz)u]_{x+dx} = -\frac{\partial(\rho u^2)}{\partial x} dx dy dz \quad (1.4)$$

then same for y and z

$$III := -u \cdot \left(\frac{\partial(\rho u)}{\partial x} + \frac{\partial(\rho v)}{\partial y} + \frac{\partial(\rho w)}{\partial z} \right) dx dy dz - \left(\rho u \frac{\partial u}{\partial x} + \rho v \frac{\partial u}{\partial y} + \rho w \frac{\partial u}{\partial z} \right) dx dy dz \quad (1.5)$$

For II, simply denote

$$II := \rho X dx dy dz + \rho S_x dx dy dz \quad (1.6)$$

X is the body force per unit mass, S_x is the x direction surface force. In total,

$$\rho \frac{\partial u}{\partial t} + u \frac{\partial \rho}{\partial t} = -u \left[\frac{\partial(\rho u)}{\partial x} + \frac{\partial(\rho v)}{\partial y} + \frac{\partial(\rho w)}{\partial z} \right] - \left(\rho u \frac{\partial u}{\partial x} + \rho v \frac{\partial u}{\partial y} + \rho w \frac{\partial u}{\partial z} \right) + \rho X + \rho S_x \quad (1.7)$$

use continuity equation to cancel:

$$\rho \frac{\partial u}{\partial t} + \left(\rho u \frac{\partial u}{\partial x} + \rho v \frac{\partial u}{\partial y} + \rho w \frac{\partial u}{\partial z} \right) = \rho X + \rho S_x \quad (1.8)$$

$$\frac{D}{Dt} \equiv \frac{\partial}{\partial t} + u \frac{\partial}{\partial x} + v \frac{\partial}{\partial y} + w \frac{\partial}{\partial z} \Rightarrow \rho \frac{Du}{Dt} = \rho X + \rho S_x \quad (1.9)$$

We get x -dir momentum equation. Also works for y

$$\rho \frac{Dv}{Dt} = \rho Y + \rho S_y = \rho F_y \quad (1.10)$$

using another annotation,

$$(u, v, w) \rightarrow (v_1, v_2, v_3) \quad (x, y, z) \rightarrow (x_1, x_2, x_3) \quad (1.11)$$

so

$$\rho \frac{Dv_i}{Dt} = \rho F_i \quad (1.12)$$

1.3 Surface stresses




Figure 1: stress of control volume

take $p_{xz} dx dz$ for example, first place x means direction, second place z means surface norm. p does not mean pressure, just a notation of force here.

$$\sum \rho F_x dx dy dz = [(p_{xx})_{x+dx} - (p_{xx})_x] dy dz + [(p_{xz})_{z+dz} - (p_{xz})_z] dx dy + \dots + \rho X dx dy dz \quad (1.13)$$

x -direction:

$$\Rightarrow \rho \frac{Du}{Dt} = \frac{\partial p_{xx}}{\partial x} + \frac{\partial p_{xz}}{\partial z} + \frac{\partial p_{xy}}{\partial y} + \rho X \quad (1.14)$$

generally, with Einstein's summation:

$$\rho \frac{Dv_i}{Dt} = \rho \frac{\partial v_i}{\partial t} + \rho v_j \frac{\partial v_i}{\partial x_j} = \frac{\partial p_{ij}}{\partial x_j} + \rho X_i \quad (1.15)$$

The decompose is (no subscript p is pressure)

$$p_{xx} = -p + \tau_{xx} \quad p_{xy} = \tau_{xy} \quad p_{xz} = \tau_{xz} \quad (1.16)$$

τ_{xx} is the viscous stress. And x -dir:

$$\rho \frac{Du}{Dt} = -\frac{\partial p}{\partial x} + \frac{\partial \tau_{xx}}{\partial x} + \frac{\partial \tau_{xy}}{\partial x} + \frac{\partial \tau_{xz}}{\partial z} + \rho X \quad (1.17)$$

$$= \rho X - \frac{\partial p}{\partial x} + \mu \nabla^2 u + \frac{\mu}{3} \frac{\partial}{\partial x} \left(\frac{\partial u}{\partial x} + \frac{\partial v}{\partial y} + \frac{\partial w}{\partial z} \right) \quad (1.18)$$

$$- \frac{2}{3} \frac{\partial \mu}{\partial x} \left(\frac{\partial u}{\partial x} + \frac{\partial v}{\partial y} + \frac{\partial w}{\partial z} \right) + 2 \frac{\partial u}{\partial x} \frac{\partial \mu}{\partial x} + \frac{\partial \mu}{\partial y} \left(\frac{\partial u}{\partial y} + \frac{\partial v}{\partial x} \right) + \frac{\partial \mu}{\partial z} \left(\frac{\partial u}{\partial z} + \frac{\partial w}{\partial x} \right) \quad (1.19)$$

Simplification, firstly, with continuity eq,

$$\frac{D\rho}{Dt} = 0 \Rightarrow \left(\frac{\partial u}{\partial x} + \frac{\partial v}{\partial y} + \frac{\partial w}{\partial z} \right) = 0 \quad (1.20)$$

and secondly if viscosity is constant, then derivatives with μ vanish.

Sometimes viscosity is related with temperature, so we can use the following technique instead:

$$\frac{\partial \mu}{\partial x} = \frac{\partial \mu}{\partial T} \left(\frac{\partial T}{\partial x} \right) \quad (1.21)$$

and $\frac{\partial T}{\partial x}$ can be calculated from heat transfer.

We now have momentum equation, after simplification:

$$\rho \frac{Du}{Dt} = \rho X - \frac{\partial p}{\partial x} + \mu \Delta u \quad (1.22)$$

this is Navier-Stokes eq. same for y and z

1.4 Developed flow in pipe




Figure 2: internal flow regime: developing and developed flow

Internal flow regimes: developing flow and fully developed flow. The developed flow is unchanging in x .

The cylinder is $2a$ in diameter. Continuity equation is

$$\frac{\partial u}{\partial x} + \frac{\partial v_r}{\partial r} + \frac{v_r}{r} + \frac{1}{r} \frac{\partial v_\theta}{\partial \theta} = 0 \quad (1.23)$$

symmetry tells no v_r, v_θ , so $\frac{\partial u}{\partial x} = 0 \Rightarrow u = u(r)$

x -dir momentum equation is

$$\rho \left[\frac{\partial u}{\partial t} + u \frac{\partial u}{\partial x} + v_r \frac{\partial u}{\partial r} + \frac{v_\theta}{r} \frac{\partial u}{\partial \theta} \right] = X - \frac{\partial p}{\partial x} + \mu \left[\frac{\partial^2 u}{\partial r^2} + \frac{1}{r} \frac{\partial u}{\partial r} + \frac{1}{r^2} \frac{\partial^2 u}{\partial \theta^2} + \frac{\partial^2 u}{\partial x^2} \right] \quad (1.24)$$

changing into

$$0 = -\frac{\partial p}{\partial x} + \mu \frac{1}{r} \frac{\partial}{\partial r} \left(r \frac{\partial u}{\partial r} \right) \quad (1.25)$$

no slip cond: $u = 0$ at $r = a$. another cond $\frac{\partial u}{\partial r} = 0$ at $r = 0$. Integrate momentum equation,

$$u = \frac{a^2}{4\mu} \left(-\frac{dp}{dx} \right) \left[1 - \left(\frac{r}{a} \right)^2 \right] \quad (1.26)$$

define

$$u_{avg}, u_{mean}, u_m = \frac{1}{\rho A_c} \left(\int_{A_c} \rho u \, dA_c \right) = \frac{1}{\rho \pi a^2} \int_0^a \rho u (2\pi r) \, dr = \frac{a^2}{8\mu} \left(-\frac{dp}{dx} \right) \quad (1.27)$$

substituting pressure term, then

$$u = 2u_{mean} \left[1 - \left(\frac{r}{a} \right)^2 \right] \quad (1.28)$$

For the shear stress, in Newtonian fluid,

$$\tau_{xr} = \mu \left(\frac{\partial v_r}{\partial x} + \frac{\partial u}{\partial r} \right) = \mu \frac{\partial u}{\partial r} = \frac{r}{2} \frac{dp}{dx} \quad (1.29)$$

Take a dx length of the cylinder, the net force at two ends should be balanced by the friction of wall. That is

$$p\pi a^2 - \left(p + \frac{dp}{dx} dx \right) \pi a^2 + (\tau_{xr})_{wall} 2\pi a dx = 0 \Rightarrow (\tau_{xr})_{wall} = \frac{a}{2} \frac{dp}{dx} \quad (1.30)$$

So this is consistent. Friction coefficient C_f is a ratio of friction of wall and the dynamic pressure.

$$C_f = \frac{\tau_{wall}}{\rho u_m^2 / 2} = \frac{8\mu u_m}{a \rho u_m^2} = \frac{16}{Re} \quad Re = \frac{\rho u_m D}{\mu} \quad (1.31)$$

so in the $Re - C_f$ log-log plot, the slope is -1 . For turbulence as Re goes up (transition about $Re = 2000$), the slope is about -0.2 .

C_f is fanning friction factor. If using Darcy friction factor f then $C_f = f/4$

About the power,

$$\dot{W} = \Delta p (\pi a^2) u_m \quad (1.32)$$

1.5 Energy equation

In a control volume, derive from 1st law for control volume. We have input/output: conduction, convection and radiation. Work of the system \dot{W} . So the law is the rate of E_{cv} should be equal to net inflow of convection, conduction radiation and surface/body forces.

By definition, we have kinetic energy per unit mass

$$ke = \frac{1}{2} (u^2 + v^2 + w^2) = \frac{1}{2} v_k v_k \quad (1.33)$$

$$E_{cv} = \rho \left(e + \frac{1}{2} (u^2 + v^2 + w^2) \right) V_{cv} \quad (1.34)$$




Figure 3: Energy equation C.V.

e is internal energy per unit mass. Then

$$\frac{\partial}{\partial t} \left[\rho \left(e + \frac{1}{2} v_k v_k \right) \right] dx dy dz = -\frac{\partial}{\partial x_j} [\rho v_j (e + ke)] dx dy dz - \frac{\partial q''_j}{\partial x_j} dx dy dz \quad (1.35)$$

$$+ \rho dx dy dz (Xu + Yv + Zw) + \frac{\partial}{\partial x_j} (p_{ij} v_i) dx dy dz \quad (1.36)$$

$$+ \rho dx dy dz R \quad (1.37)$$

The first term on *rhs* is convection, second is conduction, last is radiation (may also include chemical reactions and etc.). p_{ij} term represents for body force and shear stress.

$$p_{ij} = -p\delta_{ij} + \tau_{ij}$$

Cancel all $dx dy dz$,

$$\frac{\partial}{\partial t} [\rho(e + ke)] + \frac{\partial}{\partial x_j} [\rho v_j (e + ke)] = -\frac{\partial q''_j}{\partial x_j} + \rho X_j v_j + \frac{\partial}{\partial x_j} ((-p\delta_{ij} + \tau_{ij}) v_i) + \rho R \quad (1.38)$$

using continuity equation $\frac{\partial \rho}{\partial t} + \frac{\partial}{\partial x_j} (\rho v_j) = 0$ to simplify, then

$$\rho \frac{\partial(e + ke)}{\partial t} + \rho v_j \frac{\partial(e + ke)}{\partial x_j} = -\frac{\partial q''_j}{\partial x_j} + \rho X_j v_j + \frac{\partial}{\partial x_j} ((-p\delta_{ij} + \tau_{ij}) v_i) + \rho R \quad (1.39)$$

on the *lhs* we can use $\frac{D}{Dt}$ notation. and

$$\frac{D(ke)}{Dt} = \frac{D}{Dt} \left(\frac{v_k v_k}{2} \right) = v_k \frac{Dv_k}{Dt} \quad (1.40)$$

we get

$$\frac{De}{Dt} + v_j \frac{Dv_j}{Dt} = -\frac{\partial q''_j}{\partial x_j} + \rho X_j v_j + \frac{\partial}{\partial x_j} ((-p\delta_{ij} + \tau_{ij}) v_i) + \rho R \quad (1.41)$$

using momentum equation, $\rho \frac{Dv_i}{Dt} = \frac{\partial p_{ij}}{\partial x_j} + \rho X_i$ to simplify. Multiply it by velocity, we get Mechanical energy equation

$$\rho \frac{D(ke)}{Dt} = \rho v_k \frac{Dv_k}{Dt} = v_i \frac{\partial p_{ij}}{\partial x_j} + \rho v_i X_i \quad (1.42)$$

And use mechanical energy equation to simplify, getting thermal energy balance equation or thermal transport equation

$$\rho \frac{De}{Dt} = -\frac{\partial q''_j}{\partial x_j} + p_{ij} \frac{\partial v_i}{\partial x_j} + \rho R \quad (1.43)$$

It can also be written

$$\rho \left[\frac{De}{Dt} + \frac{p}{\rho} \frac{\partial v_i}{\partial x_i} \right] = - \frac{\partial q''_i}{\partial x_i} + \tau_{ij} \frac{\partial v_i}{\partial x_j} + \rho R \quad (1.44)$$

Then make use of continuity

$$\frac{\partial v_i}{\partial x_i} = - \frac{1}{\rho} \frac{D\rho}{Dt} = \rho \frac{D\rho^{-1}}{Dt} \quad (1.45)$$

we get

$$\rho \left[\frac{De}{Dt} + p \frac{D}{Dt} \left(\frac{1}{\rho} \right) \right] = - \frac{\partial q''_i}{\partial x_i} + \tau_{ij} \frac{\partial v_i}{\partial x_j} + \rho R \quad (1.46)$$

We want to use enthalpy, that is $i = e + p/\rho$, we get

$$\rho \frac{Di}{Dt} - \frac{Dp}{Dt} = - \frac{\partial q''_i}{\partial x_i} + \Phi + \rho R \quad \Phi = \tau_{ij} \frac{\partial v_i}{\partial x_j} \quad (1.47)$$

Φ is viscous dissipation function. Most of the time dissipation can be neglected in engineering. Also for $\frac{Dp}{Dt}$.

For gases, Φ is less likely to take effect unless in turbines. $\frac{Dp}{Dt}$ may be affective. For liquids, it is often incompressible, so $\frac{D\rho}{Dt} = 0$, $c_v = c_p = c, e = i$,

$$\rho \frac{De}{Dt} = \rho \frac{Di}{Dt} = \rho c(T) \frac{DT}{Dt} = - \frac{\partial q''_i}{\partial x_i} + \Phi - \rho R \quad (1.48)$$

Integrating to get mean properties, we want to get thermal energy convected in axial direction. Mean enthalpy i_m ,

$$\dot{m}i_m = \int_{A_c} \rho u i \, dA_c \quad (1.49)$$

If $\rho = \text{const}$, $c_p = \text{const}$, $i = c_p T$, define $i_m = c_p T_m$. For a cylinder tube, radius a , we have

$$\text{in: } \pi a^2 \rho u_m i_m \quad \text{out: } \pi a^2 \rho u_m \left(i_m + \frac{di_m}{dx} dx \right) \quad (1.50)$$

while in the C.V. heat transfer from wall is $q''_w (2\pi a dx)$. From out=in+tran, we get

$$\pi a^2 \rho u_m \frac{di_m}{dx} dx = q''_w (2\pi a) dx \quad (1.51)$$

further,

$$T_m = \frac{1}{u_m A_c} \int u T \, dA_c \quad q''_w = \frac{1}{2} a \rho u_m c_p \frac{dT_m}{dx} \quad (1.52)$$

1.6 Summary

Continuity

$$\frac{\partial \rho}{\partial t} + \frac{\partial}{\partial x} (\rho u) + \frac{\partial}{\partial y} (\rho v) + \frac{\partial}{\partial z} (\rho w) = 0 \quad (1.53)$$

If incompressible, can be simplified.

Momentum x -dir, incompressible flow, $\mu \text{ const}$

$$\rho \frac{Du}{Dt} = - \frac{\partial p}{\partial x} + \mu \left[\frac{\partial^2 u}{\partial x^2} + \frac{\partial^2 v}{\partial y^2} + \frac{\partial^2 w}{\partial z^2} \right] + X \quad (1.54)$$

Energy $q_i'' = -k \frac{\partial T}{\partial x_i}$, $i = c_p T$,

$$\rho c_p \frac{DT}{Dt} = \frac{\partial}{\partial x} \left(k \frac{\partial T}{\partial x} \right) + \frac{\partial}{\partial y} \left(k \frac{\partial T}{\partial y} \right) + \frac{\partial}{\partial z} \left(k \frac{\partial T}{\partial z} \right) + \Phi + \rho R \quad (1.55)$$

$$= k \nabla^2 T + \Phi + \rho R \quad (\text{const } k) \quad (1.56)$$

Example Fully Dev flow in round tube, lam. flow, energy eqn. Ignored heat gen, viscosity diffusion.

$$\rho u c_p \frac{\partial T}{\partial x} + \rho v_r c_p \frac{\partial T}{\partial r} = \frac{k}{r} \frac{\partial}{\partial r} \left(r \frac{\partial T}{\partial r} \right) + \frac{k}{r^2} \frac{\partial^2 T}{\partial \theta^2} + k \frac{\partial^2 T}{\partial x^2} \quad (1.57)$$

2 Fully Developed and developing flow

Fully developed: velocity field and thermal field.

2.1 FD flow in round pipe

Energy equation for round pipe,

FD refers to fully developed.

$$\rho u c_p \frac{\partial T}{\partial x} + \rho v_r c_p \frac{\partial T}{\partial r} = \frac{k}{r} \frac{\partial}{\partial r} \left(r \frac{\partial T}{\partial r} \right) + \frac{k}{r^2} \frac{\partial^2 T}{\partial \theta^2} + k \frac{\partial^2 T}{\partial x^2} \quad (2.1)$$

the θ term need not to be considered. But $\frac{\partial^2 T}{\partial x^2}$ can also be neglected in common situation, as it represents **conduction**, which is much slower than **convection**. We only need to consider it if the velocity is slow or the liquid is highly conductive. And with $v_r = 0$, we end up with

$$\rho u c_p \frac{\partial T}{\partial x} = \frac{k}{r} \frac{\partial}{\partial r} \left(r \frac{\partial T}{\partial r} \right) \quad (2.2)$$

The FD flow profile is given by subsection 1.4

$$u = u_m \left(1 - \left(\frac{r}{a} \right)^2 \right) \quad u_m = \frac{a^2}{8\mu} \left(-\frac{dp}{dx} \right) \quad (2.3)$$

In order to make use of FD condition, the unitless temperature is introduced.

$$\phi = \frac{T_w(x) - T(x, r)}{T_w(x) - T_m(x)} \quad \frac{\partial \phi}{\partial r} = \frac{-1}{T_w - T_m} \frac{\partial T}{\partial r} \quad (2.4)$$

And FD means ϕ is only a function of r . With ϕ , we can compute q_w'' and h .

note $\frac{\partial \phi}{\partial r}$ is also only a function of r .

$$q_w'' = -k \frac{\partial T}{\partial r} \Big|_{r=a} = k(T_w - T_m) \frac{\partial \phi}{\partial r}(r=a) \quad h = \frac{q_w''}{T_w - T_m} = k \frac{\partial \phi}{\partial r}(a) \quad (2.5)$$

We need to specify BCs to solve the problem. There are usually 2 cases.

case 1: constant heat flux $q_w'' = \text{const}$

$$\phi = f(r) \Rightarrow \frac{\partial \phi}{\partial x} = \frac{\partial}{\partial x} \left[\frac{T_w - T}{T_w - T_m} \right] = 0 \quad (2.6)$$

$$\Rightarrow \frac{1}{T_w - T_m} \frac{dT_w}{dx} - \frac{1}{T_w - T_m} \frac{\partial T}{\partial x} - \frac{T_w - T}{(T_w - T_m)^2} \frac{d}{dx} (T_w - T_m) = 0 \quad (2.7)$$

$$\Rightarrow \frac{dT_w}{dx} - \frac{\partial T}{\partial x} - \phi \frac{d}{dx} (T_w - T_m) = 0 \quad (2.8)$$

as $q''_w \sim (T_w - T_m)$, $q''_w = \text{const}$ means $T_w - T_m$ is const, so [Equation 2.8](#) turns into $\frac{dT_w}{dx} = \frac{\partial T}{\partial x}$. Also $T_w - T_m$ is const leads to $\frac{dT_w}{dx} = \frac{dT_m}{dx}$, then, consider heat conservation [Equation 1.52](#)

$$\frac{dT_w}{dx} = \frac{\partial T}{\partial x} = \frac{dT_m}{dx} \quad (2.9)$$

substitute u with u_m in Energy equation [Equation 2.2](#),

$$\frac{u_m}{\alpha} \frac{dT_m}{dx} \left(1 - \left(\frac{r}{a}\right)^2\right) = \frac{1}{r} \frac{\partial}{\partial r} \left(r \frac{\partial T}{\partial r}\right) \quad (2.10)$$

With BC, $q''_w = -k \frac{\partial T}{\partial r}$ at $r = a$ and $\frac{\partial T}{\partial r} = 0$ at $r = 0$, and make use of [Equation 1.52](#)

$$\frac{dT_m}{dx} = \frac{2q''_w}{\rho u_m a c_p} \quad (2.11)$$

the solution is

$$T(x, r) = T_w(x) - \frac{2u_m a^2}{\alpha} \frac{dT_m}{dx} \left[\frac{3}{16} + \frac{1}{16} \left(\frac{r}{a}\right)^4 - \frac{1}{4} \left(\frac{r}{a}\right)^2 \right] \quad (2.12)$$

$$T_m(x) = T_w(x) - \frac{11}{96} \left(\frac{2u_m}{\alpha}\right) \frac{dT_m}{dx} a^2 \quad (2.13)$$

the relation of $\partial_x T_m$ and q''_w , in this case, the convection coefficient is

$$h = \frac{q''_w}{T_w - T_m} = \frac{48}{11} \frac{k}{2a} \quad \text{or} \quad Nu_D = \frac{hD}{k} = \frac{48}{11} \approx 4.364 \quad (2.14)$$

case 2: constant wall temperature T_w . According to [Equation 2.8](#),

$$\frac{\partial T}{\partial x} - \frac{T_w - T}{T_w - T_m} \frac{dT_m}{dx} = 0 \quad \Rightarrow \quad \frac{\partial T}{\partial x} = \phi(r) \frac{dT_m}{dx} \quad (2.15)$$

using energy equation,

$$\frac{u}{\alpha} \phi(r) \frac{dT_m}{dx} = \frac{1}{r} \frac{\partial}{\partial r} \left(r \frac{\partial T}{\partial r}\right) \quad (2.16)$$

B.C., $T(a) = T_w, \frac{\partial T}{\partial r}|_{r=0} = 0$. Assume the solution is of infinite series, then

$$\phi(r) = 1.803 \sum_{n=0}^{\infty} c_{2n} \left(\frac{r}{a}\right)^{2n} \quad (2.17)$$

Question 1: The property of ϕ ?

With the definition of ϕ , I found it would be strange if take average on it:

$$\phi = \frac{T_w - T}{T_w - T_m} \quad \Rightarrow \quad T_w - T = (T_w - T_m)\phi \quad (2.18)$$

take average on both side, as T_w and T_m is not function of r ,

$$T_w - T_m = (T_w - T_m) \frac{1}{u_m A_c} \int u \phi dA_c \quad (2.19)$$

Cancel out $T_w - T_m$, we find

$$u_m A_c = \int u \phi dA_c \quad (2.20)$$

and with the definition of u_m

$$u_m = \frac{1}{A_c} \int u dA_c \Rightarrow \int (u - u\phi) dA_c = 0 \quad (2.21)$$

For the case of fully developed flow in the pipe, as u is already known,

$$\int_0^a u_m \left(1 - \left(\frac{r}{a}\right)^2\right) (1-\phi)r dr = 0 \Rightarrow \int_0^a \left(1 - \left(\frac{r}{a}\right)^2\right) (1-\phi)r dr = 0 \quad (2.22)$$

So is the eqn. above a condition that every ϕ should satisfy, or we can even solve ϕ from it?

substitute, generate equations for coefficients that balance powers of r .

$$c_0 = 1 \quad c_2 = -\frac{1}{4} \lambda_0^2 = -1.828397 \quad c_{2n} = \frac{\lambda_0^2}{(2n)^2} (c_{2n-4} - c_{2n-2}) \quad \lambda_0 = 2.704364 \quad (2.23)$$

In this situation, $Nu_D = \frac{h(2a)}{k} = 3.657$, $q''_w = h(T_w - T_m)$ is getting smaller as T_m increases. As $h = 3.657 \frac{k}{D}$, if we want a higher h , then we need larger k or smaller D .

Stanton number is a ratio of heat transfer and heat capacity.

$$St \equiv \frac{h}{\rho u_m c_p} \quad (2.24)$$

$$Nu = St \cdot Pr \cdot Re \quad Pr = \frac{\mu c_p}{k} \quad Re = \frac{\rho u_m D}{\mu} \quad (2.25)$$

2.2 FD Flow in Rectangular Channel

Rectangular channels, flow in x , dir y, z length b, a . Fully developed steady flow, neglect viscosity, dissipation, radiation and press work, const properties, neglect axial conduction.

$$\text{Continuity: } \underbrace{\frac{\partial u}{\partial x}}_{=0} + \frac{\partial v}{\partial y} + \frac{\partial w}{\partial z} = 0 \text{ B.C. } v = w = 0 \quad (2.26)$$

so everywhere $v = w = 0$.

$$\text{Momentum: } \rho \left(u \frac{\partial u}{\partial x} + v \frac{\partial u}{\partial y} + w \frac{\partial u}{\partial z} \right) = -\frac{\partial p}{\partial x} + \mu \left(\frac{\partial^2 u}{\partial y^2} + \frac{\partial^2 u}{\partial z^2} \right) \quad (2.27)$$

$$\Rightarrow \frac{\partial^2 u}{\partial y^2} + \frac{\partial^2 u}{\partial z^2} = \frac{1}{\mu} \frac{\partial p}{\partial x} \quad (2.28)$$

as $\frac{\partial p}{\partial x} = \text{const}$, this is poisson equation. We solve this with B.C. $u = 0$ on boundaries. And we expect $\frac{\partial u}{\partial y} = \frac{\partial u}{\partial z} = 0$ at centerline.

With $u(y, z)$,

$$\rho c_p \left(u \frac{\partial T}{\partial x} + \underbrace{v \frac{\partial T}{\partial y} + w \frac{\partial T}{\partial z}}_{=0} \right) = k \left(\frac{\partial^2 T}{\partial y^2} + \frac{\partial^2 T}{\partial z^2} \right) \quad (2.29)$$

$$\Rightarrow \frac{u(x, y)}{\alpha} \frac{\partial T}{\partial x} = \frac{\partial^2 T}{\partial y^2} + \frac{\partial^2 T}{\partial z^2} \quad (2.30)$$

We can solve the equation for $T = T_w$ or $q = q_w$ at boundaries.

To solve, postulate temperature field $T = \phi(y, z)f(x)$, substitute into equation, we get

$$\frac{f'}{f} = \frac{\alpha \nabla^2 \phi}{u(y, z)\phi} = \text{const} \quad (2.31)$$

we can solve the combination for every a, b .

	b/a	Nu , Heat flux BC	Nu , Temperature BC
Circle		4.364	3.66
Triangle		3.11	2.49
Rectangle	1.0	3.61	2.98
Rectangle	2.0	4.12	3.39
Rectangle	4.0	5.33	4.44
Rectangle	8.0	6.49	5.60
Rectangle	∞	8.235	7.54

Table 1: Nussel number in different shape

Two affecting factors are the minimal distance from centerline to edges and internal corner angles. We can also use Stanton number.

Colburn j factor, which is defined as

$$j \equiv StPr^{2/3} \quad (2.32)$$

Since Nu is const for fully developed flow, $StPr \propto Re^{-1}$. Friction factor $c_f = f_{Fanning} = 16Re^{-1}$, so $St \propto c_f$, meaning when we raise St , the friction effect also increased. This is heat/momentum transport analogy.

2.3 Thermal Entry Flow Between Parallel Plates

Now we want to know what is the condition of fully developed flow.

Garetz problem




Figure 4: Flow between parallel plates

$$D_H = \frac{4A_0}{D_w} = \frac{4(2b)(1)}{2} = 4b \quad (2.33)$$

The energy equation is

$$\rho u c_p \frac{\partial T}{\partial x^*} = \frac{\partial}{\partial y^*} \left(k \frac{\partial T}{\partial y^*} \right) \quad (2.34)$$

For developing flow we can have

(1) velocity field and T developing

(2) velocity field fully developed, and T is developing. Can occur when unheated entry or large Pr

we assume the second situation. The velocity profile is

$$\frac{u}{u_m} = \frac{3}{2} \left[1 - \left(\frac{y^*}{b} \right)^2 \right] \quad (2.35)$$

take $\rho c_p = \text{const}$, $\alpha = k/\rho c_p$, $\alpha_{ref} = k_{ref}/\rho c_p$, dimensionless number

$$y = \frac{y^*}{b} \quad x = \frac{2x^*}{3u_m b^2 / \alpha} = 4 \frac{x^*}{b} \frac{\alpha_{ref}}{\nu} \frac{2}{u_m (4b)} = \frac{2}{3} \frac{x^*}{b} \frac{4}{Pe} \quad (2.36)$$

where Pe is Peclet number, $Pe = Re Pr$. Partially dimensions form:

$$\frac{2}{3} \frac{u}{u_m} \frac{\partial T}{\partial x} = \frac{\partial}{\partial y} \left(\frac{\alpha}{\alpha_{ref}} \frac{\partial T}{\partial y} \right) \quad (2.37)$$

$$\theta = \frac{T - T_w}{T_i - T_w} \Rightarrow (1 - y^2) \frac{\partial \theta}{\partial x} = \frac{\partial}{\partial y} \left(\frac{\alpha}{\alpha_{ref}} \frac{\partial \theta}{\partial y} \right) \quad (2.38)$$

BC: $\theta(0, y) = \theta_i = 1$, $\theta(x, \pm 1) = \theta_w = 0$.

Postulate: $\theta(x, y) = X(x)Y(y)$, then

$$(1 - y^2)X'Y = \frac{\alpha'(y)}{\alpha_{ref}} + \frac{\alpha(y)}{\alpha_{ref}}XY'' \Rightarrow \frac{X'}{X} = \frac{\alpha'}{\alpha_{ref}} \frac{Y'}{(1 - y^2)Y} + \frac{\alpha}{\alpha_{ref}} \frac{Y''}{(1 - y^2)Y} = -\beta^2 \quad (2.39)$$

First consider α is constant, we get

$$X' + \beta^2 X = 0 \Rightarrow X = C e^{-\beta^2 x} \quad (2.40)$$

$$Y'' + (1 - y^2) \beta^2 Y = 0 \quad (2.41)$$

We can have different β s. This is called Sturm-Liouville problem.

Sturm-Liouville Problem

$$\frac{d}{dy} \left(r(y) \frac{d\phi}{dy} \right) + [q(y) + \lambda p(y)] \phi = 0 \quad (2.42)$$

$$\text{BC: } a_1 \phi(a) - a_2 \phi'(a) = 0, b_1 \phi(b) - b_2 \phi'(b) = 0.$$

Usually there will be eigenvalues $\lambda_m = \{\lambda_1, \lambda_2, \dots\}$, and also eigenfunctions ϕ_m . Any two eigenfactors are orthogonal.

$$\text{Orthogonality: } \rightarrow \int_a^b p(y) \phi_m(y) \phi_n(y) dy = 0 \quad n \neq m \quad (2.43)$$

Method of Frobenius: we postulate

$$Y = \sum_{n=0}^{\infty} a_n y^{n+c} \quad (2.44)$$

so we get

$$\sum a_n (n+c)(n+c-1) y^{n+c-2} + \beta^2 \sum a_n y^{n+c} - \beta^2 \sum a_n y^{n+c+2} = 0 \quad (2.45)$$

then we get

$$n = 0 \Rightarrow a_0 c(c-1) = 0 \Rightarrow c = 0, 1 \quad (2.46)$$

$$n = 1 \Rightarrow a_1 c(c+1) = 0 \Rightarrow \text{choose } a_1 = 0 \quad (2.47)$$

repeat the process to get other coefficients.

we set $a_1 = 0$ only for convenience, it does not matter.

$$a_n = \frac{-\beta^2 (a_{n-2} - a_{n-4})}{(n+c)(n+c-1)} \quad (2.48)$$

$$Y = c_1 \left[1 - \frac{\beta^2}{2} y^2 + \frac{\beta^2}{12} \left(\frac{\beta^2}{2} + 1 \right) y^4 + \dots \right] + c_2 \left[y - \frac{\beta^2 y^3}{16} + \frac{\beta^2}{20} \left(\frac{\beta}{6} + 1 \right) y^5 + \dots \right] \quad (2.49)$$

But the situation is symmetric with $y = 0$, so only have c_1 term, or say $c_2 = 0$. And the remaining is the eigenfunction.

B.C. require $Y(1) = 0$, so β are the roots of

$$1 - \frac{\beta^2}{2} + \frac{\beta^2}{12} \left(\frac{\beta^2}{2} + 1 \right) + \dots = 0 \Rightarrow \beta_0 = 1.67 \quad \beta_1 = 5.67 \quad \dots \quad (2.50)$$

Now

$$\theta = \sum c_m e^{-\beta_m^2 x} Y_m(y) \quad (2.51)$$

using B.C.,

$$\theta(0, y) = 1 \Rightarrow \sum c_m Y_m(y) = 1 \quad (2.52)$$

multiply both sides by $(1 - y^2)Y_n$ and integrate,

$$\int_{-1}^1 (1 - y^2)Y_n dy = \sum_m \int_{-1}^1 c_m Y_m Y_n (1 - y^2) dy = c_n \int_{-1}^1 Y_n^2 (1 - y^2) dy \quad (2.53)$$

so we get

$$c_n = \frac{\int_{-1}^1 (1 - y^2)Y_n dy}{\int_{-1}^1 (1 - y^2)Y_n^2 dy} \quad (2.54)$$

Once we get the function,

$$Nu = \frac{h \cdot 4b}{k} = \frac{4bq_w}{k(T_w - T_m)} = -\frac{4}{\theta_m} \left(\frac{\partial \theta}{\partial y} \right)_{y=1} \quad (2.55)$$

$$= \frac{4 \sum c_m e^{-\beta_m^2 x} Y'_m(1)}{\frac{3}{2} \sum c_m e^{-\beta_m^2 x} Y'_m(1) / \beta_m^2} \quad (2.56)$$

At large x , only the first term dominates, and Nussel number $\rightarrow 8\beta_0^2/3 = 7.56$. The process is

$$Nu(x = 0.0067) = 13.1 \quad Nu(x = 0.0667) = 8.20 \quad Nu(x = 0.2) = 7.52 \quad Nu(x = 1) = 7.52 \quad (2.57)$$

2.4 Developing Flow in Round Tube

constant heat flux

$$u \frac{\partial T}{\partial x^*} = \frac{\alpha}{r} \frac{\partial}{\partial r} \left(r \frac{\partial T}{\partial r} \right) \quad T(0, r) = T_i = 0 \quad \frac{\partial T}{\partial r} \Big|_{r=0} = 0 \quad \frac{\partial T}{\partial r} \Big|_{r=r_w} = \frac{q_w}{k} \quad (2.58)$$

we solve for $T - T_{FD}$, as $T - T_{FD} \rightarrow 0$ as $x^* \rightarrow \infty$. Fully developed solution for this case can be written as

$$\frac{T_{FD}}{q_w r_w / k} = \frac{4x^*/r_w}{RePr} - 4 \left[\frac{3}{16} - \frac{1}{4} \left(\frac{r}{r_w} \right)^2 + \frac{1}{16} \left(\frac{r}{r_w} \right)^4 \right] \quad (2.59)$$

we postulate solution of the form

$$T = T_{FD} + \frac{q_w r_w}{k} V(x^*, r) \quad (2.60)$$

substitute and use the fact that

$$u \frac{\partial T_{FD}}{\partial x} = \frac{\alpha}{r} \frac{\partial}{\partial r} \left(r \frac{\partial T_{FD}}{\partial r} \right) \quad (2.61)$$

leads to

$$2u_m \left(1 - \left(\frac{r}{r_w} \right)^2 \right) \frac{\partial V}{\partial x^*} = \frac{\alpha}{r} \frac{\partial}{\partial r} \left(r \frac{\partial V}{\partial r} \right) \quad (2.62)$$

we define dimensionless

$$r^+ = \frac{r}{r_w} \quad x = \frac{x^*}{r_w} \left(\frac{1}{RePr} \right) \quad Re = \frac{u_m (2r_w)}{\nu} \quad Pr = \frac{\nu}{\alpha} \quad (2.63)$$

then get

$$(1 - (r^+)^2) \frac{\partial V}{\partial x} = \frac{1}{r^+} \frac{\partial}{\partial r^+} \left(r^+ \frac{\partial V}{\partial r^+} \right) \quad (2.64)$$

BCs

$$\frac{\partial V}{\partial r^+} \Big|_{r^+=0} = 0 \quad \frac{\partial V}{\partial r^+} \Big|_{r^+=1} = -\frac{3}{4} \quad V|_{x=0} = \frac{3}{4} - (r^+)^2 + \frac{1}{4}(r^+)^4 \quad (2.65)$$

We still use separation of variables. Same methodology as flat plate case except eigenfunctions are different. Result is

$$Nu_x = \left[\frac{1}{Nu_\infty} - \frac{1}{2} \sum_m \frac{1}{A_m \gamma_m^4} e^{-\gamma_m^2 x} \right]^{-1} \quad (2.66)$$

$$\gamma_1^2 = 25.68 \quad \gamma_2^2 = 83.86 \quad A_m = 7.63 \times 10^{-3} \quad A_m = 2.053 \times 10^{-3} \quad (2.67)$$

Then compute x with Nu ,

$$Nu_x(0) = \infty \quad Nu_x(0.002) = 12.00 \quad Nu_x(0.010) = 7.49 \quad (2.68)$$

$$Nu_x(0.040) = 5.19 \quad Nu_x(0.100) = 4.51 \quad Nu_x(\infty) = 4.36 \quad (2.69)$$

Now constant wall temperature T_w case

$$u \frac{\partial T}{\partial x} = \alpha \left[\frac{1}{r} \frac{\partial}{\partial r} \left(r \frac{\partial T}{\partial r} \right) \right] + \alpha \frac{\partial^2 T}{\partial x^2} \quad (2.70)$$

Non-dimensionalize,

$$r^+ = \frac{r}{r_w} \quad u^+ = \frac{u}{u_m} \quad x^+ = \frac{2(x/2r_w)}{RePr} \quad \theta = \frac{T_w - T}{T_w - T_i} \quad (2.71)$$

we get

$$\frac{u^+}{2} \frac{\partial \theta}{\partial x^+} = \frac{\partial^2 \theta}{\partial(r^+)^2} + \frac{1}{r^+} \frac{\partial \theta}{\partial r^+} + \frac{1}{(RePr)^2} \frac{\partial \theta}{\partial(x^+)} \quad (2.72)$$

as θ, u^+, x^+, r^+ are expected to have order 1, if $Pe = RePr$ is very large, then the last term can be neglected. But if Pe is very small, it will become important.

We assume this is hydrodynamically fully developed, so $u^+ = 2(1 - r^{+2})$. Then postulate separation of variables.

$$\theta(x^+, r^+) = R(r^+)X(x^+) \Rightarrow \frac{X'}{X} = -\lambda^2 \quad (2.73)$$

the solution has the form

$$\theta(x^+, r^+) = \sum_{n=0}^{\infty} c_n R_n(r^+) e^{-\lambda_n^2 x^+} \quad (2.74)$$

c_n and $R_n(r^+)$ are determined using Sturm-Liouville process. Then we can have $T_m(x^+)$, q_w and h , Nu

$$Nu(0) = \infty \quad Nu(0.001) = 12.80 \quad Nu(0.01) = 6.00 \quad (2.75)$$

$$Nu(0.10) = 3.71 \quad Nu(\infty) = 3.66 \quad (2.76)$$

FD conditions reached at $x^+ \approx 0.10$.

$$\frac{2(x/D)}{RePr} = 0.1 \Rightarrow (x/D)_{FD} = 0.05 RePr \sim 5 \text{ for air at } Re = 100 \quad (2.77)$$

2.5 Summary

FD flow and heat transfer.

round pipe:

$$\frac{u}{u_m} = 2 \left(1 - \frac{r^2}{r_w^2} \right) \quad f = \frac{\tau_w}{\rho u_m^2 / 2} = \frac{16}{Re} \quad (2.78)$$

$$\phi = \frac{T_w - T}{T_w - T_m} = \phi(r) \Rightarrow h_{FD} = \frac{q_w}{T_w - T_m} = \text{const} \quad (2.79)$$

$$\frac{h_{FD} D}{k} = Nu_{FD} = \text{const} \quad (2.80)$$

$$u(r) \frac{\partial T}{\partial x} = \frac{k}{\rho c_p} \frac{1}{r} \frac{\partial}{\partial r} \left(r \frac{\partial T}{\partial r} \right) \quad (2.81)$$

$\frac{\partial T}{\partial x}$ is const if q_w is const, and $Nu_{FD} = 4.36$, geometry affects.

Thermally developing flows. velocity field FD. $T(x, r)$, $u(r)$, $v = 0$

$$u(r) \frac{\partial T}{\partial x} = \frac{k}{\rho c_p} \frac{1}{r} \frac{\partial}{\partial r} \left(r \frac{\partial T}{\partial r} \right) \quad (2.82)$$

Isothermal wall $T(x = 0, r) = T_m$, $T(x, r_w) = T_w$, $\frac{\partial T}{\partial r}(x, r = 0) = 0$




Figure 5: Nussel number along developing.

3 Boundary Layer

Solution strategies

- Analytical solutions or solving PDEs using math tools.
- PDE to ODE, using similarity, solve PDE with math tools or numerically.
- PDE, use finite difference or finite element equations, solve numerically.

3.1 Leveque Models

Near inlet heat transfer Two parallel plates. Hydrodynamically to fully developed:

$$u = u(y) \quad v = 0 \quad \Rightarrow \quad \frac{u}{u_m} = 6 \left(\frac{h}{H} - \frac{y^2}{H^2} \right) \quad (3.1)$$

Thermally developing, Leveque I model.

$$u \frac{\partial T}{\partial x} = \alpha \frac{\partial^2 T}{\partial y^2} \quad (3.2)$$

At the boundary, want to linearize u .

$$u = \underbrace{u_w}_{=0} + \frac{\partial u}{\partial y} \Big|_w y + \frac{1}{2} \frac{\partial^2 u}{\partial y^2} \Big|_w y^2 + \dots = \frac{\tau_w}{\mu} y \quad (3.3)$$

so $u = \beta y$, $\beta = \tau_w / \mu$, and

$$\beta y \frac{\partial T}{\partial x} = \alpha \frac{\partial^2 T}{\partial y^2} \quad (3.4)$$

BC: at $x = 0$, $T = T_i$; at $y = 0$, $T = T_w$; at $y = H/2$, $\frac{\partial T}{\partial y} = 0$. But we replace the last one with $T = T_i$ as $y \rightarrow \infty$.

Define a similarity variable,

$$\eta = \left(\frac{\beta}{9\alpha x} \right)^{1/3} y \quad \frac{\partial}{\partial x} = \frac{d}{d\eta} \frac{\partial \eta}{\partial x} \quad \frac{\partial}{\partial y} = \frac{d}{d\eta} \frac{\partial \eta}{\partial y} \quad (3.5)$$

then we get

$$\frac{d^2 T}{d\eta^2} = -3\eta^2 \frac{dT}{d\eta} \quad T = T_w, \eta = 0 \quad T = T_i, \eta \rightarrow \infty \quad (3.6)$$

can show the solution is

$$\frac{T - T_w}{T_i - T_w} = \frac{\int_0^\eta e^{-s^3} ds}{\int_0^\infty e^{-s^3} ds} = \frac{1}{0.893} \int_0^\eta e^{-s^3} ds \quad (3.7)$$

$$h = \frac{-k}{T_w - T_i} \frac{\partial T}{\partial y} \Big|_{y=0} = \frac{k}{0.893} \left(\frac{\beta}{9\alpha x} \right)^{1/3} \sim x^{-1/3} \quad (3.8)$$

We expect $h \sim k/\delta_t$, so $\delta_t \sim x^{1/3}$.

$$Nu = \frac{hD_H}{k} = \frac{h(2H)}{k} = \left(\frac{D_H}{k} \right)^{1/3} \left(\frac{12u_m D_H}{9\alpha} \right)^{1/3} \frac{1}{0.893} = 1.23 \left(\frac{D_H}{x} \right)^{1/3} \left(\frac{u_m D_H}{\nu} \right)^{1/3} \left(\frac{\nu}{\alpha} \right)^{1/3} \quad (3.9)$$

$$q_w = -k \frac{\partial T}{\partial y} \Big|_{y=0} = \frac{k}{0.893(9)^{1/3}} \left(\frac{\beta}{9\alpha x} \right)^{1/3} (T_w - T_i) \quad (3.10)$$

$$\Rightarrow q_w = 0.538k \left(\frac{\tau_w}{\mu\alpha x} \right)^{1/3} (T_w - T_i) \quad (3.11)$$

This implies $q_w \sim \tau_w^{1/3}$, so increasing q_w will lead to increase of τ_w .

usually let
 $\eta = cy^n x^{-p}$, and go
through the process,
choose suitable param
value to let
 x -dependent terms
(both in equation and
BC) drop off.

Leveque I model

$$Cy \frac{\partial T}{\partial x} = \alpha \frac{\partial^2 T}{\partial y^2} \quad (3.12)$$

$$q_w \sim x^{-1/3}(T_w - T_i), h \sim x^{-1/3}, Nu_x = \frac{hx}{k} \sim x^{2/3}$$

There are other models.

Slug Flow

$$C \frac{\partial T}{\partial x} = \alpha \frac{\partial^2 T}{\partial y^2} \quad (3.13)$$

$$q_w \sim x^{-1/2}(T_w - T_i), h = \frac{q_w}{T_w - T_i} \sim x^{-1/2}, Nu_x = \frac{hx}{k} \sim x^{1/2}$$

Slug flow is where $u = c$ is constant

For round tubes,

$$u(r) \frac{\partial T}{\partial x} = \frac{\alpha}{r} \frac{\partial}{\partial r} \left(r \frac{\partial T}{\partial r} \right) \quad (3.14)$$

FD flow $u = 2u_m(1 - (r/a)^2)$. Also use Leveque I approximation,

$$u = \frac{\partial u}{\partial r} \Big|_{r=a} (r - a) \quad (3.15)$$

set transformation $s = a - r$, assume $s \ll a$ so $a - s \approx a$

$$\frac{4u_m s}{a} \frac{\partial T}{\partial x} = \alpha \frac{\partial^2 T}{\partial s^2} \quad (3.16)$$

With similar approach, the result is

$$Nu_x = \frac{hx}{k} = 1.077(2aPe/x)^{1/3} = 1.36(x^+)^{-1/3} \quad Pe = Re_D Pr \quad x^+ = \frac{x/a}{Re_D Pr} \quad (3.17)$$

this models the left part of [Figure 5](#), and when the slope changes in the graph, it comes to fully developed state.

Leveque II, Thermal and quasi-hydro development. Parallel plates.

$$u \frac{\partial T}{\partial x} + v \frac{\partial T}{\partial y} = \alpha \frac{\partial^2 T}{\partial y^2} \quad (3.18)$$

take $u = u(x, y)$, and $v \frac{\partial T}{\partial y}$ is small enough to neglect. Take $u = \tau_w(x)y/\mu = \beta(x)y$. Integrate continuity equation,

$$v = - \int \frac{\partial u}{\partial x} dy = - \frac{d\tau_w}{dx} \int \frac{y}{\mu} dy \quad (3.19)$$

assume $v \frac{\partial T}{\partial y} \ll u \frac{\partial T}{\partial x}$, we find

$$u \frac{\partial T}{\partial x} = \alpha \frac{\partial^2 T}{\partial y^2} \Rightarrow \frac{\tau_w(x)}{\alpha \mu} \frac{\partial T}{\partial x} = \frac{1}{y} \frac{\partial^2 T}{\partial y^2} \quad (3.20)$$

let $ds = \alpha \mu / \tau_w(x) dx$, $s = \int_0^x \alpha \mu / \tau_w(x) dx$. Then equation becomes

$$\frac{\partial T}{\partial s} = \frac{1}{y} \frac{\partial^2 T}{\partial y^2} \quad (3.21)$$

define $\eta = y/(9s)^{1/3}$, and the solution is

$$\frac{T - T_w}{T_i - T_w} = \frac{1}{0.893} \int_0^\eta e^{-\lambda^3} d\lambda \quad q_w(s) = \frac{(T_w - T_i)k\alpha^{-1/3}\mu^{-1/3}}{9^{-1/3}0.893} \int_{\bar{x}=0}^x \frac{d\bar{x}}{\tau_w(\bar{x})} \quad (3.22)$$

Leveque III $T(x, y), u(x, y), v(x, y)$. Again,

$$\rho c_p \left[u \frac{\partial T}{\partial x} + v \frac{\partial T}{\partial y} \right] = k \frac{\partial^2 T}{\partial y^2} \quad (3.23)$$

apply the von mises transform $(x, y) \rightarrow (x, \psi)$, ψ is stream function, $u = \psi_y$, $v = -\psi_x$. Convert $T(x, y)$ to $T(x, \psi(x, y))$.

$$u \left(\frac{\partial T}{\partial x} \right)_y = \left(\frac{\partial \psi}{\partial y} \right)_x \left[\left(\frac{\partial T}{\partial x} \right)_\psi + \left(\frac{\partial T}{\partial \psi} \right)_x + \left(\frac{\partial \psi}{\partial x} \right)_y \right] \quad (3.24)$$

$$v \left(\frac{\partial T}{\partial y} \right)_x = - \left(\frac{\partial \psi}{\partial x} \right)_y \left(\frac{\partial T}{\partial \psi} \right)_x \left(\frac{\partial \psi}{\partial y} \right)_x \quad (3.25)$$

$$\frac{k}{\rho c_p} \frac{\partial^2 T}{\partial y^2} = \frac{k}{\rho c_p} u \left(\frac{\partial}{\partial \psi} \right)_x \left(u \left(\frac{\partial T}{\partial \psi} \right)_x \right) \quad (3.26)$$

$$\Rightarrow u \left(\frac{\partial T}{\partial x} \right)_\psi = \frac{k}{\rho c_p} u \left(\frac{\partial}{\partial \psi} \right)_x \left(u \left(\frac{\partial T}{\partial \psi} \right)_x \right) \quad (3.27)$$

this equation includes $v \frac{\partial T}{\partial y}$ term explicitly. Assume in the boundary layer region, $u = \tau_w(x)y/\mu$,

$$\Rightarrow \frac{\partial \psi}{\partial y} = \frac{\tau_w(x)y}{\mu} \Rightarrow \psi = \frac{\tau_w(x)y^2}{2\mu} \quad (3.28)$$

so the actual transfrom is

$$y = \sqrt{\frac{2\mu}{\tau_w(x)}} \psi^{1/2} \quad u = \sqrt{\frac{2\tau_w(x)}{\mu}} \psi^{1/2} \quad (3.29)$$

$$\Rightarrow \frac{1}{k/\rho c_p} \frac{1}{(2\tau_w(x)/\mu)^{1/2}} \frac{\partial T}{\partial x} = \frac{\partial}{\partial \psi} \left[\psi^{1/2} \frac{\partial T}{\partial \psi} \right] \quad (3.30)$$

$$\text{let } z = \psi^{0.5} \quad V = \frac{1}{4} \int_0^x \frac{k}{\rho c_p} \left(\frac{2\tau_w(\bar{x})}{\mu} \right)^{1/2} d\bar{x} \quad (3.31)$$

$$\Rightarrow \frac{\partial T}{\partial V} = \frac{1}{z} \frac{\partial^2 T}{\partial z^2} \quad (3.32)$$

this is equivalent to Leveque II equation if V replaces s and z replaces y . The solution is

$$q'' = -k \frac{\partial T}{\partial z} \Big|_{z=0} = \frac{(T_w - T_i)kV^{-1/3}}{9^{-1/3}(0.893)} \quad (3.33)$$

rearrange it in physical terms,

$$\frac{\partial T}{\partial z} = \frac{\partial T}{\partial y} \left(\frac{2\mu}{\tau_w(x)} \right)^{1/2} \quad (3.34)$$

$$q''_w = -k \left(\frac{\partial T}{\partial y} \right)_{y=0} = -k \left(\frac{\partial T}{\partial z} \right)_{z=0} \sqrt{\frac{\tau_w(x)}{2\mu}} = \frac{(T_w - T_i)k(\mu\alpha)^{-1/3}\tau_w(x)^{1/2}}{\sqrt[3]{9}(0.893) \left[\int_0^x \sqrt{\tau_w(\bar{x})} d\bar{x} \right]^{1/3}} \quad (3.35)$$

Entry Flow solutions (Approx formulations)

Leveque I

$$\underbrace{\left(\frac{6u_m}{H}\right)}_{=u} y T_x = \alpha T_{yy} \Rightarrow q_w'' \sim \frac{T_w - T_i}{x^{1/3}} \quad (3.36)$$

for slug flow $q_w'' \sim (T_w - T_i)/x^{1/2}$

Leveque II

$$\frac{\tau_w(x)}{\mu} y T_x = \alpha T_{yy} \Rightarrow q_w'' = \frac{T_w - T_i}{0.893} \left(\frac{k}{[9\alpha\mu]^{1/3}} \right) \left(\int_0^x \frac{d\bar{x}}{\tau_w(\bar{x})} \right)^{-1/3} \quad (3.37)$$

Leveque III

$$\left(\frac{\tau_w(x)}{y} \right) T_x - \frac{d\tau_w(x)}{dx} \frac{y^2}{2\mu} T_x = \alpha T_{yy} \quad (3.38)$$

q_w'' refers to [Equation 3.35](#)

For $\tau_w(x)$, the results of boundary layer flow theory can be used. For BL laminar flow,

$$\tau_w = 0.332\mu \left(\frac{u_\infty^{3/2}}{\nu^{1/2}} \right) x^{-1/2} \quad (3.39)$$

For Leveque III,

$$q_w'' = \frac{(T_w - T_i)k}{x^{1/2}} \left(\frac{\nu}{\alpha} \right)^{1/3} \left(\frac{u_\infty}{\nu} \right)^{1/2} \frac{(0.332)(3/4)^{1/3}}{\sqrt[3]{9}(0.893)} \quad (3.40)$$

$$Nu_x = \frac{q_w'' x}{(T_w - T_i)k} = 0.339 \left(\frac{u_\infty x}{\nu} \right)^{1/2} \left(\frac{\nu}{\alpha} \right)^{1/3} = 0.339 Re_x^{1/2} Pr^{1/3} \quad (3.41)$$

Assessment of Axial Fluid Conduction

$$\rho c_p \left(u \frac{\partial T}{\partial x} + v \frac{\partial T}{\partial y} \right) = k \frac{\partial^2 T}{\partial x^2} + k \frac{\partial^2 T}{\partial y^2} \quad (3.42)$$

$$\frac{\text{axial conduction}}{\text{axial convection}} = \frac{k \frac{\partial^2 T}{\partial x^2}}{\rho c_p u \frac{\partial T}{\partial x}} \sim \frac{\alpha}{U_c L_c} = \frac{1}{Re Pr} = Pe^{-1} \quad (3.43)$$

Axial conduction is negligible for $Re Pr \gg 1$

3.2 Variable Wall Temperature

$$u_m \frac{\partial T}{\partial x} = \alpha \frac{\partial^2 T}{\partial y^2} \quad (3.44)$$

Two steps:

$$T(x < 0) = T_i \quad T(0 \leq x \leq \xi) = T_{w0} \quad T(x > \xi) = T_{w1} \quad (3.45)$$

In the first range, up to $x = \xi$, the solution is already known as

$$T - T_i = (T_w - T_i) \left[1 - \operatorname{erf} \left(\frac{y}{2(\alpha x / u_m)^{0.5}} \right) \right] \quad (3.46)$$

Beyond $x = \xi$, the effect of step change ($T_{w1} - T_{w0}$) at $x = \xi$ is

$$(T_{w1} - T_{w0}) \left[1 - \operatorname{erf} \left(\frac{y}{2(\alpha(x - \xi) / u_m)^{0.5}} \right) \right] \quad (3.47)$$

State the full solution as

$$x < \xi : \quad T - T_i = (T_w - T_i) \left[1 - \operatorname{erf} \left(\frac{y}{2(\alpha x / u_m)^{0.5}} \right) \right] \quad (3.48)$$

$$x \geq \xi : \quad T - T_i = (T_{w0} - T_i)[\dots] + (T_{w1} - T_{w0}) \left[1 - \operatorname{erf} \left(\frac{y}{2(\alpha(x - \xi) / u_m)^{0.5}} \right) \right] \quad (3.49)$$

Three steps:

$$T(x < 0) = T_i \quad T(0 \leq x \leq \xi_1) = T_{w0} \quad T(\xi_1 \leq x \leq \xi_2) = T_{w1} \quad T(x > \xi) = T_{w2} \quad (3.50)$$

Can state similar solutions. Use $f(x, y)$ to denote the $1 - \operatorname{erf}$ terms, then we can summarize: for a change in a wall temperature ΔT_w at $x = \xi$,

$$\Delta(\text{solution}) = \Delta(T - T_i) = \Delta T_w \cdot f(x - \xi, y) \quad (3.51)$$

Generalize for N step change, for $x > \xi_N$, solution is

$$T(x, y) - T_i = \sum_{n=1}^N f(x - \xi_n, y)(T_w(\xi_n) - T_w(\xi_{n-1})) = \sum_{n=1}^N f(x - \xi_n, y) \frac{T_w(\xi_n) - T_w(\xi_{n-1})}{\xi_n - \xi_{n-1}} (\xi_n - \xi_{n-1}) \quad (3.52)$$

We want to know when the distance between steps $\xi_n - \xi_{n-1}$ are very small = $d\xi$, and we end up with an integral solution.

$$T(x, y) - T_i = \int_{\xi=0}^x f(x - \xi, y) \frac{dT_w}{d\xi} d\xi \quad (3.53)$$

This is called a stieltjes integral. Consider

$$I = \int \psi(x) \frac{dg}{dx} dx \quad (3.54)$$

we are interested in when $g(x)$ has a jump Δg at some point $x = \xi$,

$$I = \int_0^x x \frac{dg}{dx} dx = \left(\int_0^{\xi-\epsilon} + \int_{\xi-\epsilon}^{\xi+\epsilon} + \int_{\xi+\epsilon}^x \right) \psi(x) \frac{dg}{dx} dx \quad (3.55)$$

The middle term need to be considered. As in the small region, we expect $\psi = \psi(\xi)$ stays constant.

$$\int_{\xi-\epsilon}^{\xi+\epsilon} \psi \frac{dg}{dx} dx = \psi(\xi) \int_{\xi-\epsilon}^{\xi+\epsilon} dg = \psi(\xi) \Delta g \quad (3.56)$$

we end up with

$$I = \int_0^x \psi(x) \frac{dg}{dx} dx + \psi(\xi) \Delta g \quad (3.57)$$

If there are n jumps, we can treat it similarly. So for multiple jumps in wall temperature,

$$T(x, y) - T_i = \int_{\xi=0}^x f(x - \xi, y) \frac{dT_w}{d\xi} d\xi + \sum_n f(x - \xi_n, y) \Delta T_w(\xi_n) \quad (3.58)$$

For other ducts, we may have different f_s

Example 3.1: Const Temp and Linearly incr Temp

For slug flow past a plate for $T_w = \text{const}$,

$$T - T_\infty = (T_w - T_\infty) \operatorname{erf} \left(\frac{y}{2\sqrt{\alpha x/u_m}} \right) \quad (3.59)$$

$$q_w = -k \frac{\partial T}{\partial y} \Big|_{y=0} = (T_w - T_\infty) \sqrt{\frac{u_m}{\pi \alpha x}} \quad (3.60)$$

$$Nu_x = \frac{q_w x}{k(T_w - T_\infty)} = 0.564 Re_x^{1/2} Pr^{1/2} \quad (3.61)$$

slug flow with $T_w - T_\infty = Bx$, no jumps

$$T(x, y) - T_\infty = \int_0^x \frac{dT}{d\xi} \operatorname{erf} \left(\frac{y}{2\sqrt{\alpha x/u_m}} \right) d\xi \quad \frac{dT}{d\xi} = B \quad (3.62)$$

Evaluate integral and q_w ,

$$q_w = \frac{2kB}{\sqrt{\pi \alpha / u_m}} x^{1/2} \quad Nu_x = \frac{q_w x}{(T_w - T_\infty) k} = \frac{2}{\sqrt{\pi \alpha / u_m}} x^{1/2} = 1.128 Re_x^{1/2} Pr^{1/2} \quad (3.63)$$

Method extends to Leveque I, II, III models.

Example 3.2: Wall temp jump in Leveque I

$u = \beta y$, leads to

$$T - T_i = (T_w - T_i) \left[1 - \frac{1}{0.893} \int_0^w e^{-s^3} ds \right] \quad w = \left(\frac{\beta}{9\alpha x} \right)^{1/3} y \quad (3.64)$$

Actually, the term after $(T_w - T_i)$ here is defined as $f(x, y)$.

3.3 Variable Heat Flux Case

slug flow, const q_w ,

$$u_\infty \frac{\partial T}{\partial x} = \alpha \frac{\partial^2 T}{\partial y^2} \quad T(0, y) = T_i \quad T(x, \infty) = T_\infty = T_i \quad q_w = -k \frac{\partial T}{\partial y} \Big|_{y=0} = \text{const} \quad (3.65)$$

the solution

$$T(x, y) - T_i = \frac{2q_w}{k} \left[\sqrt{\frac{x\alpha}{u_\infty\pi}} \exp \left(-\frac{y^2 u_\infty}{4x\alpha} \right) - \frac{y}{2} \operatorname{erf} \left(\frac{y}{2} \sqrt{\frac{u_\infty}{\alpha x}} \right) \right] \quad (3.66)$$

$$Nu_x = \frac{q_w x}{(T_w - T_i) k} = \frac{x}{2} \sqrt{\frac{u_\infty \pi}{\alpha x}} = 0.886 Re_x^{1/2} Pr^{1/2} \quad (3.67)$$

For $y = 0$,

$$T(x, 0) - T_i = T_w(x) - T_i = \frac{2q_w}{k} \sqrt{\frac{\alpha x}{u_\infty\pi}} \quad (3.68)$$

so we know a step change of q_w at $x = 0$ can lead to

$$T_w(x) - T_i = q_{w0}B\sqrt{x} \quad B = \frac{2}{k}\sqrt{\frac{\alpha}{u_\infty\pi}} \quad (3.69)$$

So for multiple jumps. at ξ_i , q_w jump to q_{w1} ; at ξ_2 , q_w jump to q_{w2} .

$$T_w(x) - T_i = q_{w1}B\sqrt{x - \xi_1} + (q_{w2} - q_{w1})B\sqrt{x - \xi_2} \quad (3.70)$$

generalized case,

$$T_w(x) - T_i = B \sum (q_{w,n} - q_{w,n-1})\sqrt{x - \xi_n} \quad (3.71)$$

For continuously change case, $\xi_n - \xi_{n-1} \rightarrow d\xi$,

$$T_w(x) - T_i = B \int_0^x \frac{dq_w}{d\xi} \sqrt{x - \xi} d\xi \quad \left(+ \sum_n B\Delta q_{w,n} \sqrt{x - \xi_n} \right) \quad (3.72)$$

Example 3.3: Linear heat flux case

$$\frac{dq_w}{dx} = C = \text{const} \quad \Rightarrow \quad T_w - T_i = \frac{2}{k}\sqrt{\frac{\alpha}{u_\infty\pi}}C \int_{\xi=0}^x \sqrt{x - \xi} d\xi \quad (3.73)$$

Example 3.4: Extend with Leveque I

$u = \beta y$ case, for const q_w ,

$$\beta y \frac{\partial T}{\partial x} = \alpha \frac{\partial^2 T}{\partial y^2} \quad q_w = -k \frac{\partial T}{\partial y} \Big|_{y=0} = C \quad T(0, y) = T_i \quad T(x, \infty) = T_\infty = T_i \quad (3.74)$$

solution is

$$T_w(x) - T_i = 0.355 \frac{q_w}{k} \left(\frac{\alpha}{\beta}\right)^{1/3} \frac{x^{1/3}}{1/3} = q_w F(x) \quad F(x) = \frac{0.355}{k} \left(\frac{\alpha}{\beta}\right)^{1/3} \frac{x^{1/3}}{1/3} \quad (3.75)$$

so

$$T_w(x) - T_i = \int_{\xi=0}^x F(x - \xi) \frac{dq_w}{d\xi} d\xi \quad (3.76)$$

which can decompose into cont. integration and jump terms.

Example 3.5: Extend to round tube developing flow

Developing flow in round tube, constant q_w solution [subsection 2.4 Equation 2.66](#).

$$T_w - T_m = \frac{q_w D}{k} \left[\frac{1}{Nu_\infty} - \frac{1}{2} \sum_m \frac{1}{A_m \gamma_m^4} e^{-\gamma_m^2 x^+} \right] \quad (3.77)$$

$$x^+ = \frac{x}{r_w} \frac{\alpha}{2r_w u_m} \quad D = 2r_w \quad (3.78)$$

as $T_w - T_i = T_w - T_m + T_m - T_i$, $T_m - T_i = 2q_w x / (\rho c_p r_w u_m) = 2q_w D x^+ / k$,

$$T_w - T_i = \frac{q_w D}{k} \left[\frac{1}{N u_\infty} - \frac{1}{2} \sum_m \frac{1}{A_m \gamma_m^4} e^{-\gamma_m^2 x^+} + 2x^+ \right] = q_w F(x^+) \quad (3.79)$$

so for variable q_w case,

$$T_w - T_i = \int_0^{x^+} \frac{dq_w}{d\xi} F(x^+ - \xi) d\xi \quad (+\Delta \dots) \quad (3.80)$$

3.4 Full Boundary Layer Problem

Steady 2D problem. First analyze the order of magnitude,

$$u \sim U_\infty \quad \frac{\partial u}{\partial y} \sim \frac{U_\infty}{\delta} \quad \frac{\partial u}{\partial x} \sim \frac{U_\infty}{x} \quad (3.81)$$

In boundary layer we suggest boundary layer $\delta \ll x$. So $\frac{\partial u}{\partial y} \gg \frac{\partial u}{\partial x}$. The continuity equation,

$$\frac{\partial v}{\partial y} = -\frac{\partial u}{\partial x} \Rightarrow v = - \int \frac{\partial u}{\partial x} dy \sim \frac{U_\infty \delta}{x} \quad (3.82)$$

which says v is small compared to U_∞ . x -dir momentum:

$$u \frac{\partial u}{\partial x} + v \frac{\partial u}{\partial y} = -\frac{1}{\rho} \frac{\partial P}{\partial x} + \frac{\mu}{\rho} \left(\frac{\partial^2 u}{\partial x^2} + \frac{\partial^2 v}{\partial y^2} \right) + \frac{\mu}{3\rho} \frac{\partial}{\partial x} \left(\frac{\partial u}{\partial x} + \frac{\partial v}{\partial y} \right) \quad (3.83)$$

Note the left 2 terms has same magnitude, $\frac{\partial^2 u}{\partial x^2} \ll \frac{\partial^2 u}{\partial y^2}$, and the last term is vanished due to continuity. The remaining,

$$u \frac{\partial u}{\partial x} + v \frac{\partial u}{\partial y} = -\frac{1}{\rho} \frac{\partial P}{\partial x} + \nu \frac{\partial^2 u}{\partial y^2} \quad (3.84)$$

$$\frac{U_\infty^2}{x} \sim \frac{\nu U_\infty}{\delta^2} \Rightarrow \frac{\delta}{x} = \sqrt{\frac{\nu}{U_\infty x}} = Re_x^{-1/2} \quad (3.85)$$

So $\delta \ll x$ holds in large Raynolds flow. For the y -dir equation

$$u \frac{\partial v}{\partial x} + v \frac{\partial v}{\partial y} = -\frac{1}{\rho} \frac{\partial P}{\partial y} + \nu \left[\frac{\partial^2 v}{\partial x^2} + \frac{\partial^2 v}{\partial y^2} \right] \quad (3.86)$$

The magnitude of left 2 terms are $\frac{U_\infty^2}{x} \frac{\delta}{x}$ and $\frac{U_\infty^2}{x} \frac{\delta^2}{x^2}$, which is relatively small compare to the magnitude of $u \frac{\partial u}{\partial x}$, and also works for viscous terms. Then the only thing left is

$$0 = -\frac{1}{\rho} \frac{\partial P}{\partial y} \Rightarrow P = P_\infty \quad \forall y \quad (3.87)$$

But note P_∞ can be a function of x .

Outer inviscid flow, governing equation:

$$\frac{\partial u}{\partial x} + \frac{\partial v}{\partial y} = 0 \quad -\frac{1}{\rho} \frac{dP}{dx} = U_\infty \frac{dU_\infty}{dx} \quad (3.88)$$

This can be solved to get $U_\infty(x)$ and $P_\infty(x)$ for a given body.

$\delta \ll x$ because δ will only be of same magnitude of hydraulic diameter on FD condition

In the B.L,

$$\frac{\partial u}{\partial x} + \frac{\partial v}{\partial y} = 0 \quad u \frac{\partial u}{\partial x} + v \frac{\partial u}{\partial y} = -\frac{1}{\rho} \frac{\partial P}{\partial x} + \nu \frac{\partial^2 u}{\partial y^2} \quad (3.89)$$

B.C.

$$u(x=0) = U_\infty \quad u(y=0) = 0 \quad v(y=0) = 0 \quad u(y \rightarrow \infty) = U_\infty \quad (3.90)$$

The method is to introduce a similarity variable.

General approach for similarity solutions

postulate streamfunction $\psi = a(x)f(\eta)$, where $\eta = b(x)y$. Substitute into equations and BCs, get

$$f(\eta, a, b, a', b') = 0 \quad (3.91)$$

So what forms ob a, b , make the x dependence in f go away? This should work both in equation and BCs.

In this case, define

$$\psi = \sqrt{\nu x U_\infty} f(\eta) = \nu Re_x^{-1/2} f(\eta) \quad \eta = \frac{y}{\sqrt{\nu x / U_\infty}} \quad (3.92)$$

where $a(x) = \sqrt{\nu x U_\infty}$, $b(x) = 1/\sqrt{\nu x / U_\infty}$.

With the definition of ψ ,

$$u = \frac{\partial \psi}{\partial y} = U_\infty f' \Rightarrow f' = \frac{u}{U_\infty} \quad (3.93)$$

$$v = -\frac{\partial \psi}{\partial x} = \frac{1}{2} \sqrt{\frac{\nu U_\infty}{x}} (\eta f' - f) \quad (3.94)$$

The equation and BC becomes

$$ff'' + 2f''' = 0 \quad f(0) = 0 \quad f'(0) = 0 \quad f'(\infty) = 1 \quad (3.95)$$

Which can solve with shooting method. This is known as Blassius flow. Properties are

$$\tau_w = \mu \left. \frac{\partial u}{\partial y} \right|_{y=0} = \mu U_\infty \sqrt{\frac{U_\infty}{\nu x}} f''(0) \quad (3.96)$$

$$C_f(x) = \frac{\tau_w(x)}{\rho U_\infty^2/2} = \frac{2f''(0)}{\sqrt{U_\infty x / \nu}} = \frac{0.664}{\sqrt{Re_x}} \quad (3.97)$$

Characteristic BL definitions, $\delta_{0.99}$ and $\delta_{0.999}$ means y value where $f' = 0.99$ or 0.999 respectively. For displacement thickness, means displacement of leading edge flow that corresponds to mass transport loss.

$$\rho U_\infty \delta_1 = \int_0^\infty \rho (U_\infty - u) dy \quad (3.98)$$

$$\delta_1 = \sqrt{\frac{\nu x}{U_\infty}} (\eta_\infty - f(\eta_\infty)) \Rightarrow \frac{\delta_1}{x} = \frac{1.73}{\sqrt{Re_x}} \quad (3.99)$$

For momentum thickness, means displacement of leading edge flow that corresponds to momentum transport loss

$$\rho U_\infty^2 \delta_2 = \int_0^\infty \rho u(U_\infty - u) dy \quad (3.100)$$

$$\delta_2 = 0.664 \sqrt{\frac{\nu x}{U_\infty}} \Rightarrow \frac{\delta_2}{x} = \frac{0.664}{\sqrt{Re_x}} \quad (3.101)$$

3.5

Heat transfer for B.L. flow over a flat plate. Energy equation for 2D flow

$$\rho c_p \left[\underbrace{u \frac{\partial T}{\partial x} + v \frac{\partial T}{\partial y}}_{\Phi} \right] - \left[u \frac{\partial P}{\partial x} + v \frac{\partial p}{\partial y} \right] = \Phi + k \left[\frac{\partial^2 T}{\partial x^2} + \frac{\partial^2 T}{\partial y^2} \right] \quad (3.102)$$

$$u \frac{\partial T}{\partial x} \sim \frac{U_\infty \Delta T}{x} \quad v \frac{\partial T}{\partial y} \sim \frac{U_\infty \delta}{x} \frac{\Delta T}{\delta_t} \quad (3.103)$$

$$u \frac{\partial P}{\partial x} \sim U_\infty \frac{\rho U_\infty^2}{x} \quad v \frac{\partial P}{\partial y} \sim \frac{U_\infty \delta}{x} \cdot 0 \quad (3.104)$$

$$\frac{\partial^2 T}{\partial x^2} \sim \frac{\Delta T}{x^2} \quad \frac{\partial^2 T}{\partial y^2} \sim \frac{\Delta T}{\delta_t^2} \quad (3.105)$$

$$\Phi = 2\mu \left(\frac{\partial u}{\partial x} \right)^2 + 2\mu \left(\frac{\partial v}{\partial y} \right)^2 + \mu \left[\frac{\partial u}{\partial y} + \frac{\partial v}{\partial x} \right]^2 - \frac{2}{3}\mu \left[\frac{\partial u}{\partial x} + \frac{\partial v}{\partial y} \right]^2 \quad (3.106)$$

Keeping largest term,

$$\Phi = \left(\frac{\partial u}{\partial y} \right)^2 \quad (3.107)$$

So Dominant terms are

$$\rho c_p \left(u \frac{\partial T}{\partial x} + v \frac{\partial T}{\partial y} \right) = k \frac{\partial^2 T}{\partial y^2} + u \frac{\partial P}{\partial x} + \mu \left(\frac{\partial u}{\partial y} \right)^2 \quad (3.108)$$

The last 2 terms are often negligible, and our problem becomes

$$\frac{\partial u}{\partial x} + \frac{\partial v}{\partial y} = 0 \quad u \frac{\partial u}{\partial x} + v \frac{\partial u}{\partial y} = \nu \frac{\partial^2 u}{\partial y^2} \quad u \frac{\partial T}{\partial x} + v \frac{\partial T}{\partial y} = \alpha \frac{\partial^2 T}{\partial y^2} \quad (3.109)$$

B.C., at $y = 0$, $u = v = 0, T = T_w$; at $y = \infty$ $u = U_\infty, T = T_\infty$.

Use similarity transformation,

$$\psi = \nu \sqrt{Re_x} f(\eta) \quad Re_x = \frac{U_\infty x}{\nu} \quad \eta = \frac{y}{2\sqrt{\nu x / U_\infty}} \quad \phi = \frac{T - T_\infty}{T_w - T_\infty} \quad (3.110)$$

note here η differs by factor of 1/2. Equations and B.C.s transform to

$$ff'' + ff''' = 0 \quad \phi'' + Pr f \phi' = 0 \quad f(0) = f'(0) = 0, \phi(0) = 1 \quad f'(\infty) = \phi(\infty) = 0 \quad (3.111)$$

Solve numerically for specified $Pr = \nu/\alpha$,

$$q_w'' = -k \frac{\partial T}{\partial y} \Big|_{y=0} = -k \left(\frac{d\phi}{d\eta} \frac{\partial \eta}{\partial y} \right)_{y=0} (T_w - T_\infty) = -k \phi'(0) \frac{1}{2x} \sqrt{Re_x} (T_w - T_\infty) \quad (3.112)$$

$$Nu_x = \frac{hx}{k} = \frac{q_w'' x}{k(T_w - T_\infty)} = -\frac{1}{2} \phi'(0) \sqrt{Re_x} \quad (3.113)$$

where $\phi'(0)$ is function of Pr .

- Large Pr leads to $\delta_t \ll \delta$, $Nu_x = 0.332Pr^{1/3}Re_x^{1/2}$. Recall Lighthill Leveque III, $Nu_x = 0.339Pr^{1/3}Re_x^{1/2}$.
- Small P_r leads to $\delta_t \gg \delta$, $Nu_x = 0.564Pr^{1/2}Re_x^{1/2}$, agrees with slug flow model.

3.6 Other Types of Boundary Layer Flows

Wedge flows wedge angle β . Outer flow over wedge is dictated by potential flow solution

$$U_\infty = cx^m \quad m = \frac{\beta/\pi}{2 - \beta/\pi} \quad (3.114)$$

c determined from potential flow solution. If $\beta = \pi$, it is just a stagnation flow.
momentum eq.

$$u \frac{\partial u}{\partial x} + v \frac{\partial u}{\partial y} = -\frac{1}{\rho} \frac{dP_\infty}{dx} + \nu \frac{\partial^2 u}{\partial y^2} \quad (3.115)$$

in potential flow, Bernoulli's equation dictates

$$P_\infty - \frac{1}{2} \rho U_\infty^2 = \text{const} \Rightarrow -\frac{1}{\rho} \frac{dP_\infty}{dx} = U_\infty \frac{dU_\infty}{dx} = c^2 mx^{2m-1} = \frac{U_\infty^2 m}{x} \quad (3.116)$$

so the momentum equation becomes

$$u \frac{\partial u}{\partial x} + v \frac{\partial u}{\partial y} = \frac{m U_\infty^4(x)}{x} + \nu \frac{\partial^2 u}{\partial y^2} \quad (3.117)$$

B.C., at $y = 0$, $u = v = 0$; at $y = \infty$, $u = U_\infty$. Note different m for different angles.

Introduce similarity transform

$$\eta = y \sqrt{\frac{U_\infty(x)}{\nu x}} \quad \psi = \sqrt{\nu x U_\infty(x)} \zeta(\eta) \quad (3.118)$$

this converts u -momentum equation and B.C. to

$$\zeta''' + \frac{1}{2}(m+1)\zeta\zeta'' + m(1-\zeta'^2) = 0 \quad \zeta(0) = \zeta'(0) = 0 \quad \zeta'(\infty) = 1 \quad (3.119)$$

Could be solved numerically. The surface drag coefficient can be related to results of the similarity solution

$$C_f = \frac{\tau_w(x)}{\phi U_\infty^2 / 2} = 2\zeta''(0) Re_x^{-1/2} \quad (3.120)$$

$\zeta''(0)$ varies with wedge angle.

	m	β	$\zeta''(0)$
Alligned Plate	0	0	0.332
Inclined Plate	0.111	0.627	0.510
Stagnation	1	π	1.233
Separation	-0.09	-0.625	0

Table 2: Wedge flow

Energy equation

$$u \frac{\partial T}{\partial x} + v \frac{\partial T}{\partial y} = \alpha \frac{\partial^2 T}{\partial y^2} \quad (3.121)$$

define

$$\eta = \frac{y}{x} \sqrt{\frac{U_\infty(x)x}{\nu}} \quad \theta = \frac{T - T_w}{T_\infty - T_w} \quad (3.122)$$

then we find

$$\theta'' + \frac{Pr}{2}(m+1)\zeta\theta' = 0 \quad \theta(0) = 0 \quad \theta(\infty) = 1 \quad (3.123)$$

Integrating twice from 0 to η and using B.C.s yields

$$\theta(\eta) = \frac{\int_0^\eta \exp \left[-\frac{Pr}{2}(m+1) \int_0^w \zeta(w) dw \right] d\eta}{\int_0^\infty \exp \left[-\frac{Pr}{2}(m+1) \int_0^w \zeta(w) dw \right] dw} \quad (3.124)$$

and

$$h = \frac{q''_w}{T_w - T_\infty} = k \frac{\partial \theta}{\partial y} \Big|_{y=0} = k\theta'(0) \sqrt{\frac{U_\infty(x)}{\nu x}} = k\theta'(0) \sqrt{\frac{C}{\nu} x^{\frac{m-1}{2}}} \quad (3.125)$$

$$\frac{hx}{k} = Nu_x = \theta'(0) \sqrt{\frac{U_\infty x}{\nu}} = \theta'(0) Re^{0.5} \quad (3.126)$$

For $Pr = 1.0$,

β	m	$\theta'(0)$	$\zeta''(0)$	Re_x	h
0	0	0.332	0.332	$\sim x$	$\sim 1/\sqrt{x}$
0.627	0.111	0.378	0.510	$\sim x^{1.11}$	$\sim x^{-0.445}$
1.57	0.333	0.440	0.759	$\sim x^{1.33}$	$\sim x^{-0.333}$

π

Buoyancy induced boundary layer flow and heat transfer, transport close to a vertical or nearly vertical surface.




Figure 6: Buoyancy Convection

- neglecting streamwise viscous transport and viscous dissipation
- constant μ, c_p, k
- include gravity body force

- Assume Boundary Layer (2D) orders of magnitude apply

Governing equations:

$$u \frac{\partial u}{\partial x} + v \frac{\partial v}{\partial y} = 0 \quad (3.127)$$

$$u \frac{\partial u}{\partial x} + v \frac{\partial u}{\partial y} = -\frac{1}{\rho} \frac{\partial P}{\partial x} - g + \nu \frac{\partial^2 u}{\partial y^2} \quad (3.128)$$

$$u \frac{\partial T}{\partial x} + v \frac{\partial T}{\partial y} = \alpha \frac{\partial^2 T}{\partial y^2} \quad (3.129)$$

in the u -momentum equation, $\frac{\partial P}{\partial x}$ is decomposed

$$\frac{\partial P}{\partial x} = -\rho_\infty g + \frac{\partial P_m}{\partial x} \quad (3.130)$$

the first term is hydrostatic, the second is applied motion-inducing gradient if any. Here it is 0. Then the equation becomes

$$u \frac{\partial u}{\partial x} + v \frac{\partial v}{\partial y} = g \frac{\rho_\infty - \rho}{\rho} + \nu \frac{\partial^2 u}{\partial y^2} \quad (3.131)$$

$\rho_\infty - \rho$ may be due to temperature differences or concentration differences.

For buoyancy driven flows, it is common to invoke the two Boussinesq approximations:

- density is taken to be constant, except for the density variation in the buoyancy force term
- differences in density in the buoyancy force term are linearly proportional to temperature differences.

For liquids, incompressible so $\rho = \rho(T)$. For common natural convection flows in gases, pressure differences are small. Ideal gas: $\rho = P/RT$. Taylor series expansion for small ρ changes:

$$\rho_\infty - \rho = \left(\frac{\partial \rho}{\partial t} \right)_P (T_\infty - T) + \left(\frac{\partial \rho}{\partial P} \right)_T (P_\infty - P) + H.O.T \quad (3.132)$$

$\left(\frac{\partial \rho}{\partial P} \right)_T$ is pretty small. so

$$\frac{\rho_\infty - \rho}{\rho} = \frac{1}{\rho} \left(\frac{\partial \rho}{\partial T} \right)_P (T_\infty - T) = -\beta(T_\infty - T) \quad (3.133)$$

this is second Boussinesq approximation. u -momentum equation becomes

$$u \frac{\partial u}{\partial x} + v \frac{\partial u}{\partial y} = g\beta(T - T_\infty) + \nu \frac{\partial^2 u}{\partial y^2} \quad (3.134)$$

For B.L. flow, we expect

$$u \sim U_c \quad v \sim U_c \delta / L \quad x \sim L \quad y \sim \delta \quad (3.135)$$

what is characteristic velocity U_c ? We expect accelerating force $\sim g(\rho_\infty - \rho)$. The accelerating force acting through distance x should increase the K.E. of the flow, then

$$\frac{1}{2} \rho u^2 \sim g x (\rho_\infty - \rho) \quad (3.136)$$

take U_c so that

$$\frac{1}{2}\rho U_c^2 = gx(\rho_\infty - \rho) = gx\rho\beta(T_w - T_\infty) \Rightarrow U_c = \sqrt{gx\beta(T_w - T_\infty)} \quad (3.137)$$

so for u -momentum equation,

$$u \frac{\partial u}{\partial x} \sim U_c \frac{U_c}{x} \quad v \frac{\partial u}{\partial y} \sim \frac{U_c \delta}{x} \frac{U_c}{\delta} \quad \nu \frac{\partial^2 u}{\partial y^2} \sim \frac{\nu U_c}{\delta^2} \quad (3.138)$$

for momentum and buoyancy terms to be compressible,

$$\frac{U_c^2}{x} = \frac{gx\beta(T_w - T_\infty)}{x} \sim g\beta(T_w - T_\infty) \quad (3.139)$$

also, for momentum and viscous terms to be comparable,

$$\frac{U_c^2}{x} \sim \nu \frac{U_c}{\delta^2} \Rightarrow \frac{\delta}{x} \sim \frac{1}{\sqrt{U_c x / \nu}} \quad (3.140)$$

where

$$\frac{U_c x}{\nu} = \sqrt{\frac{gx^3\beta(T_w - T_\infty)}{\nu^2}} \quad (3.141)$$

This is known as Grashof number,

$$Gr_x = \frac{gx^3\beta(T_w - T_\infty)}{\nu^2} \quad (3.142)$$

so $\delta/x \sim Gr_x^{-1/4}$

For energy equation,

$$u \frac{\partial T}{\partial x} \sim U_c \frac{T_w - T_\infty}{x} \quad v \frac{\partial T}{\partial y} \sim \frac{U_c \delta}{x} \frac{T_w - T_\infty}{\delta_t} \quad \alpha \frac{\partial^2 T}{\partial y^2} \sim \alpha \frac{T_w - T_\infty}{\delta_t^2} \quad (3.143)$$

for convection to be comparable to conduction,

$$\frac{U_c(T_w - T_\infty)}{x} \sim \alpha \frac{T_w - T_\infty}{\delta_t} \Rightarrow \frac{\delta_t}{x} \sim \frac{1}{Gr_x^{1/4} Pr^{1/2}} \quad (3.144)$$

thus boundary layer flow results only if Gr_x is large. Laminar B.L. analysis expected to be valid for

$$10^4 < Gr_x < 10^9 \quad \frac{\delta}{x} < 10^{-1} \quad (3.145)$$

For $Gr_x > 10^9$, transitions to turbulent flow is expected. Note $Re = \sqrt{Gr_x}$, it is consistant with flat plate FC BL transition $Re = 3.5 \times 10^5$.

So governing equations and B.C.s for natural convection BL flows are

$$\frac{\partial u}{\partial x} + \frac{\partial v}{\partial y} = 0 \quad (3.146)$$

$$u \frac{\partial u}{\partial x} + v \frac{\partial u}{\partial y} = g\beta(T_w - T_\infty) + \nu \frac{\partial^2 u}{\partial y^2} \quad (3.147)$$

$$u \frac{\partial T}{\partial x} + v \frac{\partial T}{\partial y} = \alpha \frac{\partial^2 T}{\partial y^2} \quad (3.148)$$

At $y = 0$, $u = v = 0, T = T_w$; At $y = \infty$, $u = 0, T = T_\infty$. This can be solved using a similarity transformation:

$$\eta = \frac{y}{x} \left(\frac{Gr_x}{4} \right)^{1/4} \quad Gr_x = \frac{g\beta(T_w - T_\infty)x^3}{\nu^2} \quad (3.149)$$

$$\psi = f(\eta) \left(4\nu \left(\frac{Gr_x}{4} \right)^{1/4} \right) \quad \phi = \frac{T - T_\infty}{T_w - T_\infty} \quad (3.150)$$

then

$$u = \frac{\partial \psi}{\partial y} = \frac{2\nu}{x} Gr_x^{1/2} f'(\eta) \quad (3.151)$$

v is similarly determined using $v = -\frac{\partial \psi}{\partial x}$. Substituting converts momentum equation, energy equation and B.C.s to

$$f''' + 3ff'' - 2f'^2 + \phi = 0 \quad \phi'' + 3Prf\phi' = 0 \quad (3.152)$$

At $\eta = 0$, $f = f' = 0, \phi = 1$; At $\eta = \infty$, $f' = 0, \phi = 0$


$$q_w'' = -k \frac{\partial T}{\partial y} \Big|_{y=0} = -k\phi'(0) \frac{1}{x} \left(\frac{Gr_x}{4} \right)^{1/4} (T_w - T_\infty) \quad (3.153)$$

$$h = \frac{q_w''}{T_w - T_\infty} = -\frac{k}{x} \frac{\phi'(0)}{\sqrt{2}} Gr_x^{1/4} \quad (3.154)$$

$$Nu_x = \frac{hx}{k} = -\frac{\phi'(0)}{\sqrt{2}} Gr_x^{1/4} \quad (3.155)$$

$\phi'(0)$ is determined for a specific Pr value.

3.7 Integral Relations for BL Transport



Assume steady flow and constant density.


Inflow must equal outflow,

$$\rho \frac{\partial v}{\partial y} = -\rho \frac{\partial u}{\partial x} \Rightarrow \rho \int_0^\delta \frac{\partial v}{\partial y} dy = -\rho \int_0^\delta \frac{\partial u}{\partial x} dy \quad (3.156)$$

$$\rho v|_0^\delta = -\rho \frac{d}{dx} \int_0^\delta u dy + \rho u|_0^\delta \frac{d\delta}{dx} \quad (3.157)$$

rearrange to get

$$\rho \frac{d}{dx} \int_0^\delta u dy = \rho U_\infty \frac{d\delta}{dx} - \rho v_\infty \quad (3.158)$$



$$\tau_w \Delta x = \left[\rho \int_0^\delta u^2 dy \right]_{x+\Delta x}^x + \left(\rho U_\infty \frac{d\delta}{dx} - \rho v_\infty \right) \Delta x U_\infty \quad (3.159)$$

expanding each term,


$$\mu \frac{\partial u}{\partial y} \Big|_{y=0} \Delta x = -\rho \frac{d}{dx} \int_0^\delta u^2 dy \Delta x + \rho \frac{d}{dx} \int_0^\delta u U_\infty dy \Delta x \quad (3.160)$$

combining integrals yields

$$\rho \frac{d}{dx} \int_0^\delta (U_\infty - u) u dy = \mu \frac{\partial u}{\partial y} \Big|_{y=0} \quad (3.161)$$

can show that order of differentiation and integral does not matter here.

$$\frac{d}{dx} \int_0^\delta (U_\infty - u) u dy = \underbrace{[(U_\infty - u)u]_\delta \frac{d\delta}{dx}}_{=0} + \int_0^\delta \frac{\partial}{\partial x} [(U_\infty - u)u] dy \quad (3.162)$$



$$q_w \Delta x = \left[\rho c_p \int_0^{\delta_t} u T \, dy \right]_x^{x+\Delta x} - \dot{m}_{net} c_p T_\infty \quad (3.163)$$

$$-k \frac{\partial T}{\partial y} \Big|_{y=0} = \rho c_p \frac{d}{dx} \int_0^{\delta_t} t U \, dy \Delta x - \rho \frac{d}{dx} \int_0^{\delta_t} u T_\infty \, dy c_p \Delta x \quad (3.164)$$

$$\rho c_p \frac{d}{dx} \int_0^{\delta_t} u (T_\infty - T) \, dy = k \frac{\partial T}{\partial y} \Big|_{y=0} = -q_w \quad (3.165)$$

3.8 Integral solution of the blasius flow problem

$$\rho \int_0^\delta \frac{\partial}{\partial x} [(U_\infty - u)u] \, dy = \mu \frac{\partial u}{\partial y} \Big|_{y=0} \quad (3.166)$$

postulate

$$\frac{u}{U_\infty} = \frac{3}{2} \frac{y}{\delta} - \frac{1}{2} \left(\frac{y}{\delta} \right)^3 \quad (3.167)$$

the equation changes into

$$\int_0^\delta \left(U_\infty \frac{\partial u}{\partial x} - \frac{\partial u^2}{\partial x} \right) \, dy = \nu \frac{\partial u}{\partial y} \Big|_{y=0} \quad (3.168)$$

$$U_\infty \frac{\partial u}{\partial x} = U_\infty \frac{\partial u}{\partial \delta} \frac{d\delta}{dx} = U_\infty^2 \frac{-\frac{3}{2} \frac{y}{\delta^2} + \frac{3}{2} \frac{y^3}{\delta^4}}{dx} \quad (3.169)$$

$$u^2 = U_\infty^2 \left[\frac{9}{4} \frac{y^2}{\delta^2} - \frac{3}{2} \frac{y^4}{\delta^4} + \frac{1}{4} \frac{y^6}{\delta^6} \right] \quad (3.170)$$

$$\frac{\partial u^2}{\partial x} = U_\infty^2 \left[-\frac{9}{2} \frac{y^2}{\delta^3} + 6 \frac{y^4}{\delta^5} - \frac{3}{2} \frac{y^6}{\delta^7} \right] \frac{d\delta}{dx} \quad (3.171)$$

$$\frac{\partial u}{\partial y} \Big|_0 = U_\infty \left[\frac{3}{2\delta} - \frac{3y^2}{2\delta^3} \right]_{y=0} = \frac{3U_\infty}{2\delta} \quad (3.172)$$

substitute into equation, integrate polynomial and simplify to get

$$\delta \frac{d\delta}{dx} = \frac{140}{13} \frac{\nu}{U_\infty} \quad (3.173)$$

Integrate,

$$\int_0^\delta \delta \, d\delta = \frac{140}{13} \frac{\nu}{U_\infty} \int_0^x dx \Rightarrow \frac{\delta^2}{2} = \frac{140\nu}{13U_\infty} x \quad (3.174)$$

$$\delta = 4.64x \sqrt{\frac{\nu}{xU_\infty}} \quad (3.175)$$

$$C_{fx} = \frac{(\tau_w)_x}{\rho U_\infty^2 / 2} = \frac{0.646}{\sqrt{Re_x}} \quad (3.176)$$

This result is very close to Blasius similarity result.

Integral method for Thermal BL

$$\rho c_p \frac{d}{dx} \int_0^{\delta_t} u(T_\infty - T) dy = k \frac{\partial T}{\partial y} \Big|_{y=0} = -q_w \quad (3.177)$$

define

$$\theta = \frac{T - T_0}{T_\infty - T_0} \Rightarrow T = \theta(T_\infty - T_0) + T_0 \quad (3.178)$$

we find

$$\rho c_p \frac{d}{dx} \int_0^{\delta_t} u(1 - \theta) dy = k \frac{\partial \theta}{\partial y} \Big|_{y=0} \quad (3.179)$$

postulate

$$\theta = \frac{3}{2} \frac{y}{\delta_t} - \frac{1}{2} \frac{y^3}{\delta_t^3} \quad (3.180)$$

and same polynomial for u/U_∞ ,

$$\begin{aligned} \rho c_p \frac{d}{dx} \int_0^{\delta_t} U_\infty \left[\frac{3}{2} \frac{y}{\delta} - \frac{1}{2} \frac{y^3}{\delta^3} \right] \left[1 - \frac{3}{2} \frac{y}{\delta_t} + \frac{1}{2} \frac{y^3}{\delta_t^3} \right] dy \\ = \frac{\alpha}{\delta_t} \left[\frac{3}{2} - \frac{3}{2} \frac{y^2}{\delta_t^2} \right]_{y=0} = \frac{3\alpha}{2\delta_t} \end{aligned} \quad (3.181)$$

we specifically consider $Pr \geq 1, \zeta = \delta_t/\delta \leq 1$, integration leads to

$$\frac{d}{dx} \left[U_\infty \delta \left(\frac{3}{20} \zeta^2 - \frac{3}{280} \zeta^4 \right) \right] = \frac{3}{2} \frac{\alpha}{\zeta \delta} \quad (3.182)$$

neglect $O(\zeta^4)$ compared to $O(\zeta^2)$ terms,

$$U_\infty \frac{d}{dx} \left[\delta \frac{3}{20} \zeta^2 \right] = \frac{3}{2} \frac{\alpha}{\zeta \delta} \quad (3.183)$$

$$\frac{1}{10} U_\infty \zeta^3 \delta \frac{d\delta}{dx} + \frac{1}{5} U_\infty \delta^2 \zeta^2 \frac{d\zeta}{dx} = \alpha \quad (3.184)$$

from momentum BL solution,

$$\delta \frac{d\delta}{dx} = \frac{140}{13} \frac{\nu}{U_\infty} \quad (3.185)$$

we find

$$\zeta^3 + 4x\zeta^2 \frac{d\zeta}{dx} = \frac{13}{14Pr} \quad (3.186)$$

previous modeling indicate ζ is constant with $\delta_t, \delta \rightarrow 0$ at $x = 0$, then $\frac{d\zeta}{dx} = 0$, so

$$\zeta^3 = \frac{13}{14Pr} \quad \zeta = \frac{1}{1.026Pr^{1/3}} \quad (3.187)$$

By definition,

$$h = -\frac{k \frac{\partial T}{\partial y} \Big|_{y=0}}{T_0 - T_\infty} = k \frac{\partial \theta}{\partial y} \Big|_{y=0} = \frac{3k}{2\delta_t} = \frac{3k}{2} (1.026) Pr^{1/3} \sqrt{\frac{13}{280}} \sqrt{\frac{U_\infty}{\nu x}} \quad (3.188)$$

$$Nu_x = 0.323 Re_x^{1/2} Pr^{1/3} \quad (3.189)$$

while the coefficient is 0.332 for similarity solution.

Example 3.6: Uniform heat flux BC

Define

$$\phi = \frac{T - T_\infty}{\Delta T} \quad \Delta T(x) = T_0 - T_\infty \quad \Rightarrow \quad T_\infty - T = -\Delta T\phi \quad (3.190)$$

for [Equation 3.165](#),

$$\frac{\partial T}{\partial y} = \Delta T \frac{\partial \phi}{\partial y} \quad q_w = -k \frac{\partial T}{\partial y} \Big|_{y=0} = -k \frac{\partial \phi}{\partial y} \Big|_{y=0} \Delta T \quad (3.191)$$

from integral momentum solution,

$$\frac{u}{U_\infty} = \frac{3}{2} \frac{y}{\delta} - \frac{1}{2} \left(\frac{y}{\delta} \right)^3 \quad (3.192)$$

here we postulate a simple linear temperature profile $\phi = 1 - y/\delta_t$, substituting into eq

$$\frac{d}{dx} \int_0^{\delta_t} u \phi \Delta T dy = \frac{q_w}{\rho c_p} \quad (3.193)$$

$$\int_0^{\delta_t} u \phi \Delta T dy = \int_0^{\delta_t} U_\infty \Delta T \left(1 - \frac{y}{\delta_t} \right) \left(\frac{3}{2} \frac{y}{\delta} - \frac{1}{2} \left(\frac{y}{\delta} \right)^3 \right) \quad (3.194)$$

neglect higher order as $\delta_t/\delta < 1$, finally

$$\int_0^{\delta_t} u \phi \Delta T dy = U_\infty \Delta T \delta \frac{1}{4} \frac{\delta_t^2}{\delta^2} \quad (3.195)$$

The integral equation becomes

$$frac{1}{4} U_\infty \frac{d}{dx} \left[\Delta T \frac{\delta_t^2}{\delta} \right] = \frac{q_w}{\rho c_p} \quad (3.196)$$

$$\frac{1}{4} U_\infty \Delta T \frac{\delta_t^2}{\delta} = \frac{q_w x}{\rho c_p} \quad (3.197)$$

using $q_w = -k \frac{\partial T}{\partial y} \Big|_{y=0}$ and temperature profile, we find $q_w = k \Delta T / \delta_t$. So plug in and get

$$\delta_t^3 = \frac{4 \alpha x \delta}{U_\infty} \quad (3.198)$$

from flow analysis,

$$\delta = \sqrt{\frac{280}{13}} \sqrt{\frac{\nu x}{U_\infty}} \quad (3.199)$$

so

$$\delta_t = 4^{1/3} \left(\frac{280}{13} \right)^{1/6} Pr^{-1/3} x Re_x^{-1/2} \quad (3.200)$$

$$h = \frac{q_w}{\Delta T} = \frac{k}{\delta_t} \quad Nu_x = 0.378 \sqrt{Re_x} Pr^{1/3} \quad (3.201)$$

3.9 Summary

Steady BL flow, can model using

1. Finite difference solution of NS and energy equations, and

$$h = f(\rho, \nu, c_p, k, x, U_\infty, \bar{u}) \quad (3.202)$$

must analyze lots of runs to resolve parameter trends, could improve if non-dimensionalize equations.

2. Similarity solution, predicts forms of parametric variations,

$$Nu_x = \frac{hx}{k} = -\frac{1}{2}\phi'(0)\sqrt{Re_x} \quad (3.203)$$

$\phi'(0)$ is get by solving ODE's for fixed Pr . Similarity framework illuminates parametric trends.

3. Integral solution with postulated u, T profiles

4 Notes on Numerical solution of PDEs

general form of 2nd order ODE,

$$A \frac{\partial^2 \phi}{\partial x^2} + B \frac{\partial^2 \phi}{\partial x \partial y} + C \frac{\partial^2 \phi}{\partial y^2} + D \left(x, y, \phi, \frac{\partial \phi}{\partial x}, \frac{\partial \phi}{\partial y} \right) = 0 \quad (4.1)$$

if ϕ appears to first power throughout. then it is linear. Classification:

$$B^2 - 4AC < 0 \Rightarrow \text{elliptic} \quad (4.2)$$

$$B^2 - 4AC = 0 \Rightarrow \text{parabolic} \quad (4.3)$$

$$B^2 - 4AC > 0 \Rightarrow \text{hyperbolic} \quad (4.4)$$

hyperbolic have wave behavior, solution is constant along characteristics. Finite velocity of disturbance (information) propagation. Classic example: compressible flow. Another example, first order convection equation

$$\frac{\partial \phi}{\partial t} + \hat{c} \frac{\partial \phi}{\partial x} = 0 \Rightarrow \frac{\partial^2 \phi}{\partial t^2} + \hat{c} \frac{\partial^2 \phi}{\partial x \partial t} = 0 \quad (4.5)$$

$A = 0, B = \hat{c}, C = 1, B^2 - 4AC = \hat{c}^2 > 0$ is hyperbolic.

parabolic Infinite propagation speed, information flows in one direction, can march solution forward if know solution at initial value. Example: 1D transient conduction solution

$$\frac{\partial T}{\partial t} = \alpha \frac{\partial^2 T}{\partial x^2} \quad (4.6)$$

FTCS explicit method used in Proj2 does this for transient natural convection BL flow

elliptic Information flows in all directions at once, infinite speed, no preferred direction. Example: 2D steady laplace equation,

$$\frac{\partial^2 T}{\partial x^2} + \frac{\partial^2 T}{\partial y^2} = 0 \quad (4.7)$$

another example. FD flow and convection considered in Proj1.

Important numerical method properties

- Convergence, if iterative
- mesh independence
- stability.

Stability of the FTCS method, consider as an example

$$\frac{\partial T}{\partial t} = \alpha \frac{\partial^2 T}{\partial x^2} \quad (4.8)$$

descretize as

$$\frac{\partial T}{\partial t} = \frac{T_m^* - T_m}{\Delta t} + O(\Delta t) \quad (4.9)$$

$$\frac{\partial^2 T}{\partial x^2} = \frac{T_{m+1} - 2T_m + T_{m-1}}{\Delta x^2} + O(\Delta x^2) \quad (4.10)$$

substituting into the PDEand rearranging

$$T_m^* = T_m + F(T_{m+1} - 2T_m + T_{m-1}) \quad F = \frac{\alpha \Delta t}{\Delta x^2} \quad (4.11)$$

F is called grid Fourier number.

Suppose a steady-state solution has been reached which $T_m = T_s$ for all m , we then introduce a small instantaneous disturbance ϵ at location m , $T_m = T_s + \epsilon$, what happens as we march the scheme forward?

$$T^* = T_s + \epsilon + F(T_s - 2(T_s + \epsilon) + T_s) \Rightarrow T_m^* - T_s = \epsilon(1 - 2F) \quad (4.12)$$

the *lhs* is the deviation from steady state solution, for stability we want a disturbance to die-out,

$$\frac{T_m^* - T_s}{\epsilon} < 1 \Rightarrow (1 - 2F) < 1 \quad (4.13)$$

so $-1 \leq 1 - 2F \leq 1$, from left side we have $F \leq 1$, indicating

$$\Delta t \leq \frac{\Delta x^2}{\alpha} \quad (4.14)$$

If we further want to assure that disturbance damp without overshoot, require

$$\frac{T_m^* - T_s}{\epsilon} \geq 0 \Rightarrow F \leq \frac{1}{2} \quad (4.15)$$

can show by analyzing subsequent timesteps that $F \leq 1/2$, $\Delta t \leq \Delta x^2/2\alpha$ is necessary for stability.

Somewhat more complicated for convective transport equations due to extreme terms, but concept is the same and liead to

$$F_1 = \frac{\Delta t \alpha}{\Delta y^2} \leq \frac{1}{2} \quad F_2 = \frac{\Delta t \nu}{\Delta y^2} \leq \frac{1}{2} \quad (4.16)$$

So for the FTCS explicit method, necessary conditions for stability in terms of grid Fourier numbers,

$$F_1 = \frac{\alpha \Delta t}{\Delta y^2} < \frac{1}{2} \Rightarrow \Delta t < \frac{\Delta y^2}{2\alpha} \quad (4.17)$$

$$F_2 = \frac{\nu \Delta t}{\Delta y^2} < \frac{1}{2} \Rightarrow \Delta t < \frac{\Delta y^2}{2\nu} \quad (4.18)$$

4.1 Another Solution of Interest-Transporation

Injection or suction at surface, can be due to evaporation, sublimation, condensation. PDE the same just new BC.

$$\eta = \frac{y}{\sqrt{\nu x/U_\infty}} \quad \psi = \sqrt{\nu x U_\infty} f(\eta) \quad (4.19)$$

$$u \frac{\partial u}{\partial x} + v \frac{\partial u}{\partial y} = \nu \frac{\partial^2 u}{\partial y^2} \Rightarrow \frac{1}{2} f f'' + f''' = 0 \quad (4.20)$$

$$v = -\frac{\partial \psi}{\partial x} = \frac{U_\infty}{2\sqrt{U_\infty x/\nu}} (-f(\eta) + \eta f'(\eta)) \quad (4.21)$$

at $y = 0, \eta = 0$,

$$v = -\frac{U_\infty}{2\sqrt{U_\infty x/\nu}} f(0) = v_w \Rightarrow f(0) = \frac{2v_w}{U_\infty} \sqrt{\frac{U_\infty x}{\nu}} \quad (4.22)$$

If v_w is constant, no similarity solution. For aligned plate, similarity requires $v_w \sim x^{-1/2}$.

For wedge flows with injection, same similarity formulation described earlier,

$$v(\eta = 0) = v_w = v_0 = -\frac{m+1}{2} \zeta(0) \frac{U_\infty(x)}{\sqrt{U_\infty(x)/\nu}} \quad (4.23)$$

similarity requires

$$v_w \sim \sqrt{\frac{U_\infty(x)}{x}} \sim \sqrt{\frac{Cx^m}{x}} \sim x^{(m-1)/2} \quad (4.24)$$

for similarity, $m = 1, \beta = \pi, v_w$ is constant. If $b = 0, m = 0, v_w \sim x^{-0.5}$.

Now consider heat transfer, flat plate and aligned ($m = 0$)

$$\rho c_p \left(u \frac{\partial T}{\partial x} + v \frac{\partial T}{\partial y} \right) = \alpha \frac{\partial^2 T}{\partial y^2} \Rightarrow \phi'' + Pr f \phi' = 0 \quad (4.25)$$

for a solid plate, $v_w = 0$,

$$Nu_x Re_x^{-1/2} = 0.332 \quad (Pr = 1) \quad 0.292 \quad (Pr = 0.7) \quad (4.26)$$

for $v_w \neq 0$, injection or suction $T_{gas} = T_w, Pr = 1.0$

$$\begin{array}{ccccccc} \frac{v_w}{U_\infty} Re_x^{1/2} & 0.5 & 0.25 & 0 & -0.25 & -0.75 \\ Nu_x Re_x^{-1/2} & 0.0356 & 0.165 & 0.332 & 0.523 & 0.945 \end{array}$$

Table 3: Injection and suction affects HT

from the table we can see suction enhance HT while injection weakens.

4.2 Axisymmetric Plume Above a Point Source

Concentrated source, laminar flow.

Example 4.1:

- Above a candle flame
- Above an electrical component
- On a horizontal surface
- Above a heated sphere

We consider laminar BL flow. Assuming

1. Boussinesq approximations
2. Properties other than ρ are constant
3. Neglect viscous dissipation, pressure work

Equations (cyl. coordinates) and BCs (y is radius)

$$\frac{\partial(yu)}{\partial x} + \frac{\partial(yv)}{\partial y} = 0 \quad (4.27)$$

$$u \frac{\partial u}{\partial x} + v \frac{\partial u}{\partial y} = g\beta(T - T_\infty) + \frac{\nu}{y} \frac{\partial}{\partial y} \left(y \frac{\partial u}{\partial y} \right) \quad (4.28)$$

$$u \frac{\partial T}{\partial x} + v \frac{\partial T}{\partial y} = \frac{\alpha}{y} \frac{\partial}{\partial y} \left(y \frac{\partial T}{\partial y} \right) \quad (4.29)$$

$$y = 0 \quad v = \frac{\partial u}{\partial y} = \frac{\partial T}{\partial y} = 0 \quad (4.30)$$

$$y \rightarrow \infty \quad u \rightarrow 0, \quad T \rightarrow T_\infty \quad (4.31)$$

we can explore a similarity formulation as follows, we define a stream function such that

$$u = \frac{1}{y} \frac{\partial \psi}{\partial y} \quad v = -\frac{1}{y} \frac{\partial \psi}{\partial x} \quad (4.32)$$

we then postulate definitions

$$\eta = b(x)y \quad \psi = \nu c(x)f(\eta) \quad \phi = \frac{T - T_\infty}{d(x)} \quad (4.33)$$

$d(x) = T_0 - T_\infty$, $T_0 = T(y = 0)$. Express y, u, ν, T in terms of $\eta, f(\phi), f'(\phi), \phi$, and substitute to get

$$\begin{aligned} f''' + \frac{g\beta}{\nu^2}(yb) \frac{d}{b^4 c} \phi + \frac{c_x}{yb} f f'' - \left[\frac{c_x}{yb} + \frac{1}{yb} \left(\frac{2cb_x}{b} \right) \right] f'^2 \\ - \frac{c_x}{(yb)^2} f f' - \frac{1}{yb} f'' + \frac{1}{(yb)^2} f' = 0 \end{aligned} \quad (4.34)$$

x subscript means $\frac{d}{dx}$.

$$\frac{\phi''}{Pr} + \frac{c_x}{yb} f \phi' - \frac{1}{yb} \left(\frac{d_x c}{d} \right) f' \phi + \frac{1}{yb} \left(\frac{1}{Pr} \right) \phi' = 0 \quad (4.35)$$

similarity requires that coefficients of terms must be constants or functions of η alone. since $yb = \eta$, similarity requires

$$\frac{d}{b^4 c} = B_1 \quad c_x = B_2 \quad \frac{cb_x}{b} = B_3 \quad \frac{d_x c}{d} = B_4 \quad (4.36)$$

$B_{1,2,3,4}$ are constants or functions of η . For $d(x)$ assumed to be a power law variation $d = Nx^n$, the above relations require that

$$c(x) \sim x \quad b(x) \sim x^{(n-1)/4} \quad (4.37)$$

These properties are satisfied if we pick

$$c(x) = \nu x \quad b(x) = \frac{Gr_x^{1/4}}{x} \quad Gr_x = \frac{g\beta x^3(T_0 - T_\infty)}{\nu^2} \quad (4.38)$$

It follows that

$$\eta = \frac{y}{x} Gr_x^{1/4} \quad \psi = \nu x f(\eta) \quad u = \frac{\nu}{x} Gr_x^{1/2} \frac{f'}{\eta} \quad v = -\frac{\nu}{x} Gr_x^{1/4} \left(\frac{f}{\eta} - \frac{f'}{2} \right) \quad (4.39)$$

and the equations and BCs become

$$f''' + (f - 1) \left(\frac{f'}{\eta} \right)' - \frac{1+n}{2} \frac{f'^2}{\eta} + \eta\phi = 0 \quad (4.40)$$

$$(\eta\phi')' + Pr(f\phi' - nf'\phi) = 0 \quad (4.41)$$

$$f(0) = f'(0) = 0 \quad \phi(0) = 1 \quad \phi'(0) = 0 \quad (4.42)$$

How do we determine n ? Note this is no input of thermal energy downstream of the source, so convected thermal energy above the ambient level $Q(x)$ at any x location must be constant and equal to the rate of heat input at the source

$$Q = \int_0^\infty \rho c_p (T - T_\infty) u 2\pi y \, dy \quad (4.43)$$

substituting to write this in terms of similarity variables.

$$2\pi\rho c_p \nu (T_0 - T_\infty) x \int_0^\infty f' \phi \, d\eta = 2\pi\rho c_p \nu N x^{n+1} \int_0^\infty f' \phi \, d\eta = 0 \quad (4.44)$$

note that n must equal to -1 to make x dependence go away on the *lhs*. So

$$T_0 - T_\infty = \frac{N}{x} \quad N = \frac{Q}{2\pi\rho c_p \nu I} \quad I = \int_0^\infty f' \phi \, d\eta \quad (4.45)$$

For $n = -1$, the equations and BCs become

$$f''' + (f - 1) \left(\frac{f'}{\eta} \right)' + \eta\phi = 0 \quad (4.46)$$

$$(\eta\phi')' + Pr(f\phi)' = 0 \quad (4.47)$$

$$\eta = 0 \quad \left(\frac{f'}{\eta} \right)' = 0 \quad \phi' = 0 \quad \frac{f}{\eta} - \frac{f'}{2} = 0 \quad \phi = 1 \quad (4.48)$$

$$\eta \rightarrow \infty \quad \frac{f'}{\eta} \rightarrow 0 \quad \phi \rightarrow 0 \quad (4.49)$$

It can be shown that the BCs can be equivalently stated as

$$f(0) = f'(0) = \phi'(0) = 0 \quad \phi(0) = 1 \quad f'(\infty) = \text{bounded} \quad (4.50)$$

Integrating the energy equation once with respect to η and using the BCs to evaluate the integration constant yields

$$\eta\phi' + Prf\phi = 0 \quad (4.51)$$

Integrating this from $\eta = 0$ to η yields

$$\phi(\eta) = \phi(0)e^{-Pr \int_0^\eta f/\eta d\eta} \quad (4.52)$$

as momentum equation is numerically integrated to get $f(\eta)$, this can be used to compute $\phi(\eta)$. Solutions of equations and BC's yields velocity and temperature fields for axisymmetric plumes (see plots).

Centerline temperature difference

$$T_0 - T_\infty = \frac{Q}{2\pi\rho c_p \nu I x} \quad (4.53)$$

centerline u velocity

$$u(x, 0) = \sqrt{\frac{g\beta Q}{2\pi\rho c_p \nu I}} \left(\frac{f'}{\eta} \right)_{\eta=0} \quad (4.54)$$

Note this is a constant. Accelerating effects of buoyancy are balanced by deaccelerating effects of entrainment. Defining η_δ as the y location where the dimensionless velocity f'/η drops to 1% of its peak value, it follows that the velocity boundary layer thickness is given by

$$\delta(x) = \eta_\delta \left(\frac{2\pi c_p \mu \nu^2 I}{g\beta Q} \right)^{1/4} \sqrt{x} \quad (4.55)$$

similarly for the thermal BL thickness

$$\delta_t(x) = \eta_{\delta_t} \left(\frac{2\pi c_p \mu \nu^2 I}{g\beta Q} \right)^{1/4} \sqrt{x} \quad (4.56)$$

Mollerndorf and Gebhardt (1974) reported	$Pr = 0.7$	$f''(0)$	$f(\infty)$	I	air	note
	$Pr = 7.0$	1.351	7.91	2.074		

also

$$v = \frac{-\nu}{x} Gr_x^{1/4} \left(\frac{f}{\eta} - \frac{f'}{2} \right) \quad (4.57)$$

entrainment velocity

$$v_\delta = -\frac{\nu}{x} Gr_x^{1/4} \left(\frac{f}{\eta} - \frac{f'}{2} \right)_{\eta \rightarrow \infty} \quad (4.58)$$

what happens at $x = 0$? We don't expect this solution to be very accurate as we assume $x \gg \delta$.

5 Turbulent Flow

5.1 Transition to turbulent flow

disturbances in laminar flow amplify, leading to a chaotic flow field. Usually modeled as fluctuations superimposed on mean fields. Transition in FD internal flow in a round tube., $Re_D = 2300$. Not really this abrupt, transition occurs over a range Re_D near 2300.




Figure 7: different picture for boundary layer flows

For forced flow dictated by momentum transport.

For natural convection flows, process is similar. Key difference is momentum and thermal energy transport affect transition.

For isothermal surface

$$Ra_x = Gr_x Pr = \frac{g\beta(T_w - T_\infty)}{\nu\alpha} x^3 \approx 10^9 \quad (5.1)$$

For uniform heat flux surface

$$Ra^* = Gr_x^* Pr = \frac{g\beta x^4 q_w}{k\nu^2} Pr \approx 5 \times 10^{14} \quad (5.2)$$

Linear stability analysis for natural convection BL flow, predicts that disturbance Fourier frequencies in specific frequency range are amplified leading to transition to turbulent flow.

5.2 FD Turbulent flow

characteristics: eddies, random erratic bursts, chaos. Fluctuations in u, v, T with time. For laminar flow, molecular level diffusive transport only. (Conduction, viscosity transport of momentum.) In turbulent flows, molecular level + turbulent macroscopic transport.

$$\bar{u} = \frac{1}{t_a} \int_0^{t_a} u \, dt = \frac{1}{t_a} \int_0^{t_a} \bar{u} \, dt + \frac{1}{t_a} \int_0^{t_a} u' \, dt \quad (5.3)$$

$\bar{u} = U, \bar{u}' = 0$. Likewise for other velocity components. Decompose:

$$u = U + u' \quad v = V + v' \quad w = W + w' \quad (5.4)$$

Continuity equation

$$\frac{\partial U}{\partial x} + \frac{\partial u'}{\partial x} + \frac{\partial V}{\partial y} + \frac{\partial v'}{\partial y} + \frac{\partial W}{\partial z} + \frac{\partial w'}{\partial z} = 0 \quad (5.5)$$

note

$$\frac{1}{t_a} \int_0^{t_a} \frac{\partial U}{\partial x} \, dt = \frac{1}{t_a} \frac{\partial}{\partial x} \int_0^{t_a} U \, dt = \frac{\partial U}{\partial x} \quad (5.6)$$

$$\frac{1}{t_a} \int_0^{t_a} \frac{\partial u'}{\partial x} \, dt = \frac{1}{t_a} \frac{\partial}{\partial x} \int_0^{t_a} u' \, dt = 0 \quad (5.7)$$

Continuity equation becomes

$$\frac{\partial U}{\partial x} + \frac{\partial V}{\partial y} + \frac{\partial W}{\partial z} = 0 \quad (5.8)$$

subtract and get

$$\frac{\partial u'}{\partial x} + \frac{\partial v'}{\partial y} + \frac{\partial w'}{\partial z} = 0 \quad (5.9)$$

BL cons of momentum,

$$\frac{\partial u}{\partial t} + u \frac{\partial u}{\partial x} + v \frac{\partial u}{\partial y} + w \frac{\partial u}{\partial z} = -\frac{1}{\rho} \frac{\partial P}{\partial x} + \nu \frac{\partial^2 u}{\partial y^2} \quad (5.10)$$

add

$$u \left(\frac{\partial u}{\partial x} + \frac{\partial v}{\partial y} + \frac{\partial w}{\partial z} \right) = 0 \quad (5.11)$$

get

$$\frac{\partial u}{\partial t} + \frac{\partial(uu)}{\partial x} + \frac{\partial uv}{\partial y} + \frac{\partial uw}{\partial z} = -\frac{1}{\rho} \frac{\partial P}{\partial x} + \nu \frac{\partial^2 u}{\partial y^2} \quad (5.12)$$

note $\frac{\partial u}{\partial t} = \frac{\partial U}{\partial t} + \frac{\partial u'}{\partial t}$, steady flow leads to $\frac{\partial U}{\partial t} = 0$. Also time averaging, $\frac{\partial \bar{u}}{\partial t} = 0$. For other terms, e.g.

$$\frac{\partial}{\partial x}(uu) = \frac{\partial}{\partial x}(UU + 2Uu' + u'u') \Rightarrow \overline{\frac{\partial(uu)}{\partial x}} = \frac{\partial}{\partial x}(UU + \overline{u'u'}) \quad (5.13)$$

viscosity term,

$$\frac{\partial^2 u}{\partial y^2} = \frac{\partial^2}{\partial y^2}(U + u') \Rightarrow \overline{\frac{\partial^2 u}{\partial y^2}} = \frac{\partial^2 U}{\partial y^2} \quad (5.14)$$

Mean pressure

$$\overline{\frac{\partial P}{\partial x}} = \frac{\partial \mathcal{P}}{\partial x} \quad (5.15)$$

finally we have

$$\frac{\partial}{\partial x}(UU + \overline{u'u'}) + \frac{\partial}{\partial y}(UV + \overline{u'v'}) + \frac{\partial}{\partial z}(Uw + \overline{u'w'}) = -\frac{1}{\rho} \frac{\partial \mathcal{P}}{\partial x} + \nu \frac{\partial^2 U}{\partial y^2} \quad (5.16)$$

rearranging,

$$\rho U \frac{\partial U}{\partial x} + \rho V \frac{\partial U}{\partial y} + \rho W \frac{\partial U}{\partial z} = -\frac{\partial}{\partial x}(\mathcal{P} + \rho \overline{u'u'}) + \frac{\partial}{\partial y} \left(\mu \frac{\partial U}{\partial y} - \rho \overline{u'v'} \right) + \frac{\partial}{\partial z}(-\rho \overline{u'w'}) \quad (5.17)$$

we assume $O(u') = O(v') = O(w')$ (isotropic), for BL flow,

$$\frac{\partial}{\partial y} \gg \frac{\partial}{\partial x}, \frac{\partial}{\partial z} \quad (5.18)$$

so neglecting terms consistent with this and $w = 0$,

$$\rho U \frac{\partial U}{\partial x} + \rho V \frac{\partial U}{\partial y} = \frac{\partial}{\partial y} \left(\mu \frac{\partial U}{\partial y} - \rho \overline{u'v'} \right) - \frac{\partial \mathcal{P}}{\partial x} \quad (5.19)$$

We can define an eddy diffusivity and turbulent (kinematic) viscosity associated with turbulence

$$\tau_{turb} = -\rho \overline{u'v'} = \mu_{turb} \frac{\partial U}{\partial y} = \rho \epsilon_M \frac{\partial U}{\partial y} \quad (5.20)$$

$$\Rightarrow \epsilon_M = -\frac{\overline{u'v'}}{\frac{\partial U}{\partial y}} \quad (5.21)$$

big when u' and v' are correlated both big at the same time.

$$\tau_{total} = \tau_{visc} + \tau_{turb} = \rho(\nu + \epsilon_M) \frac{\partial U}{\partial y} \quad (5.22)$$

momentum equation becomes

$$U \frac{\partial U}{\partial x} + V \frac{\partial U}{\partial y} = \frac{\partial}{\partial y} \left((\nu + \epsilon_M) \frac{\partial U}{\partial y} \right) - \frac{1}{\rho} \frac{\partial P}{\partial x} \quad (5.23)$$

5.3 Turbulent boundary layer heat transfer

$$\rho c_p \left[\frac{\partial T}{\partial t} + u \frac{\partial T}{\partial x} + v \frac{\partial T}{\partial y} + w \frac{\partial T}{\partial z} \right] = \left[\frac{\partial^2 T}{\partial x^2} + \frac{\partial^2 T}{\partial y^2} + \frac{\partial^2 T}{\partial z^2} \right] \quad (5.24)$$

assume 2D $w = 0$, use decomposition

$$\begin{aligned} \rho c_p \left[U \frac{\partial \bar{T}}{\partial x} + V \frac{\partial \bar{T}}{\partial y} \right] + \rho c_p \left[\frac{\partial}{\partial x} (\bar{u}'T') + \frac{\partial}{\partial y} (\bar{v}'T') + \frac{\partial}{\partial z} (\bar{w}'T') \right] \\ = k \left[\frac{\partial^2 \bar{T}}{\partial x^2} + \frac{\partial^2 \bar{T}}{\partial y^2} \right] + \frac{\partial^2 \bar{T}}{\partial z^2} \end{aligned} \quad (5.25)$$

And for B.L. flow, $\frac{\partial}{\partial y} \gg \frac{\partial}{\partial x}, \frac{\partial}{\partial z}$,

$$\frac{\partial^2 \bar{T}}{\partial x^2} \ll \frac{\partial^2 \bar{T}}{\partial y^2} \quad \frac{\partial^2 \bar{T}}{\partial z^2} \ll \frac{\partial^2 \bar{T}}{\partial y^2} \quad (5.26)$$

Neglecting small terms,

$$\rho c_p \left[U \frac{\partial \bar{T}}{\partial x} + V \frac{\partial \bar{T}}{\partial y} \right] = \frac{\partial}{\partial y} \left[k \frac{\partial \bar{T}}{\partial y} - \rho c_p \bar{v}'T' \right] \quad (5.27)$$

for constant properties this can be written

$$U \frac{\partial \bar{T}}{\partial x} + V \frac{\partial \bar{T}}{\partial y} = \frac{\partial}{\partial y} \left[\alpha \frac{\partial \bar{T}}{\partial y} - \bar{v}'T' \right] \quad (5.28)$$

similar to what we did for momentum transport, we define an eddy diffusivity for heat ϵ_H as

$$\epsilon_H = \frac{-\bar{v}'T'}{\frac{\partial \bar{T}}{\partial y}} \quad (5.29)$$

and the equation becomes

$$U \frac{\partial \bar{T}}{\partial x} + V \frac{\partial \bar{T}}{\partial y} = \frac{\partial}{\partial y} \left[(\alpha + \epsilon_H) \frac{\partial \bar{T}}{\partial y} \right] \quad (5.30)$$

note

$$q''_{molecular} = -k \frac{\partial \bar{T}}{\partial y} \quad q''_{turb} = -k \frac{\partial \bar{T}}{\partial y} = -\rho c_p \epsilon_H \frac{\partial \bar{T}}{\partial y} \quad (5.31)$$

This analysis formulates turbulent transport modeling in terms of ϵ_M and ϵ_H which are related to cross correlations $\overline{v'u'}$ and $\overline{v'T'}$. We also define the turbulent Prandtl number Pr_t ,

$$Pr_t = \frac{\epsilon_M}{\epsilon_H} \quad (5.32)$$

It is often argued that $Pr_t \sim 1.0$. Now the equation

$$U \frac{\partial \bar{T}}{\partial x} + V \frac{\partial \bar{T}}{\partial y} = \frac{\partial}{\partial y} \left[(\alpha + \frac{\epsilon_M}{Pr_t}) \frac{\partial T}{\partial y} \right] \quad (5.33)$$

Some models of turbulent transport are based on analogies with kinetic theory.

Consider a laminar gas flow with velocity profile $U(y)$ near surface, l is mean free path of molecules between collisions. From basic kinetic theory. the velocity distribution is

$$\frac{dN_{uvw}}{N} = f(u, v, w) = \left(\frac{m}{2\pi k_B T} \right)^{3/2} e^{-m(u^2+v^2+w^2)/2k_B T} du dv dw \quad (5.34)$$

$c^2 = u^2 + v^2 + w^2$, mean molecular speed

$$\bar{c} = \sqrt{\frac{8k_B T}{\pi m}} \quad (5.35)$$

In the flow, shear is rate of momentum transport over m^2 . A molecule crossing horizontal plane at y has travelled an average distance l since its last collision. y' is average y location of last collision, $y' = y - vl/\bar{c}$. Using taylor series

$$[p_x]_{y=y'} = [p_x] - \left(\frac{d[p_x]}{dy} \right) \frac{vl}{\bar{c}} \quad (5.36)$$

flux of x direction momentum

$$j_{[p_x]} = \iiint_{-\infty}^{\infty} [p_x]_{y=y'} \nu \rho_N f(u, v, w) du dv dw \quad (5.37)$$

f is the probability of u, v, w combination. substituting leads to

$$j_{[p_x]} = -\frac{1}{3} \rho_n n l \bar{c} \frac{dU}{dy} \quad (5.38)$$

since $\tau = -j_{[p_x]} = \mu \frac{\partial U}{\partial y} = \rho v \frac{\partial U}{\partial y}$

$$\mu = \rho \nu = \frac{1}{3} \rho_N n l \bar{c} c \quad \Rightarrow \quad \nu = \frac{1}{3} \bar{c} l \quad (5.39)$$

l is the distance since last interaction, \bar{c} is characteristic speed. For gases, l can be predicted from kinetic theory, simple analysis:

$$l = \frac{k_B T}{\sqrt{2\pi D^2 P}} \quad (5.40)$$

substitute and get

$$\mu = \frac{1}{3} \left(\frac{1}{\pi} \right)^{3/2} \frac{\sqrt{mk_B T}}{D^2} \quad (5.41)$$

μ depends only on T , not on P .

Similar analysis for transport of internal energy in a temperature gradient yields

$$j_Q = -\frac{1}{3} \left(\frac{\rho_N l \hat{c}_V \bar{c}}{N_A} \right) \frac{\partial T}{\partial y} \quad (5.42)$$

Since Fourier's Law indicates $j_Q = q'' = -k \frac{\partial T}{\partial y}$, then

$$k = \frac{1}{3} \left(\frac{\rho_N l \hat{c}_V \bar{c}}{N_A} \right) = \frac{\mu \hat{c}_v}{m N_A} \Rightarrow \frac{k}{\hat{\rho} \hat{c}_V} = \frac{1}{3} \bar{c} l \quad (5.43)$$

k only depends only on T for ideal gas.

Turbulent flow mixing length hypothesis, based on analogy with kinetic theory. Ball of fluid \Leftrightarrow molecule.

$$\tau_{turb} = \rho \overline{u'v'} \sim \rho \sqrt{\overline{v'^2}} \sqrt{\overline{u'^2}} \quad (5.44)$$

$$O(\sqrt{\overline{u'^2}}) \sim O(u') = U(y) - U(y-1) = \frac{\partial U}{\partial y} l \quad (5.45)$$

l is mixing length, distance along which ball of fluid maintains its identity.

$$\tau_{turb} = \rho \sqrt{\overline{v'^2}} l \frac{\partial U}{\partial y} = \mu_{turb} \frac{\partial U}{\partial y} \quad (5.46)$$

$$\Rightarrow \mu_{turb} = \rho \sqrt{\overline{v'^2}} l \quad (5.47)$$

If turbulence is isotropic,

$$\sqrt{\overline{v'^2}} \sim \sqrt{\overline{u'^2}} \sim l \frac{\partial U}{\partial y} \quad (5.48)$$

$$\tau_{turb} \sim |\rho \overline{v'u'}| \sim l^2 \frac{\partial U}{\partial y} \left| \frac{\partial U}{\partial y} \right| \quad (5.49)$$

mixing length model,

$$\epsilon_M = l^2 \left| \frac{\partial U}{\partial y} \right| \quad \tau_{turb} = \rho \epsilon_M \frac{\partial U}{\partial y} \quad \tau = \rho (\nu + \epsilon_M) \frac{\partial U}{\partial y} \quad (5.50)$$

5.4 Turbulent FD flow in round tube

$$\rho U \frac{\partial U}{\partial x} + \rho V \frac{\partial U}{\partial r} = - \frac{\partial P}{\partial x} + \frac{1}{r} \frac{\partial}{\partial r} (r \tau) \quad (5.51)$$

here $\tau = \nu + \epsilon_M$. FD means $\frac{\partial U}{\partial x} = 0, v = 0$, equation becomes

$$\frac{1}{r} \frac{\partial}{\partial r} (r \tau) = \frac{dP}{dx} = \text{const} \quad (5.52)$$

Integrate once, using $\tau = 0$ at $r = 0$ by symmetry,

$$\tau = \frac{r}{2} \frac{dP}{dx} \Rightarrow \frac{\tau}{\tau_w} = \frac{r}{r_w} \quad \tau_w = \frac{r_w}{2} \frac{dP}{dx} \quad (5.53)$$

combined to eliminate $\frac{dP}{dx}$,

$$\frac{\tau}{\tau_w} = \frac{r}{r_w} \quad (5.54)$$

combine this result with ϵ_M we get

$$\frac{\rho (\nu + \epsilon_M)}{\tau_w} \frac{dU}{dr} = \frac{r}{r_w} \quad (5.55)$$

can solve for $U(r)$ if $\epsilon_M(r)$ is known.

5.5 Turbulent FD heat transfer in a tube

$$\rho U c_p \frac{\partial T}{\partial x} + \rho V c_P \frac{\partial T}{\partial r} = -\frac{1}{r} \frac{\partial}{\partial r} (r q'') \quad (5.56)$$

here $q'' = -\rho c_p (\alpha + \epsilon_M) \frac{\partial T}{\partial r}$ can solve this numerically with known $U(r), \epsilon_M(r)$. Consider simplified case, q''_w is const, so h is const, $Y_w - T_m$ is const. $\frac{dT_w}{dx} = \frac{dT_m}{dx}$. Assume $\frac{\partial T}{\partial x} = \frac{dT_m}{dx}$, and equation becomes

$$\rho U c_p \frac{dT_m}{dx} = -\frac{1}{r} \frac{\partial}{\partial r} (r q'') \quad (5.57)$$

integrate w.r.t. r ,

$$\rho c_p \frac{dT_m}{dx} \int U(r) r dr = -r q'' \quad (5.58)$$

further simplify by taking $U(r) = U_m$ in integral,

$$\rho c_p \frac{dT_m}{dx} \frac{U_m r^2}{2} = -r q'' \quad (5.59)$$

$$q'' = \frac{\rho c_p U_m}{2} \frac{dT_m}{dx} r \Rightarrow \left| \frac{q''}{q''_w} \right| = \frac{r}{r_w} \quad (5.60)$$

note for both

$$\left| \frac{q}{q''_w} \right| = \frac{\tau}{\tau_w} = \frac{r}{r_w} \quad (5.61)$$

so

$$\frac{\rho c_p (\alpha + \epsilon_H) \frac{dT}{dr}}{q''_w} = \frac{\rho (\nu + \epsilon_M) \frac{dU}{dr}}{\tau_w} \quad (5.62)$$

rearrange to find

$$\frac{\tau_w}{q''_w} c_p \left(\frac{\alpha + \epsilon_H}{\nu + \epsilon_M} \right) dT = dU \quad (5.63)$$

for $Pr = Pr_T = 1$, the bracket is 1, so

$$\frac{\tau_w}{q''_w} c_p dT = dU \Rightarrow \frac{\tau_w}{q''_w} c_p (T_m - T_w) = U_m \quad (5.64)$$

note

$$\frac{T_m - T_w}{q''_w} = \frac{1}{h} \quad \tau_w = c_f \frac{\rho U_m^2}{2} \quad (5.65)$$

substitute to get

$$\frac{c_f}{2} = \frac{h}{\rho U_m c_p} = St \quad \text{for } Pr = 1 \quad (5.66)$$

This is called heat transfer Raynolds analogy

For $Pr \neq 1$, experimental data imply

$$\frac{c_f}{2} = St Pr^n \quad n \approx \frac{2}{3} \quad (5.67)$$

Since $c_f = f(Re)$, analogy implies $St Pr^{2/3} = f(Re)$, ususally define colburn j factor $j = St Pr^{2/3}$.

And for laminar fully developed flow in a round tube (isothermal wall), $Nu_D = \frac{hD}{k} - 3.66$,

$$St = \frac{h}{\rho U_m c_p} = 3.66 Pr^{-1} Re^{-1} \quad j = 3.66 Pr^{-1/3} Re^{-1} \quad (5.68)$$

and laminar result $f = \frac{16}{Re}$.

5.6 Near wall in turbulent flows




Figure 8: Near wall flow regime

In Fully turbulent regime, we expect $\epsilon_M \gg \nu$. Also, we have the x dir momentum equation

$$U \frac{\partial U}{\partial x} + V \frac{\partial U}{\partial y} = - \frac{\partial P}{\partial x} + \frac{1}{r} \frac{\partial}{\partial r}(r\tau) \quad (5.69)$$

Close to wall we expect terms on *lhs* to be small since velocities are low there.

$$0 = - \frac{dP}{dx} + \frac{1}{r} \frac{\partial}{\partial r}(r\tau) \quad (5.70)$$

If we have flow in a pipe, $\frac{dP}{dx}$ is constant and $\neq 0$, and as before

$$\frac{\tau}{\tau_w} = \frac{r}{r_w} - 1 = 1 - \frac{y}{r_w} \quad (5.71)$$

for $y \ll r_w$, $\tau \approx \tau_w$.

If we have a free boundary layer flow with $\frac{dP}{dx} = 0$, equation becomes

$$\frac{\partial}{\partial r}(r\tau) = 0 \Rightarrow r\tau = \text{const} = r_w\tau_w \quad (5.72)$$

$$\tau = \frac{r_w}{r} \tau_w = \frac{r_w}{r_w - y} \tau_w = \frac{1}{1 - y/r_w} \tau_w \quad (5.73)$$

and again if $y \ll r_w$ leads to $\tau = \tau_w$. For constant shear region, $\tau = \tau_w = \epsilon_M \frac{\partial U}{\partial y}$. or if we use mixing length theory

$$\frac{\tau_w}{\rho} = l^2 \left(\frac{\partial U}{\partial y} \right)^2 \quad (5.74)$$

and using $l = \kappa y$ proposed by Prandtl. He argued that eddy size varied proportional to distance from the wall implying $l \sim y$, so

$$\frac{\tau}{\rho} = \kappa^2 y^2 \left(\frac{U}{y} \right)^2 \quad (5.75)$$

data indicates $\kappa = 0.41$, called Von Karmen const.

Next introduce non-dimensional variables

$$u^+ = \frac{U}{\sqrt{\tau_w/\rho}} \quad y^+ = \frac{y\sqrt{\tau_w/\rho}}{\nu} \quad (5.76)$$

substituting into equation and we find

$$\frac{du^+}{dy^+} = \frac{1}{\kappa y^+} \quad \tau = \tau_w \quad (5.77)$$

Integrating this equation,

$$u^+ = \frac{1}{\kappa} \ln y^+ + c_0 \quad (5.78)$$

the best fit to experimental velocity profile data in the fully turbulent portion of the near wall region is achieved with $c_0 = 5.0$.

$$u^+ = 2.44 \ln y^+ + 5.0 \quad (5.79)$$

note that as $y^+ \rightarrow 0$, $u^+ \rightarrow -\infty$, which is not physically realistic.

Very close to the wall we expect to find a viscous sublayer in which $\nu \gg \epsilon_M$, for constant τ region,

$$\frac{\tau}{\rho} = \nu \frac{\partial U}{\partial u} \quad (5.80)$$

Integrating from wall yields

$$\int_0^U dU = \frac{\tau_w}{\mu} \int_0^y dy \Rightarrow U = \frac{\tau_w}{\mu} y \quad (5.81)$$

substituting yields $u^+ = y^+$ for viscous sublayer.




Figure 9: Similarity turbulent result

Comparison of these equations with data. Indicates data agrees with viscous sublayer relation to about $y^+ = 5$ and then transitions to fully turbulent region. u^+ vs y^+ relation established experimentally is the universal velocity profile near a wall for $\frac{dP}{dx} = 0$ or low-moderate $\frac{dP}{dx}$ values.

Note: need best fit near wall (small to moderate y^+) to predict heat transfer well at wall.

Other curve-fit relations for the universal velocity profile have been proposed. e.g., power law fit

$$u^+ = 8.75(y^+)^{1/7} \quad (5.82)$$

which fits fairly well to $y^+ = 1500$. More convenient for calculations (not segmented). A variation is

$$u^+ = A(y^+)^n \quad (5.83)$$

where n is a function of Re or y^+ . e.g., 3 layer model

Viscous sublayer $0 \leq y^+ \leq 5$, $u^+ = y^+$

Buffer region $5 < y^+ \leq 30$, $u^+ = -3.05 + 5 \ln y^+$

Fully turbulent region $y^+ > 30$ $u^+ = 5.5 + 2.5 \ln y^+$

Note if we have a relation $u^+ = u^+(y^+)$ for the universal profile, we can derive a relation for ϵ_M

$$u^+ = \frac{U}{\sqrt{\tau_w/\rho}} = u^+(y^+) \quad y^+ = y \frac{\sqrt{\tau_w/\rho}}{\nu} \Rightarrow \quad (5.84)$$

$$\frac{\partial U}{\partial y} = \sqrt{\frac{\tau_w}{\rho}} \frac{du^+}{dy} = \frac{\tau_w}{\rho\nu} \frac{du^+}{dy^+} \quad (5.85)$$

In general $\tau = \rho(\nu + \epsilon_M) \frac{\partial U}{\partial y}$. And for the constant shear layer near the wall, $\tau = \tau_w$ so

$$\tau_w = \rho(\nu + \epsilon_M) \frac{\partial U}{\partial y} = \rho(\nu + \epsilon_M) \frac{\tau_w}{\rho\nu} \frac{du^+}{dy^+} \quad (5.86)$$

solve,

$$\frac{\epsilon_M}{\nu} = \frac{1}{\frac{du^+}{dy^+}} - 1 \quad (5.87)$$

which predicts $\epsilon_M = \epsilon_M(y^+)$.

1. In viscous sublayers

$$u^+ = y^+, \quad (5.88)$$

Or for a 3 regime model,

1. Viscous sublayer $0 \leq y^+ \leq 5$: $u^+ = y^+$, $\epsilon_M = 0$

Another example: van Driest model, mixing length is $l = \kappa y(1 - e^{-y/A})$

$$y/A = y^+/A^+ \quad l = \frac{\kappa y^+ \nu}{\sqrt{\tau_w/\rho}} (1 - e^{-y^+/A^+}) \quad (5.89)$$

where $A^+ \sim 26.0$ is good for fitting data. With this we have

$$\epsilon_M = l^2 \left| \frac{\partial u}{\partial y} \right| \quad (5.90)$$

using definitions to replace y with y^+ and U with u^+ yields

$$\frac{\epsilon_m}{\nu} = \kappa^2 y^{+2} (1 - e^{-y^+/A^+}) \frac{du^+}{dy^+} \quad (5.91)$$

note: can get relation $\frac{\epsilon_M}{\nu}(y^+)$ if we know $u^+(y^+)$.

Note also the relations for $u^+(y^+)$ can be modified to include effects of suction, blowing (at the wall) or finite $\frac{\partial P}{\partial x}$ if necessary.

5.7 Two equations approach

$k - \epsilon$ two-equation model of turbulent transport. Concept: turbulent kinetic energy and dissipation of turbulent kinetic energy vary throughout flow field.

$$k' = \frac{1}{2}(u'u' + v'v' + w'w') \quad \bar{k} = \frac{1}{2}(\overline{u'u'} + \overline{v'v'} + \overline{w'w'}) \quad (5.92)$$

consider mixing length model

$$\epsilon_M = l^2 \left| \frac{\partial U}{\partial y} \right| = l_{ml} \left(l_{ml} \cdot \left| \frac{\partial U}{\partial y} \right| \right) \quad (5.93)$$

this is length scale times velocity scale, which suggests $\epsilon_M = al_k\sqrt{\bar{k}}$, l_k is eddy size in turbulence.

Dimensional analysis suggests that dissipation ϵ

$$\epsilon = C_D \frac{(\sqrt{\bar{k}})^3}{l_\epsilon} \quad \Phi \sim \rho\nu \left(\frac{\partial u}{\partial y} \right)^2 \sim \rho m^2/s^3 \quad (5.94)$$

A bit of reasoning can be applied to relate l_k and l_ϵ to l_{ml} , which leads to

$$\epsilon_M = C_D^{1/4} l_{ml} \sqrt{\bar{k}} \quad \epsilon = C_d^{3/4} \frac{\bar{k}^{3/2}}{l_{ml}} \quad (5.95)$$

To use in transport modeling, we need to predict \bar{k} and ϵ throughout the flow. With decomposition and time-averaging of equations, we can derive equations for transport of \bar{k} and ϵ .

Example 5.1:

Deriving \bar{k} equation for boundary layer flow, start with

$$u \frac{\partial u}{\partial x} + v \frac{\partial u}{\partial y} = - \frac{\partial p}{\partial x} + \frac{\nu \partial^2 u}{\rho \partial y^2} \quad (5.96)$$

multiply by u and use continuity to get

$$\frac{\partial}{\partial x}(uu^2/2) + \frac{\partial}{\partial y}(vu^2/2) = \nu \frac{\partial^2}{\partial y^2}(u^2/2) - \nu \left(\frac{\partial u}{\partial y} \right)^2 - u \frac{\partial P}{\partial x} \quad (5.97)$$

then substitute $u = U + u'$, $v = V + v'$, $p = P + p'$, $\frac{\partial P}{\partial x} = 0$, time average, combine with mean velocity equation

$$U \frac{\partial U}{\partial x} + V \frac{\partial U}{\partial y} = \nu \frac{\partial^2 U}{\partial y^2} - \frac{\partial}{\partial y}/9\overline{u'v'} \quad (5.98)$$

multiplied by U . Neglect x derivative terms compared to y derivative terms (BL approx). Write result in terms of

$$\bar{k} = \frac{1}{2}(\overline{u'u'} + \overline{v'v'} + \overline{w'w'}) \quad \epsilon = \nu \left(\frac{\partial u'_i}{\partial x_j} \frac{\partial u'_i}{\partial x_j} \right) \quad (5.99)$$

resulting equation

$$\rho U \frac{\partial \bar{k}}{\partial x} + \rho V \frac{\partial \bar{k}}{\partial y} = \frac{\partial}{\partial y} \left[-\rho \overline{v'k'} - \overline{v'P'} + \mu \frac{\partial \bar{k}}{\partial y} \right] - \rho \overline{u'v'} \frac{\partial \bar{V}}{\partial y} - \rho \epsilon \quad (5.100)$$

with modeling implemented

$$U \frac{\partial \bar{k}}{\partial x} + v \frac{\partial \bar{K}}{\partial y} = \frac{\partial}{\partial y} \left[(\nu + \epsilon_k) \frac{\partial \bar{k}}{\partial y} \right] + \epsilon_M \left(\frac{\partial U}{\partial y} \right)^3 - \epsilon \quad (5.101)$$

can similarly derive an equation for local dissipation ϵ

$$U \frac{\partial \epsilon}{\partial x} + V \frac{\partial \epsilon}{\partial y} = \frac{\partial}{\partial y} \left[(\nu + \epsilon_\epsilon) \frac{\partial \epsilon}{\partial y} \right] + c_1 \frac{\epsilon}{\bar{k}} \left(\epsilon_M \left(\frac{\partial U}{\partial y} \right)^2 \right) - c_2 \frac{\epsilon^2}{\bar{k}} \quad (5.102)$$

typical definitions,

$$Sc_\epsilon = \epsilon_M / \epsilon \quad Sc_k = \epsilon_M / \epsilon_k \quad (5.103)$$

\bar{k} and ϵ equations are solved simultaneously with mean continuity, u -momentum and energy equations for model constants. we also need boundary conditions (\bar{k}, ϵ match at sublayer boundary). Example,

$$\epsilon_M = C_\mu \bar{k}^2 / \epsilon \quad C_\mu = 0.09 \quad (5.104)$$

$$C_1 = 1.44 \quad C_2 = 1.92 \quad Sc_k = 1.0 \quad Sc_\epsilon = 1.3 \quad (5.105)$$

note these equations apply outside the sublayer.

Inside sublayer, use law of the wall or mixing length model. Law of the wall still important for predicting heat transfer at the wall.

6 Mass transfer

Note that for each convective transport of thermal energy(we will consider BL case specifically)

$$\rho c_p \left(u \frac{\partial T}{\partial x} + v \frac{\partial T}{\partial y} \right) = \frac{\partial}{\partial y} \left(k \frac{\partial T}{\partial y} \right) = - \frac{\partial}{\partial y} q'' \quad (6.1)$$

define i as enthalpy/unitmass $i = c_p T$, we can rewrite equation as

$$\rho u \frac{\partial i}{\partial x} + \rho v \frac{\partial i}{\partial y} = \frac{\partial}{\partial y} \left(\frac{k}{c_p} \frac{\partial i}{\partial y} \right) \quad (6.2)$$

so i is a transportable property per unit mass of fluid. Flux of this property (relation to center of mass of moving fluid) is

$$q'' = j_i = - \frac{k}{c_p} \frac{\partial i}{\partial y} \Leftrightarrow \frac{1}{c_p} \frac{\partial i}{\partial y} = \frac{\partial T}{\partial y} \quad (6.3)$$

another transportable quantity is the mass of species 1 per unit of total fluid mass c_1 . Species concentration on flux j_{c1} obeys the diffusive transport relation known as Fick's law.

$$m''_{c1} = j_{c1} = - \rho D_{12} \frac{\partial c_1}{\partial y} \quad (6.4)$$

we invoke the analogy

$$-q'' = \frac{k}{c_p} \frac{\partial i}{\partial y} \Leftrightarrow -j_{c1} = \rho D_{12} \frac{\partial c_1}{\partial y} \quad (6.5)$$

the mass transport for species 1 is

$$\rho \left(u \frac{\partial c_1}{\partial x} + v \frac{\partial c_1}{\partial y} \right) = \frac{\partial}{\partial y} \left(\rho D_{12} \frac{\partial c_1}{\partial y} \right) \quad (6.6)$$

or for constant density D_{12}

$$u \frac{\partial c_1}{\partial x} + v \frac{\partial c_1}{\partial y} = D_{12} \frac{\partial^2 c_1}{\partial y^2} \quad (6.7)$$

6.1 Forced convection with mass flow over a flat plate

$$\frac{\partial u}{\partial x} + \frac{\partial v}{\partial y} = 0 \quad u \frac{\partial u}{\partial x} + v \frac{\partial u}{\partial y} = \nu \frac{\partial^2 u}{\partial y^2} \quad (6.8)$$

$$u \frac{\partial T}{\partial x} + v \frac{\partial T}{\partial y} = \alpha \frac{\partial^2 T}{\partial y^2} \quad u \frac{\partial c_1}{\partial x} + v \frac{\partial c_1}{\partial y} = D_{12} \frac{\partial^2 c_1}{\partial y^2} \quad (6.9)$$

binary mixture $c_2 = 1 - c_1$. BC

$$y = 0 \quad : \quad u = 0 \quad v = v_0 \quad T = T_0 \quad c_1 = c_{10} \quad (6.10)$$

$$y = \infty \quad : \quad u = U_\infty \quad T = T_\infty \quad c_1 = c_{1\infty} \quad (6.11)$$

similarity solution

$$\eta = \frac{y}{2} \sqrt{\frac{U_\infty}{\nu x}} \quad \theta = \frac{T - T_\infty}{T_\infty - T_0} = \frac{c_1 - c_{10}}{c_{1\infty} - c_{10}} \quad (6.12)$$

$$f(\eta) = \psi / \sqrt{U_\infty \nu x} \quad u = \frac{\partial \psi}{\partial x} \quad v = -\frac{\partial \psi}{\partial y} \quad (6.13)$$

equations and BC become

$$f''' + \frac{1}{2} f f'' = 0 \quad (6.14)$$

$$\theta'' + \frac{1}{2} \frac{\nu}{\alpha} f \theta' = 0 \quad (6.15)$$


$$\phi'' + \frac{1}{2} \frac{\nu}{D} f \phi' = 0 \quad (6.16)$$

$$\eta = 0 \quad : \quad f' = 0 \quad \theta = 0 \quad \phi = 0 \quad f = \frac{2v_0}{U_\infty} \quad (6.17)$$

Note that here we define a mass transfer coefficient μ_D such that

$$m_1'' = \mu_D (c_{1,s} - c_{1,\infty}) \quad (6.18)$$

Example 6.1: wet and dry bulb thermometer



at steady state, negligible conduction into thermometer. surface energy balance on wet bulb

$$\text{heat transfer from air} = \text{evaporation rate } h_{ev} \quad (6.19)$$

$$\bar{h}_c(T_{db,\infty} - T_s)A = \bar{h}_D(c_{1,s} - c_{1,\infty})Ah_{ev} \quad (6.20)$$

rearrange this to solve for $c_{1,\infty}$

$$c_{1,\infty} = c_{1,s} - \frac{\bar{h}_c}{\bar{h}_D h_{ev}}(T_{db,\infty} - T_s) \quad (6.21)$$

$$c_{1,s} = \frac{x_{1,s}M_1}{x_{1,s}M_1 + (1 - x_{1,s})M_2} \quad (6.22)$$

$$x_{1,s} = \frac{p_{sat}(T_s)}{p_{atm}} \quad (6.23)$$

If we measure T_s and T_{db} , compute $x_{1,s}, c_{1,s}, c_{1,\infty}$ then

$$x_{1,\infty} = \frac{c_{1,\infty}/M_1}{\frac{c_{1,\infty}}{M_1} + \frac{1-c_{1,\infty}}{M_2}} \quad (6.24)$$

RH is $x_{1,\infty}/x_{1,s}$

For flow over a cylinder or sphere, heat transfer - mass transfer analogy leads to similar relations for the mean heat transfer and mass transfer coefficients

$$\frac{\bar{h}_c D}{k_f} = 0.615 Re_D^{0.466} Pr^{1/3} \quad 40 < Re_D < 4000 \quad (6.25)$$

$$\frac{\bar{h}_c D}{k_f} = 0.172 Re_D^{0.618} Pr^{1/3} \quad 4000 < Re_D < 40000 \quad (6.26)$$

$$\frac{\bar{h}_c D}{k_f} = A Re_D^n Pr^{1/3} \Rightarrow \frac{\bar{h}_c}{\rho c_p U_\infty} \frac{\mu c_p}{\mu} \frac{D}{k_f} = A Re_D^n Pr^{4/3} \quad (6.27)$$

so

$$St = \frac{\bar{h}_c}{\rho c_p U_\infty} = A Re_D^{n-1} Pr^{-2/3} \quad (6.28)$$

by analogy, we expect

$$St_m = \frac{\bar{h}_D}{\rho U_\infty} = A Re_D^{n-1} Sc^{-2/3} \quad (6.29)$$

taking the ratio of St/St_m yields

$$\frac{\bar{h}_c}{c_p \bar{h}_D} = \left(\frac{Pr}{Sc} \right)^{-2/3} \quad (6.30)$$

define Lewis number

$$Le = \frac{\bar{h}_c}{c_p \bar{h}_D} = \left(\frac{Pr}{Sc} \right)^{-2/3} \quad (6.31)$$

for water -vapor and air mixtures $Le \approx 1$

So measure T_{db} , T_{wb} , compute $x_{1,s}$, $c_{1,s}$, use above relation.