

Client:	VotingWorks	Doc. No.: VWX-001-D018
Project:	Ballot Receptacle	Revision: X01
Doc. Title:	Floor Assembly Instructions	Date: 11/01/2024

## 1.0 PURPOSE

The purpose of this document is to describe the required parts, assemblies, tools, preparation, and process to assemble the Floor Assembly (VX~01-10048).

## 2.0 PARTS & ASSEMBLIES

## 2.1 Made-To-Spec (MTS)

Item Number	Description
VX~02-10059	FLOOR, FRAME
VX~02-10050	TOE KICK OUTER
VX~02-10127	TOE KICK INNER

## 2.2 Off-The-Shelf (OTS)

Item Number	Description
VX~99-10054	SPACER, SEMI-TUBULAR RIVET, 3/16 IN
VX~99-10053	SEMI-TUBULAR RIVET, 3/16 IN X 11/32 IN, AL
VX~99-10052	POP RIVET, 5/32 IN X 0.55 IN, BLACK, AL
VX~99-10051	FOOT, RUBBER



Client:	VotingWorks	Doc. No.: VWX-001-D018
Project:	Ballot Receptacle	Revision: X01
Doc. Title:	Floor Assembly Instructions	Date: 11/01/2024

## 3.0 TOOLS

# 3.1 Made-To-Spec (MTS)

Item Number	Description

# 3.2 Off-The-Shelf (OTS)


Supplier	Part Number	Description
JAY-CEE	TO-TP-888-3	Solid rivet Semi-tubular Rivet Squeezer 3" Reach, 1-1/4" Gap
JAY-CEE	TO-200-OH05	5/16 (.312) HEAD SET FOR RIVET SQUEEZER
JAY-CEE	TO-200-4506	Roll Over Set for 3/16
ZIPP	ZT1017VS	PNUEMATIC BLIND RIVET TOOL
-	-	FINE TIP TWEEZERS
-	-	HAND DRILL
-	-	#20 DRILL BIT



Client:	VotingWorks	Doc. No.: VWX-001-D018
Project:	Ballot Receptacle	Revision: X01
Doc. Title:	Floor Assembly Instructions	Date: 11/01/2024

#### 4.0 PREPARATION

Adjust the rivet squeezer to 18.4 mm



## 5.0 ASSEMBLY PROCESS

Assemble the Floor Assembly (VX $\sim$ 01-10048) as defined in the following steps.



Client:	VotingWorks	Doc. No.: VWX-001-D018
Project:	Ballot Receptacle	Revision: X01
Doc. Title:	Floor Assembly Instructions	Date: 11/01/2024

#### STEP 1 **INSTALL RUBBER FEET TO THE FLOOR FRAME**

1.1 Place the floor frame part onto the working surface with the bent tabs facing upward



- 1.2 Chase rubber feet mounting holes with #20 sized drill bit
- Place the rubber foot over the left tab hole (shorter tab) 1.3



Page

4 of 13



Client:	VotingWorks	Doc. No.: VWX-001-D018
Project:	Ballot Receptacle	Revision: X01
Doc. Title:	Floor Assembly Instructions	Date: 11/01/2024

1.4 Push the rivet through both the rubber foot and the floor tab.



1.5 Repeat steps 1.2 and 1.3 with the right tab



- 1.6 Using the pop rivet tool, fully install the pop rivets to affix the rubber feet to the floor tabs.
- 1.7 Test the rubber foot retention by trying to move it around. The rubber foot should be secured to the floor frame part.



Client:	VotingWorks	Doc. No.: VWX-001-D018
Project:	Ballot Receptacle	Revision: X01
Doc. Title:	Floor Assembly Instructions	Date: 11/01/2024

#### STEP 2 INSTALL THE TOE KICK TO THE FLOOR FRAME

2.1 Set a floor, with its tabs facing upwards, onto blocks to prop its mounting tabs ~3in above the bench surface.



Page

6 of 13



Client:	VotingWorks	Doc. No.: VWX-001-D018
Project:	Ballot Receptacle	Revision: X01
Doc. Title:	Floor Assembly Instructions	Date: 11/01/2024


# 2.2 Push the semi-tubular rivet through the outer toe kick





Client:	VotingWorks	Doc. No.: VWX-001-D018
Project:	Ballot Receptacle	Revision: X01
Doc. Title:	Floor Assembly Instructions	<b>Date:</b> 11/01/2024

2.3 Slide the semi-tubular rivet into the pivot hole of the Floor with a Semi-tubular rivet spacer (VX~99-10054) between the Outer toe kick and the floor tab and a second Semi-tubular rivet spacer after the Floor tab as shown.





Client:	VotingWorks	Doc. No.: VWX-001-D018	
Project:	Ballot Receptacle	Revision: X01	
Doc. Title: Floor Assembly Instructions		Date: 11/01/2024	

#### 2.4 Insert the inner toe kick onto the outer toe kick




- 2.5 Using the rivet squeezer affix the rivet in place
- 2.6 Repeat for 2.1 through 2.5 for the second floor



Client: VotingWorks		Doc. No.: VWX-001-D018	
Project:	Ballot Receptacle	Revision: X01	
Doc. Title:	Floor Assembly Instructions	Date: 11/01/2024	

#### STEP 3 FINAL ASSEMBLY

3.1 Place both floor parts onto blocks to prop the assemblies ~3in above the bench with their toe kicks interleaved.





Client:	VotingWorks	Doc. No.: VWX-001-D018
Project:	Ballot Receptacle	Revision: X01
Doc. Title:	Floor Assembly Instructions	Date: 11/01/2024

3.2 Attach the floor together by sliding a Semi-tubular rivet through each Toe kick with a a Semi-tubular rivet spacer ( $VX^99-10054$ ) on each side of the floor tab. Use fine tip tweezers to place the rivet spacer in position while installing the rivet.







Client: VotingWorks		Doc. No.: VWX-001-D018	
Project:	Ballot Receptacle	Revision: X01	
Doc. Title:	Floor Assembly Instructions	Date: 11/01/2024	

# 3.3 Using the rivet squeezer affix the rivets in place



3.4 Check the final assembly for excessive toe kick play. If necessary, re-squeeze the rivets with a tighter squeezer setup



Client: VotingWorks Doc. N		Doc. No.: VWX-001-D018
Project:	Ballot Receptacle	Revision: X01
Doc. Title: Floor Assembly Instructions		Date: 11/01/2024

#### **REVISION HISTORY AND APPROVALS**

If this document is a released alpha-revision, a record of the approvers and specifics of the approval process associated with each released version of this document is contained in the CR# listed in the table, and available for review on NOVO's online CR system.

Rev	Description	CR#	Date	Submitted By
X01	Initial Draft	N/A		