

VxPrint Hardware Setup

Hardware Overview

VxPrint is a commercial off-the-shelf (COTS) laptop pre-installed with VotingWorks software alongside a COTS laser printer.

VxPrint Setup

1. Unbox and Set Up Printer:

- ☐ Remove the printer and power cord from the case
- ☐ Plug the power cord into the back of the printer
- ☐ Plug the power cord into an outlet
- ☐ Press the power button to turn the printer on
- ☐ Load paper into the lower paper tray




 For printer troubleshooting — toner, print quality, paper type, and other issues — see the [HP Printer FAQ's](#).

2. Set Up VxPrint Laptop:

- ☐ Remove laptop from case and document seals as necessary

- ☐ Pull the **power cord** (A) out and plug into the laptop and an outlet
- ☐ Pull the **USB hub** (B) out and plug into the laptop
- ☐ Pull the **printer cord** (C) out and plug into the USB hub and the printer
- ☐ Turn the laptop on

 An optional mouse is included. Plug it in to the USB hub to use.



Packing Up VxPrint

To pack up VxPrint, place all of the components back into the case as displayed above. Secure the case as required by sealing the eyelets.

[screenshot]