


P3-1 —
 P3-2 — GREY1/+5V
 P3-3 —
 P3-4 —
 P3-5 —
 P3-6 —
 P3-7 —
 P3-8 — BLACK1/SI-D/GPIO14
 P3-9 —
 P3-10 — WHITE1/SI-E/GPIO15
 P3-11 — ORANGE1/GPIO17/GND
 P3-12 — BROWN1/GPIO18/GND
 P3-13 —
 P3-14 — GREY2/GND
 P3-15 — WHITE2/SO-DN/GPIO22
 P3-16 — PURPLE2/SO-EN/GPIO23
 P3-17 —
 P3-18 —
 P3-19 — BLUE1/CLK/GPIO10
 P3-20 —
 P3-21 — GREEN1/CS-N/GPIO9
 P3-22 —
 P3-23 — YELLOW1/SI-A/GPIO11
 P3-24 — PURPLE1/RESET-N/GPIO8
 P3-25 —
 P3-26 —
 P3-27 —
 P3-28 —
 P3-29 —
 P3-30 —
 P3-31 —
 P3-32 — RED1/SI-B/GPIO12
 P3-33 — BLUE2/SI-C/GPIO13
 P3-34 — GREEN2/GND
 P3-35 — BLACK2/SO-AN/GPIO19
 P3-36 — YELLOW2/GPIO16/GND
 P3-37 —
 P3-38 — ORANGE2/SO-BN/GPIO20
 P3-39 — BROWN2/GND
 P3-40 — RED2/SO-CN/GPIO21



BLACK1/SI-D/GPIO14	1
WHITE1/SI-E/GPIO15	2
GREY1/+5V	3
PURPLE1/RESET-N/GPIO8	4
BLUE1/CLK/GPIO10	5
GREEN1/CS-N/GPIO9	6
YELLOW1/SI-A/GPIO11	7
ORANGE1/GPIO17/GND	8
RED1/SI-B/GPIO12	9
BROWN1/GPIO18/GND	10
BLACK2/SO-AN/GPIO19	11
WHITE2/SO-DN/GPIO22	12
GREY2/GND	13
PURPLE2/SO-EN/GPIO23	14
BLUE2/SI-C/GPIO13	15
GREEN2/GND	16
YELLOW2/GPIO16/GND	17
ORANGE2/SO-BN/GPIO20	18
RED2/SO-CN/GPIO21	19
BROWN2/GND	20

SV3

SV1-1	—
GREY1/+5V	—
SV1-2	—
PURPLE1/RESET-N/GPIO8	—
SV1-3	—
BLACK2/SO-AN/GPIO19	—
SV1-4	—
GREEN1/CS-N/GPIO9	—
SV1-5	—
BLUE1/CLK/GPIO10	—
SV1-6	—
SV1-7	—
YELLOW1/SI-A/GPIO11	—
SV1-8	—
SV1-9	—
RED1/SI-B/GPIO12	—
SV1-10	—
SV1-11	—
SV1-12	—
BLUE2/SI-C/GPIO13	—
SV1-13	—
ORANGE1/GPIO17/GND	—
SV1-14	—
BLACK1/SI-D/GPIO14	—
SV1-15	—
GREEN2/GND	—
SV1-16	—
WHITE1/SI-E/GPIO15	—
SV1-17	—
BROWN1/GPIO18/GND	—
SV1-18	—
WHITE2/SO-DN/GPIO22	—
SV1-19	—
GREY2/GND	—
SV1-20	—
PURPLE2/SO-EN/GPIO23	—
SV1-21	—
YELLOW2/GPIO16/GND	—
SV1-22	—
RED2/SO-CN/GPIO21	—
SV1-23	—
BROWN2/GND	—
SV1-24	—
ORANGE2/SO-BN/GPIO20	—
SV1-25	—
SV1-26	—