


P3-1 —
 P3-2 — GREY1/+5V
 P3-3 —
 P3-4 —
 P3-5 —
 P3-6 —
 P3-7 —
 P3-8 — BLACK1/SI-D/GPIO14
 P3-9 —
 P3-10 — WHITE1/SI-E/GPIO15
 P3-11 — ORANGE1/GPIO17/GND
 P3-12 — BROWN1/GPIO18/GND
 P3-13 —
 P3-14 — GREY2/GND
 P3-15 — WHITE2/SO-DN/GPIO22
 P3-16 — PURPLE2/SO-EN/GPIO23
 P3-17 —
 P3-18 —
 P3-19 — BLUE1/CLK/GPIO10
 P3-20 —
 P3-21 — GREEN1/CS-N/GPIO9
 P3-22 —
 P3-23 — YELLOW1/SI-A/GPIO11
 P3-24 — PURPLE1/RESET-N/GPIO8
 P3-25 —
 P3-26 —
 P3-27 —
 P3-28 —
 P3-29 —
 P3-30 —
 P3-31 —
 P3-32 — RED1/SI-B/GPIO12
 P3-33 — BLUE2/SI-C/GPIO13
 P3-34 — GREEN2/GND
 P3-35 — BLACK2/SO-AN/GPIO19
 P3-36 — YELLOW2/GPIO16/GND
 P3-37 —
 P3-38 — ORANGE2/SO-BN/GPIO20
 P3-39 — BROWN2/GND
 P3-40 — RED2/SO-CN/GPIO21



BLACK1/SI-D/GPIO14	1
WHITE1/SI-E/GPIO15	2
GREY1/+5V	3
PURPLE1/RESET-N/GPIO8	4
BLUE1/CLK/GPIO10	5
GREEN1/CS-N/GPIO9	6
YELLOW1/SI-A/GPIO11	7
ORANGE1/GPIO17/GND	8
RED1/SI-B/GPIO12	9
BROWN1/GPIO18/GND	10
BLACK2/SO-AN/GPIO19	11
WHITE2/SO-DN/GPIO22	12
GREY2/GND	13
PURPLE2/SO-EN/GPIO23	14
BLUE2/SI-C/GPIO13	15
GREEN2/GND	16
YELLOW2/GPIO16/GND	17
ORANGE2/SO-BN/GPIO20	18
RED2/SO-CN/GPIO21	19
BROWN2/GND	20

SV3

SV1-1	GREY1/+5V
SV1-2	PURPLE1/RESET-N/GPIO8
SV1-3	BLACK2/SO-AN/GPIO19
SV1-4	GREEN1/CS-N/GPIO9
SV1-5	BLUE1/CLK/GPIO10
SV1-6	YELLOW1/SI-A/GPIO11
SV1-7	RED1/SI-B/GPIO12
SV1-8	SV1-9
SV1-10	SV1-11
SV1-12	SV1-13
SV1-14	SV1-15
SV1-16	SV1-17
SV1-18	SV1-19
SV1-20	SV1-21
SV1-22	SV1-23
SV1-24	SV1-25
SV1-26	